

SpyCentre Security 00854041008712

Micro Voice Recorder User Manual

Model: 00854041008712 | Brand: SpyCentre Security

1. INTRODUCTION

This manual provides comprehensive instructions for the SpyCentre Security Micro Voice Recorder. Designed for discreet and efficient audio capture, this device features voice-activated recording, extended battery life, and ample memory storage. Please read this manual carefully to ensure proper use and to maximize the performance of your device.

2. PRODUCT OVERVIEW

The Micro Voice Recorder is a compact USB flash drive-style device. It integrates a high-quality microphone and internal memory for audio recording. Below are key components and their functions:



Figure 2.1: Front view of the Micro Voice Recorder. This image shows the overall compact, rectangular design of the device, resembling a standard USB flash drive.



Figure 2.2: The Micro Voice Recorder held in a hand, illustrating its small and discreet size, similar to a thumb drive.



Figure 2.3: Close-up view of the Micro Voice Recorder with its cap removed, revealing the standard USB input and a small hole for the battery indicator light.



Figure 2.4: Top view of the recorder showing the recording dial with two distinct settings: two dots for Voice Activated Recording and a dash for Continuous Recording.



Figure 2.5: Angled view highlighting the location of the embedded microphone on the side of the device, near the USB end.



Figure 2.6: Diagram showing the approximate dimensions of the recorder: 2.5 inches in length and 0.5 inches in width.

Product Demonstration Video

This video provides a visual overview of the Micro Voice Recorder, demonstrating its compact size, key features, and how to connect it for charging and file transfer. It highlights the discreet design and ease of use.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the device. Plug the Micro Voice Recorder into any standard USB port (e.g., on a computer or a USB wall adapter). The device is not compatible with USB-C ports. A full charge typically takes approximately 2 hours. The battery indicator light will provide feedback on charging status.

3.2 Setting Date and Time Stamp (Windows Only)

To ensure your recordings are accurately time-stamped, connect the device to a Windows computer. Use the provided Windows-only software to set the current date and time. This software also allows you to adjust recording quality and automatic recording level control.

4. OPERATING INSTRUCTIONS

4.1 Recording Modes

The device offers two recording modes, selected via a physical dial on the unit:

- **Voice Activated Recording (VOS Mode):** Move the dial to the position marked with **two dots**. In this mode, the recorder will only activate and record when it detects sound, conserving battery life and memory. The battery can last up to 25 days in VOS mode, depending on environmental noise.
- **Continuous Recording:** Move the dial to the position marked with **adash**. The device will record continuously until the battery runs out or memory is full. It can record continuously for up to 24 hours on a full battery.

4.2 Starting and Stopping Recording

To begin recording, simply move the recording dial to your desired mode (Voice Activated or Continuous). Recording starts within seconds. To stop recording, move the dial back to the off position.

4.3 Accessing and Managing Recordings

To listen to or transfer recordings:

1. Ensure the device is in the off position.
2. Plug the Micro Voice Recorder into a standard USB port on a Windows or Mac computer.
3. The device will appear as a removable drive. Navigate to the drive to find your audio files (MP3 format).
4. You can play, copy, or delete files as you would with any other USB flash drive. No additional software is required for basic file management.

4.4 Memory and Recording Quality

The device features 8GB of internal flash memory. Recording capacity varies based on selected quality settings (adjustable via Windows-only software):

- **PCM Quality:** Approximately 23 hours of recording.
- **XHQ Quality:** Approximately 144 hours of recording.
- **HQ Quality:** Approximately 288 hours of recording.

5. MAINTENANCE

5.1 Battery Care

To prolong battery life, avoid fully discharging the device frequently. Recharge the device promptly when the battery indicator suggests low power. Store the device in a cool, dry place when not in use for extended periods.

5.2 Cleaning

Wipe the exterior of the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the device or its internal components.

5.3 Storage

When not in use, store the device with its USB cap on to protect the connector from dust and damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not recording.	Incorrect recording mode selected; Battery is low or depleted; Memory is full.	Ensure the dial is set to either Voice Activated (two dots) or Continuous (dash) mode. Charge the device fully. Transfer files to your computer and delete them from the device to free up space.
Recordings have poor quality or are silent.	Microphone obstructed; Device too far from sound source; Low recording quality setting.	Ensure the embedded microphone is not covered. Place the device closer to the sound source. Adjust recording quality to PCM or XHQ using the Windows-only software.
Date and Time Stamp is incorrect.	Date/Time not synchronized.	Connect the device to a Windows computer and use the dedicated software to synchronize the date and time. This feature is only available on Windows.
Device not recognized by computer.	Loose USB connection; Damaged USB port; Device not in off position.	Ensure the device is firmly plugged into a standard USB port. Try a different USB port or computer. Make sure the recording dial is in the off position before connecting to a computer.

7. SPECIFICATIONS

Model Number: 00854041008712

Product Dimensions: 2.67 x 0.43 x 0.82 inches

Item Weight: 0.4 ounces

Memory Storage Capacity: 8 GB

Battery Type: 1 Lithium Polymer battery (included)

Battery Life (Continuous Recording): Up to 24 Hours

Battery Life (Voice Activated Mode): Up to 25 Days (standby, depending on noise)

Charging Time: Approximately 2 hours

Audio Format: MP3

Microphone: Built-In

Hardware Interface: USB (Standard USB-A, not USB-C compatible)

Compatible Devices: Personal Computer (Windows/Mac for file access, Windows for advanced settings)

Manufacturer: Esonic



Date First Available: October 7, 2019





8. WARRANTY AND SUPPORT

SpyCentre Security offers a **1-year warranty** on this product from the date of purchase. Additionally, lifetime technical support is available for all customers. For assistance, please contact SpyCentre Security customer service through their official website or the retailer where the product was purchased.

For further information or to access the Windows-only software for advanced settings, please visit the [SpyCentre Security Store](#).

Related Documents - 00854041008712

	<p>6847 World's Thinnest Micro Voice Recorder: User Guide & Instructions</p> <p>Comprehensive guide for the 6847 World's Thinnest Micro Voice Recorder. Learn how to charge, record, playback, manage files, set time/date, and use VLC Media Player. Includes troubleshooting tips.</p>
	<p>SpyCentre 1758-1 Micro Voice Recorder User Guide</p> <p>Comprehensive guide for the SpyCentre 1758-1 World's Smallest Micro Voice Recorder, covering charging, recording modes (continuous and voice-activated), file playback on various devices (PC, Mac, Android, Chromebook), and software setup.</p>

	<p>6676 Pro USB Audio Recorder: User Guide and Setup Instructions</p> <p>Comprehensive guide for the 6676 Pro USB Audio Recorder by SpyCentre Security. Learn how to charge the device, record audio, manage files on Windows, Mac, Chromebook, and Android devices, and set the time and date. Includes information on using VLC Media Player for playback.</p>
	<p>SpyCentre 6677 USB Audio Recorder: User Guide and Instructions</p> <p>Comprehensive guide for the SpyCentre 6677 USB Audio Recorder, covering charging, recording, file management, time/date setting, and playback on various devices.</p>
	<p>Mini Pen Interview Recorder User Manual</p> <p>User manual for the Mini Pen Interview Recorder, a discreet DVR disguised as a pen for personal security, journalism, and surveillance. Includes setup, operation, and FAQ.</p>
	<p>Nokia 2720 User Manual: Features, Setup, and Operation</p> <p>Comprehensive user manual for the Nokia 2720, covering setup, basic operations, connectivity, personalization, camera, music, organization, security, and safety information.</p>