

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SIMPLETASTE](#) /
- › [SIMPLETASTE Electric Salt and Pepper Grinder Set User Manual](#)

SIMPLETASTE 710-0002

SIMPLETASTE Electric Salt and Pepper Grinder Set

Model: 710-0002

INTRODUCTION

Thank you for choosing the SIMPLETASTE Electric Salt and Pepper Grinder Set. This automatic, one-handed grinder set is designed to simplify your seasoning process, bringing convenience and elegance to your kitchen. Featuring a durable stainless steel body, rustproof ceramic core, adjustable coarseness settings, and a built-in LED light, these grinders ensure a perfect seasoning experience every time.

IMPORTANT SAFETY INFORMATION

WARNING:

This appliance is not intended for use by dependents and children. All use by dependents should be supervised by a responsible, capable adult.

- Do not immerse the grinder in water or other liquids.
- Do not use abrasive cleaners or harsh chemicals on the grinder.
- Keep out of reach of children.
- Ensure batteries are inserted correctly according to polarity markings.
- Remove batteries if the grinder will not be used for an extended period.

PACKAGE CONTENTS

- 2 x SIMPLETASTE Electric Grinders (Silver)
- 1 x Stand Base
- 1 x User Manual (this document)

PRODUCT OVERVIEW



Figure 1: Exploded view of the grinder, highlighting the stainless steel top cover, grinding button, motor housing and battery compartment, adjustable screw, 30g peppercorns capacity, and grinder base.

- **Stainless Steel Top Cover:** Protects the internal components and provides a sleek finish.
- **Grinding Button:** Activates the grinding mechanism for one-handed operation.
- **Motor Housing and Battery Compartment:** Houses the motor and batteries.
- **Adjustable Screw:** Located at the bottom, allows for precise control over grind coarseness.
- **Grinder Base:** The transparent section where salt or pepper is stored.

SETUP

1. Battery Installation



Figure 2: Visual guide for disassembling, installing batteries, and refilling the grinder.

1. Gently pull the top stainless steel cover upwards to separate the top section from the transparent spice container (refer to step 1 in Figure 2).
2. Unscrew the motor housing from the spice container (refer to step 2 in Figure 2).
3. Open the battery compartment cover located at the top of the motor housing.
4. Insert 6 x AAA batteries (not included) into the compartment, ensuring correct polarity (+/-) as indicated (refer to step 3 in Figure 2).
5. Replace the battery compartment cover.

2. Filling the Grinder

6. Fill the transparent spice container with your desired whole peppercorns, coarse salt, or other spices. Do not overfill.
7. Reattach the motor housing to the spice container by screwing it back on securely.
8. Place the stainless steel top cover back onto the assembled grinder (refer to step 4 in Figure 2).

OPERATION

1. Grinding Spices

Upgraded Integrated LED

Very considerate design, automatically lights up during grinding



Figure 3: The grinder in use, demonstrating the integrated LED light illuminating the seasoning area.

To operate the grinder, simply press and hold the grinding button located on the top of the unit. The grinder will automatically begin to grind your spices. Release the button to stop grinding.

The built-in LED light will automatically illuminate during grinding, providing visibility to ensure precise seasoning, even in low-light conditions.

2. Adjusting Coarseness

Adjustable

Control the fineness of your pepper grinding by using the adjustable screw.




Figure 4: Illustration of the adjustable screw at the bottom of the grinder, allowing selection between finer, middle finer, and coarser grinds.

The grinder features an adjustable ceramic grinding mechanism. To change the coarseness of your grind:

1. Locate the adjustable screw at the bottom of the grinder.
2. Turn the screw clockwise for a finer grind.
3. Turn the screw counter-clockwise for a coarser grind.
4. There are 5 different settings to choose from, allowing you to customize your seasoning to your preference.

MAINTENANCE AND CLEANING

- **Cleaning:** Wipe the exterior of the grinder with a soft, damp cloth. Do not use abrasive cleaners.
- **Dishwasher Safety:** This product is NOT dishwasher safe.
- **Spice Residue:** The bottom cap helps keep counters clean. Periodically check and clean any spice residue that may accumulate around the grinding mechanism or on the stand base.
- **Storage:** Store the grinders upright in their stand base in a dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinder not working / No power	Batteries are dead or incorrectly installed.	Replace with new AAA batteries, ensuring correct polarity.
Grinding is weak or inconsistent	Low battery power; grinding mechanism clogged; coarseness setting too fine for spice.	Replace batteries. Clear any blockages from the grinding mechanism. Adjust coarseness to a coarser setting.
LED light not illuminating	Batteries are dead or incorrectly installed; LED malfunction.	Replace batteries. If problem persists, contact customer support.
Spice leakage from bottom	Grinder base not securely attached; excessive residue.	Ensure all parts are screwed on tightly. Clean accumulated spice residue.

SPECIFICATIONS

Brand: SIMPLETASTE

Model: 710-0002

Material: Stainless Steel, Ceramic (grinding mechanism)

Color: Silver

Product Dimensions: 1.96"W x 7"H (each grinder)

Item Weight: Approximately 1.32 pounds (600 Grams) per set

Operation Mode: Automatic, One-Handed

Power Source: 6 x AAA batteries (not included) per grinder (total 12 AAA for the set)

Recommended Uses: Kitchen (Salt, Pepper, other whole spices)

Dishwasher Safe: No

WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty claims, please contact SIMPLETASTE customer service through the retailer where the product was purchased or visit the official SIMPLETASTE website for contact information.

Please retain your proof of purchase for warranty purposes.