

[manuals.plus](#) /

› [OIVO](#) /

› [OIVO PS4 Controller Charging Station User Manual for PlayStation 4 / Slim / Pro](#)

OIVO 12359687031

OIVO PS4 Controller Charging Station User Manual

Model: 12359687031

1. PRODUCT OVERVIEW

The OIVO PS4 Controller Charging Station is designed to efficiently charge two PlayStation 4, PS4 Slim, or PS4 Pro controllers simultaneously. It features LED indicators to display charging status and incorporates intelligent protection mechanisms to ensure safe and reliable operation.



Image 1.1: The OIVO PS4 Controller Charging Station, capable of charging two controllers simultaneously.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x OIVO PS4 Controller Charging Station
- 1 x Charging Cable (Micro USB)
- 1 x User Manual (this document)

3. SETUP INSTRUCTIONS

1. **Connect the Charging Station:** Insert the provided charging cable into the Micro USB port on the back of the charging station. Connect the other end of the cable to a compatible 5V/1A power source. Compatible sources include a computer USB port, PS4/Slim/Pro console USB port, wall adapter (not included), or a power bank.
2. **Place Controllers for Charging:** Align the charging port on your PS4 controller with the connector pins on the charging station. Gently push the controller down until it securely docks. The LED indicator

on the station will change color to show the charging status.



Image 3.1: Illustration of compatible power sources and how to correctly place a PS4 controller onto the charging station.

4. OPERATING INSTRUCTIONS

4.1 Charging Controllers

Once controllers are docked, the charging process begins automatically. The station is designed to charge two controllers simultaneously in approximately 1.8 hours.

- **LED Indicator:** The front panel features LED indicators for each charging slot.
- **Red Light:** Indicates that the PS4 controller is currently charging.
- **Blue Light:** Indicates that the PS4 controller is fully charged or the station is in standby mode (no controller or fully charged controller).

LED Indicator

The light clearly indicate the charging stauts



Image 4.1: The LED indicators on the charging station display red when charging and blue when fully charged or in standby.

4.2 Fast Charging Capability

The charging station is equipped with an upgraded copper chip, enabling fast charging for both controllers. This allows for a full charge of two controllers in approximately 1.8 hours.

Charge Rapide et Sécurisé

Permet la charge la plus rapide en 1.8 heures



Eclairage Rouge: En Charge



Eclairage Bleu:
Chargé / Mode Veille



Image 4.2: Visual representation of the 1.8-hour fast charging cycle for two controllers.

5. SAFETY FEATURES

The OIVO PS4 Controller Charging Station integrates smart chips and high-quality components to provide comprehensive protection for your controllers and the charging station itself. These protections include:

- **Over-Heated Protection:** Prevents overheating during charging.
- **Short-Circuit Protection:** Safeguards against short circuits.
- **Over-Current Protection:** Protects against excessive current flow.
- **Over-Voltage Protection:** Shields against voltage spikes.



Image 5.1: Visual representation of the intelligent protection features built into the charging station.

6. MAINTENANCE

- **Cleaning:** Disconnect the charging station from the power source before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the charging station in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping or subjecting the device to strong impacts. Do not attempt to disassemble or repair the unit yourself.

7. TROUBLESHOOTING

Problem	Solution

Problem	Solution
Controller not charging (no LED light)	<ul style="list-style-type: none"> Ensure the charging cable is securely connected to both the station and the power source. Verify the power source is active and providing 5V/1A output. Check if the controller is properly docked and making contact with the charging pins. Try a different USB port or power adapter.
Charging is slow	<ul style="list-style-type: none"> Ensure your power source provides at least 5V/1A. Lower power output may result in slower charging. Confirm the charging cable is not damaged.
LED light is blue but controller is not fully charged	<ul style="list-style-type: none"> Remove and re-dock the controller to reset the connection. Ensure the controller's battery is functioning correctly.

8. SPECIFICATIONS

Feature	Detail
Brand	OIVO
Model Number	12359687031
Color	Blue
Connector Type	USB
Compatible Devices	Game Console (PS4, PS4 Slim, PS4 Pro controllers)
Special Features	Fast Charging
Total USB Ports	2 (for charging controllers)
Input Voltage	5 Volts
Amperage	1 A
Included Components	USB Cable
Manufacturer	OIVO
Country of Origin	China

9. WARRANTY AND SUPPORT

This OIVO product comes with a **2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by accident, misuse, abuse, neglect, unauthorized modification or repair, or damage from external causes such as power surges.

For warranty claims or technical support, please contact OIVO customer service through the retailer where the product was purchased or visit the official OIVO website for contact information.