

## Furgle RE7

# Furgle Gaming Chair Instruction Manual

Model: RE7

## 1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Always assemble the chair according to the provided instructions.
- Do not exceed the maximum weight recommendation of 330 pounds (150 kg) to ensure stability and safety.
- Keep the chair on a stable, flat surface to prevent tipping.
- Do not leave the chair unattended while in the reclined position to prevent falls.
- Ensure all screws and bolts are tightened securely before use. Periodically check and re-tighten as necessary.

## 2. INCLUDED COMPONENTS

Verify all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Figure 2.1: All chair components including seat, backrest, armrests, base, casters, gas lift, and hardware.

Components include:

- User Manual
- Casters (Wheels)
- 5-Star Metal Base
- Gas Lift Cylinder
- Seat Cushion
- Backrest
- Adjustable Armrests
- Headrest Pillow

- Lumbar Support Pillow
- Mounting Hardware (screws, washers, Allen wrench)

---

## 3. SETUP AND ASSEMBLY

Follow these steps to assemble your Furgle Gaming Chair. It is recommended to have a second person assist with certain steps for ease and safety.

### 3.1. Base Assembly

1. Insert the five casters into the holes at the end of each leg of the 5-star metal base. Push firmly until they click into place.
2. Insert the gas lift cylinder into the center hole of the assembled base. Place the gas lift cover over the cylinder.

### 3.2. Seat and Backrest Assembly

3. Attach the seat plate mechanism to the underside of the seat cushion using the provided screws. Ensure the front of the mechanism faces the front of the seat.
4. Attach the backrest to the seat cushion using the side brackets and screws. Align the holes carefully and tighten all screws securely.
5. Attach the armrests to the seat using the designated screw holes. Ensure they are firmly attached.

### 3.3. Final Assembly

6. Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.
7. Attach the headrest pillow and lumbar support pillow using their integrated straps. Adjust their positions for optimal comfort.

### 3.4. Assembly Video Guide

Video 3.1: Detailed installation instructions for the Furgle Gaming Chair.

---

## 4. OPERATING INSTRUCTIONS

Your Furgle Gaming Chair offers multiple adjustment options for personalized comfort.

### 4.1. Seat Height Adjustment

- To raise the seat: Pull the lever on the right side of the seat upwards while taking your weight off the seat. Release the lever at the desired height.
- To lower the seat: Pull the lever on the right side of the seat upwards while seated. Release the lever at the desired height.

### 4.2. Recline Function

- To recline the backrest: Pull the lever on the left side of the seat upwards and lean back to the desired angle (90 to 180 degrees). Release the lever to lock the position.
- To return to upright position: Pull the lever on the left side upwards and lean forward. The backrest will return to its upright position.



Figure 4.1: Visual guide to chair adjustments including recline and height.

### 4.3. Rocking Mode

- To enable rocking: Pull the height adjustment lever outwards. The chair will now rock freely.
- To disable rocking: Push the height adjustment lever inwards. The chair will lock in the upright position.
- Tension adjustment: Rotate the round knob located under the seat to adjust the tension of the rocking mechanism. Turn clockwise to increase tension (harder to rock), counter-clockwise to decrease tension (easier to rock).

### 4.4. Adjustable Armrests

- The armrests can be adjusted vertically. Locate the button on the side of each armrest. Press and hold the button, then move the armrest up or down to your desired height. Release the button to lock.



Figure 4.2: Key features and adjustable components of the chair.

## 4.5. Usage and Function Video Guide

Video 4.1: Understanding the functions and adjustments of the gaming chair.

## 5. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your Furgle Gaming Chair.

- **Cleaning:** Wipe the PU leather surfaces with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts, especially those connecting the backrest, seat, and armrests. Re-tighten any loose hardware to ensure stability and prevent squeaking.
- **Casters:** Clean the casters regularly to remove dust, hair, and debris that can impede smooth rolling.
- **Gas Lift:** The gas lift is a sealed unit and requires no maintenance. If the chair is not holding its height, the gas lift may need replacement.

## 6. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Chair Squeaks or Creaks	Loose hardware; friction between components.	Tighten all assembly screws. Apply a small amount of silicone lubricant to moving parts or contact points if necessary.
Chair Sinks or Does Not Hold Height	Gas lift cylinder failure.	The gas lift cylinder may need to be replaced. Contact customer support for assistance.
Armrests are Loose or Wobbly	Loose screws connecting armrests to the seat.	Re-tighten the screws securing the armrests to the chair.
Chair Does Not Roll Smoothly	Debris in casters; damaged casters.	Remove any hair or debris from the caster wheels. If damaged, replace the casters.

If the problem persists after attempting these solutions, please contact customer support.

## 7. SPECIFICATIONS

- **Brand:** Furgle
- **Model:** RE7
- **Color:** Black
- **Product Dimensions:** 21"D x 23"W x 56"H
- **Maximum Weight Recommendation:** 330 Pounds (150 kg)
- **Material:** PU Leather, Sponge (Fill Material)
- **Back Style:** Solid Back
- **Special Features:** Adjustable, Sturdy, Ergonomic, Rocking Mode
- **Arm Style:** With arms (Adjustable)
- **Furniture Base Movement:** Swivel
- **Reclining Position Count:** 3 (Adjustable from 90-180 degrees)
- **Item Weight:** 46.2 pounds
- **UPC:** 778992168823

## 8. WARRANTY AND SUPPORT

Warranty information for your Furgle Gaming Chair is typically provided with your purchase. Please refer to the documentation included in your product packaging for specific warranty terms and conditions.

For technical support, replacement parts, or any other inquiries, please visit the official Furgle website or contact their customer service department directly. Contact information can usually be found on the product packaging or the manufacturer's website.

Video 8.1: General usage and installation guide for the Furgle Gaming Chair.

