



Manuals.plus /

- › BALI OUTDOORS /
- › BALI OUTDOORS 50000 BTU Propane Fire Pit Instruction Manual

## BALI OUTDOORS 30in-Tile Type

# BALI OUTDOORS 50000 BTU Propane Fire Pit Instruction Manual

Model: 30in-Tile Type (ASIN: B07YYSD4P1)  
Brand: BALI OUTDOORS

## 1. INTRODUCTION

---

This manual provides essential information for the safe assembly, operation, and maintenance of your BALI OUTDOORS 50000 BTU Propane Fire Pit. Please read all instructions carefully before use to ensure proper function and safety.



Image 1: BALI OUTDOORS 30-inch Propane Fire Pit in operation, highlighting its modern design with a tile tabletop and a sturdy metal base, emitting a warm flame.

## 2. IMPORTANT SAFETY INFORMATION

---

**WARNING:** Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- Keep a safe distance from combustible materials.
- Use only the specified fuel type (Liquefied Petroleum Gas).
- Be cautious of potential fire hazards.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- An LP cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.
- Always ensure adequate ventilation.
- Never leave the fire pit unattended when in use.
- Keep children and pets away from the fire pit.

- Do not use the fire pit in an enclosed space.
- Ensure all connections are tight and leak-free before operation.

### 3. PACKAGE CONTENTS

---

Verify that all components are present and undamaged before assembly. If any parts are missing or damaged, do not attempt to assemble or operate the fire pit. Contact customer support immediately.

Item	Description	Quantity
Fire Pit Table Frame	Main body of the fire pit.	1
Burner Assembly	Pre-assembled burner with control knob and hose.	1
Lava Rocks / Glass Stones	Decorative media for the burner pan.	1 bag
Tabletop Tiles	Ceramic tiles for the table surface.	4
Burner Lid / Cover	Cover for the burner area when not in use.	1
Hardware Pack	Screws, bolts, and tools for assembly.	1 set
Instruction Manual	This document.	1

### 4. SETUP AND ASSEMBLY

---

Assembly is designed to be straightforward and typically takes less than 30 minutes. Follow these steps carefully:

1. Unpack all components and lay them out on a clean, flat, non-abrasive surface.
2. Attach the legs to the main fire pit frame using the provided hardware. Ensure all connections are secure.
3. Install the burner assembly into the designated opening on the tabletop. Connect the gas hose to the burner.
4. Place the tabletop tiles into their respective slots around the burner opening.
5. Carefully place the glass stones or lava rocks into the burner pan, ensuring not to block the igniter or burner holes.
6. Connect the gas hose from the burner assembly to a standard 20 lb propane tank (not included). Ensure the tank is placed securely inside the fire pit's enclosure.
7. Perform a leak test on all gas connections before first use. Apply a soapy water solution to all connections; bubbles indicate a leak. If a leak is detected, tighten the connection and retest. Do not operate if a leak persists.

# Easy to Assembly

Assembled in Less Than 30 Minutes



Image 2: A person demonstrating the assembly process of the fire pit, highlighting the ease of setup.



Image 3: The fire pit with its side panel open, showing the internal compartment designed to house a 20lb propane tank (not included). Dimensions of 30x30x25 inches are indicated.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Ignition

1. Ensure the propane tank valve is fully open.
2. Push and turn the control knob to the "LOW" position.
3. Press and hold the igniter button until the burner ignites. You may need to hold the button for a few seconds.
4. Once ignited, continue to hold the control knob in for 10-15 seconds to allow the thermocouple to heat up.
5. Release the control knob. If the flame extinguishes, repeat steps 2-4.

### 5.2. Flame Adjustment

Once the fire pit is lit, you can adjust the flame height by rotating the control knob between "LOW" and "HIGH" settings.

### 5.3. Shut-down

1. Turn the control knob to the "OFF" position.
2. Close the valve on the propane tank.
3. Allow the fire pit to cool completely before covering or moving.

## 6. MAINTENANCE

---

- **Cleaning:** Regularly clean the exterior surfaces with a soft cloth and mild detergent. Do not use abrasive cleaners. Ensure the burner and igniter are free from debris.
- **Storage:** When not in use, especially during off-season or inclement weather, cover the fire pit with a weather-resistant cover. Disconnect the propane tank and store it in a cool, dry, well-ventilated area away from direct sunlight and heat sources.
- **Inspection:** Periodically inspect the gas hose for any signs of wear, cuts, or damage. Check all connections for tightness.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Burner does not ignite.	No gas flow; igniter issue; air in line.	Check propane tank valve; ensure tank is not empty; check igniter electrode for spark; purge air from gas line by repeating ignition steps.
Low flame or inconsistent flame.	Low gas pressure; partially closed tank valve; debris in burner.	Ensure tank valve is fully open; check for kinks in hose; clean burner ports.
Smell of gas.	Gas leak.	Immediately turn off gas at the tank. Perform a leak test with soapy water. Do not operate until leak is fixed. If smell persists, contact emergency services.
Fire pit does not stay lit.	Thermocouple not heating sufficiently; control knob not held long enough.	Ensure thermocouple is in flame path; hold control knob for 10-15 seconds after ignition.

## 8. SPECIFICATIONS

---

Attribute	Detail
Brand	BALI OUTDOORS
Model	30in-Tile Type
ASIN	B07YYSD4P1
Material	Metal
Product Dimensions	30"D x 30"W x 25"H
Style	Elegant
Finish Type	Painted
Shape	Square
Item Weight	68 Pounds
Fuel Type	Liquefied Petroleum Gas
Heat Output	50,000 BTU
Color	black

## 9. WARRANTY AND CUSTOMER SUPPORT

---

BALI OUTDOORS products are manufactured to high-quality standards. For warranty information, product support, or to inquire about replacement parts, please contact BALI OUTDOORS customer service.

You can typically find contact information on the manufacturer's website or through your point of purchase. Please have your model number (30in-Tile Type) and ASIN (B07YYSD4P1) ready when contacting support.

For additional resources, visit the official BALI OUTDOORS Store: [BALI OUTDOORS Store on Amazon](#).

## 10. PRODUCT VIDEOS (IF AVAILABLE)

---

Based on the provided product data, specific official product videos with creator type "Seller" were not identified for direct embedding. Please refer to the product listing on Amazon for any available video content.

