Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EGLO 203544A

EGLO 203544A Delvelde Pendant Light User Manual

Model: 203544A

Introduction

This manual provides essential information for the safe installation, operation, and maintenance of your EGLO Delvelde Pendant Light, Model 203544A. Please read these instructions thoroughly before beginning installation and retain them for future reference.

Safety Information

WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the circuit breaker or fuse box before installation or servicing. Improper installation can result in electric shock or fire.

- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Do not install this fixture in wet locations. It is designed for indoor use only.
- Handle the fixture with care to avoid damage.
- Use only the specified bulb type and wattage to prevent overheating.

Package Contents

Verify that all components are present before beginning installation:

- 1 x Delvelde Pendant Light Fixture
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

Note: Light bulb(s) are not included and must be purchased separately.

Setup and Installation

Follow these steps carefully for proper installation:

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the light fixture's power supply. Turn off the power completely before proceeding.
2. **Prepare Mounting Location:** If replacing an existing fixture, carefully remove it. Ensure the junction box is securely mounted and capable of supporting the pendant light's weight.
3. **Attach Mounting Plate:** Secure the provided mounting plate to the junction box using the screws.
4. **Make Electrical Connections:**
    - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box.
    - Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box.
    - Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the junction box.
    - Secure all connections with wire nuts and wrap with electrical tape for added safety.
5. **Mount the Fixture:** Carefully tuck all wires into the junction box. Align the fixture canopy with the mounting plate and secure it using the provided screws.
6. **Install Bulb:** Screw one A19 60-Watt maximum bulb (not included) into the socket.
7. **Restore Power:** Turn the power back on at the circuit breaker or fuse box. Test the light fixture.



Figure 1: Front view of the EGLO Delvelde Pendant Light. This image shows the matte nickel finish and the metal cage surrounding the bulb.



Figure 2: EGLO Delvelde Pendant Light with indicated dimensions. The fixture measures approximately 7 inches in width and 57 inches in height (including the rod).

Operating Instructions

The EGLO Delvelde Pendant Light is designed for simple operation:

- **Bulb Type:** Uses 1 A19 60-Watt bulb (not included). LED bulbs are compatible.

- **Dimmer Compatibility:** This fixture is compatible with standard wall dimmers (not included). Ensure the bulb used is also dimmable if you intend to use a dimmer switch.
- **Power Control:** Operate the light using a standard wall switch or compatible dimmer switch.

Maintenance

To maintain the appearance and functionality of your pendant light:

- **Cleaning:** Always disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure power is off before replacing the bulb. Allow the old bulb to cool completely before removal. Screw in the new A19 60-Watt maximum bulb.
- **Inspection:** Periodically check all electrical connections and mounting hardware for tightness.

Troubleshooting

If your pendant light is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture	Check circuit breaker or fuse. Ensure wall switch is on.
	Loose wire connections	Turn off power, check and tighten all wire connections.
	Defective bulb	Replace bulb with a new one.
Light flickers	Loose bulb or wiring	Turn off power, tighten bulb. Check wire connections.
	Incompatible dimmer or bulb	Ensure both bulb and dimmer are compatible with each other and the fixture.

Specifications

- **Model:** 203544A
- **Brand:** EGLO
- **Material:** Alloy Steel, Metal Shade
- **Finish:** Matte Nickel, Painted
- **Dimensions:** 7 x 7 x 12 inches (fixture body), 57 inches (overall height)
- **Item Weight:** 3.35 pounds
- **Light Source:** 1 x A19 bulb (not included)
- **Max Wattage:** 60 Watts
- **Bulb Base:** E26
- **Voltage:** 120 Volts
- **Installation Type:** Semi Flush Mount / Pendant
- **Indoor/Outdoor Usage:** Indoor
- **Control Method:** Touch (via compatible dimmer switch)
- **Brightness:** 800 Lumens (with compatible bulb)

Warranty and Support

This EGLO product is covered by a **90-day warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical support, or replacement parts, please contact EGLO customer service through their official website or the retailer where the product was purchased. Please have your model number (203544A) and proof of purchase available.
For more information, visit the EGLO Store on Amazon.

© 2023 EGLO Lighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YYT6Y7V

More documents and user manuals: **https://manuals.plus/**