

[manuals.plus](#) /

- › [Best Choice Products](#) /
- › [Best Choice Products 88-Key Full Size Digital Piano Electronic Keyboard Set Instruction Manual](#)

## **Best Choice Products SKY5484**

# **Best Choice Products 88-Key Full Size Digital Piano**

## **INSTRUCTION MANUAL**

### **INTRODUCTION**

Thank you for choosing the Best Choice Products 88-Key Full Size Digital Piano. This manual provides essential information for the proper setup, operation, and maintenance of your new instrument. Please read it thoroughly before use to ensure optimal performance and longevity.



Figure 1: Best Choice Products 88-Key Digital Piano. This image shows the full digital piano setup, including the keyboard, X-style stand, and sustain pedal.

## 1. SETUP

---

### 1.1 Unpacking and Contents

Carefully remove all components from the packaging. Ensure all parts listed below are present.

# WHAT'S INCLUDED



x1 Keyboard



x1 Stand



x1 Holder



x1 Sustain Pedal

Figure 2: Included Components. This image displays the main components: the 88-key keyboard, the X-style stand, the music holder, and the sustain pedal.

- 88-Key Digital Piano
- X-Style Keyboard Stand
- Sustain Pedal
- Music Holder
- Power Adapter

## 1.2 Assembly Instructions

1. **Assemble the Stand:** Unfold the X-style keyboard stand and adjust it to your desired height. Ensure it is stable and level on a flat surface.
2. **Place the Keyboard:** Carefully place the 88-key digital piano onto the assembled stand. Ensure it is securely seated and does not wobble.
3. **Connect the Sustain Pedal:** Locate the sustain pedal input jack on the back or side of the keyboard and firmly insert the pedal cable.
4. **Connect Power:** Insert the power adapter cable into the DC IN jack on the keyboard. Plug the other end of the adapter into a standard electrical outlet.
5. **Attach Music Holder:** Slide the music holder into the designated slots on the top panel of the keyboard.

## 2. OPERATING YOUR DIGITAL PIANO

### 2.1 Power On/Off

Press the **POWER** button located on the top left of the control panel to turn the piano on or off. A blue indicator light will illuminate when the piano is powered on.

### 2.2 Volume Control

Adjust the overall volume using the **VOLUME** knob on the left side of the control panel. Turn clockwise to increase volume and counter-clockwise to decrease.

### 2.3 Key Features

- **88 Semi-Weighted Keys:** The full-size keyboard features 88 semi-weighted keys designed to provide a realistic piano feel, suitable for all experience levels.



Figure 3: 88 Semi-Weighted Keys. This image highlights the full range of 88 semi-weighted keys, providing a tactile experience similar to an acoustic piano.

- **Sustain Pedal:** The included detachable sustain pedal allows you to prolong notes, simulating the damper effect of an acoustic piano. Press the pedal to sustain notes, release to stop.

## SUSTAIN PEDAL

Hold out notes with the included pedal for a professional sound you can control




Figure 4: Sustain Pedal Function. This diagram visually explains how the sustain pedal works, showing the difference in sound wave duration when the pedal is not pressed versus when it is pressed.

- **Built-in Speakers:** Enjoy clear and rich sound through the integrated high-quality digital speakers.
- **Headphone Jack:** For private practice, connect standard 3.5mm headphones to the headphone jack. This will mute the built-in speakers.

### 2.4 Sound Settings and Functions

The control panel offers various buttons to customize your sound and utilize practice features.



Figure 5: Control Panel. This image shows the detailed control panel with buttons for various sound settings (Piano, Electronic Piano, Church Organ, Guitar, Bass, Strings, Percussion) and functions (Function, Demo, Metronome, Lesson, Split).

- **Timbre Selection:** Press the dedicated buttons to switch between different instrument sounds:
  - Piano
  - Electronic Piano
  - Church Organ
  - Guitar
  - Bass
  - Strings
  - Percussion
- **Function:** Activates advanced settings. Refer to the full PDF manual for detailed use.
- **Demo:** Plays pre-recorded demonstration songs.
- **Metronome:** Provides a steady beat for practice. Adjust tempo as needed.
- **Lesson:** Engages lesson mode for guided practice.
- **Split:** Divides the keyboard into two sections, allowing two different instrument sounds or two players.

### 3. MAINTENANCE

- Cleaning:** Use a soft, dry cloth to wipe down the surface of the piano. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive cleaners, solvents, or waxes, as these can damage the finish.
- Storage:** Store the digital piano in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. Excessive heat or cold can affect the electronic components and keyboard action.
- Handling:** Always handle the piano with care. Avoid dropping it or placing heavy objects on top of it. When moving, ensure the stand is properly secured or disassembled to prevent damage.
- Dust Protection:** When not in use, consider covering the piano with a dust cover to prevent dust accumulation on the keys and internal components.

### 4. TROUBLESHOOTING

If you encounter any issues with your digital piano, please refer to the following common troubleshooting steps before contacting customer support.

Problem	Possible Cause	Solution
No sound from speakers/headphones	Piano not powered on; Volume too low; Headphones connected; Speaker malfunction.	Ensure power is on and indicator light is blue. Increase volume. Disconnect headphones if sound is desired from speakers.
Keys not responding	Power issue; Internal malfunction.	Check power connection. Turn off and on again. If problem persists, contact support.
Distorted or poor sound quality	Volume too high; Incorrect sound setting; Speaker issue.	Lower the volume. Ensure the correct timbre is selected.
Sustain pedal not working	Pedal not fully connected; Damaged pedal/cable.	Ensure the sustain pedal cable is fully inserted into the correct jack.

For more detailed troubleshooting or issues not listed above, please refer to the official [Instructions for Use \(IFU\) PDF](#).

### 5. SPECIFICATIONS

Feature	Detail
Model Name	88-Key Weighted Full Size Digital Piano Set
Model Number	SKY5484
Number of Keys	88 (Semi-Weighted)
Product Dimensions	51"(L) x 11"(W) x 4.5"(H)
Item Weight	20.7 Pounds
Color	Black
Style	Digital

Feature	Detail
Connector Type	3.5mm Jack
Connectivity Technology	Auxiliary
Power Source	AC Power Adapter (manual operation)
Headphones Jack	3.5mm Jack
Manufacturer	Best Choice Products
UPC	842957119257
Skill Level	All
Special Feature	Portable




Figure 6: Product Dimensions. This image provides detailed measurements for both the digital piano and its accompanying stand.



## 6. WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included with your purchase or visit the official Best Choice Products website. If you require further assistance or have questions not covered in this manual, please contact Best Choice Products customer support.

**Official User Guide (PDF):** [Download Here](#)

© 2024 Best Choice Products. All rights reserved.

### Related Documents - SKY5484

	<p><a href="#">88 Key Digital Piano Instruction Manual</a> Comprehensive instruction manual for the Best Choice Products 88 Key Digital Piano with Fully Weighted Keys and U Type Stand (Model SKY6604). Includes setup, operation, features, troubleshooting, and warranty information.</p>
	<p><a href="#">Best Choice Products 61-Key Electronic Teaching Keyboard Instruction Manual</a> Comprehensive instruction manual for the Best Choice Products 61-Key Electronic Teaching Keyboard (Models SKY2954 + SKY3160), covering assembly, features, performance, and safety guidelines.</p>
	<p><a href="#">Best Choice Products 61-Key Electronic Keyboard with USB Input Instruction Manual</a> Comprehensive instruction manual for the Best Choice Products 61-Key Electronic Keyboard with USB Input (Model SKY5138), covering setup, operation, features, and troubleshooting.</p>

	<p><a href="#"><u>Best Choice Products 61-Key Electronic Teaching Keyboard Instruction Manual</u></a>  Comprehensive instruction manual for the Best Choice Products 61-Key Electronic Teaching Keyboard (Model SKY5588), covering setup, features, performance, and safety information.</p>
	<p><a href="#"><u>Best Choice Products 61-Key Electronic Keyboard with USB Input Instruction Manual</u></a>  Comprehensive instruction manual for the Best Choice Products SKY5138 61-Key Electronic Keyboard with USB Input, covering setup, operation, features, and troubleshooting.</p>
	<p><a href="#"><u>61-Key Electronic Teaching Keyboard Instruction Manual</u></a>  Comprehensive instruction manual for the 61-Key Electronic Teaching Keyboard by Best Choice Products. Learn about assembly, features, functions, and basic operation.</p>