

[Manuals.plus](#) /

› [Teamson Kids](#) /

› Teamson Kids Little Chef Charlotte Play Kitchen Instruction Manual (Model TD-12302M)

Teamson Kids TD-12302M

Teamson Kids Little Chef Charlotte Play Kitchen Instruction Manual (Model TD-12302M)

For Ages 3+

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Teamson Kids Little Chef Charlotte Play Kitchen. Designed to inspire imaginative role-play, this modular wooden kitchen set features realistic details and functional storage. Please read all instructions carefully before assembly and use.

SAFETY INFORMATION

This product is intended for external use only. Suggested for children aged 3 years and above. Avoid contact with eyes. Keep away from naked flame or direct heat sources. This kitchen set meets all U.S. safety standards (CPSIA, ASTM F963).

WHAT'S IN THE BOX

- Play Kitchen Set (Modular components: Refrigerator, Sink Unit, Stove/Oven Unit)
- 2 Play Ice Cubes
- 1 Play Cup
- Assembly Instructions

SETUP & ASSEMBLY

Assembly is required for this play kitchen. Please refer to the separate "Assembly Instruction" booklet included in the packaging for detailed, step-by-step guidance. Ensure all parts are accounted for before beginning assembly. A Phillips head screwdriver may be required (not included). The modular design allows for flexible arrangement of the refrigerator, sink, and stove units to fit various play spaces.



Figure 1: Assembled dimensions of the play kitchen, showing the refrigerator, stove, and sink units.

PRODUCT FEATURES & OPERATION

1. Refrigerator Unit with Pretend Ice Maker

- **Openable Doors:** The refrigerator features two openable doors for storing play food and accessories.
- **Pretend Ice Maker:** Insert the included play ice cubes into the dispenser. Press the lever to release the ice cubes into the play cup.
- **Lower Freezer Drawer:** A functional lower drawer provides additional storage space.



Figure 2: Child interacting with the pretend ice maker, dispensing play ice cubes into a cup.

2. Stove and Oven Unit

- **Clicking Knobs:** Four turning oven knobs produce a realistic clicking sound when rotated.
- **Oven Door:** The oven door opens to reveal interior space for play cooking.
- **Stove Burners:** Two pretend burners are integrated into the countertop.




Figure 3: Detailed view of the stove burners, clicking knobs, and farmhouse sink.

3. Sink Unit

- **Farmhouse Sink:** A deep, white farmhouse-style sink is included for pretend dishwashing.
- **Chrome Faucet:** The faucet features movable handles for an interactive experience.
- **Under-Sink Cabinet:** An openable cabinet below the sink provides additional storage.



Figure 4: Child engaging with the sink and movable faucet handles.

4. Modular Design

The play kitchen consists of three separate modular units (refrigerator, stove/oven, and sink) that can be arranged together in various configurations or used separately to suit different room layouts and play scenarios.



Figure 5: The complete modular play kitchen set, showcasing its mint and gold design.

OFFICIAL PRODUCT VIDEO



Video 1: Official product overview of the Teamson Kids Little Chef Charlotte Play Kitchen, highlighting its features and design.

MAINTENANCE

To clean the play kitchen, simply wipe surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish. Regularly check all screws and fasteners to ensure they are tight and secure for continued safe play.

TROUBLESHOOTING

- **Loose Parts:** If any parts become loose, re-tighten screws or fasteners as per the assembly instructions.
- **Doors/Drawers Not Closing Properly:** Check for any obstructions or misalignment. Ensure hinges

are securely attached.

- **Ice Maker Malfunction:** Verify that play ice cubes are correctly inserted and the lever mechanism is clear of debris.

SPECIFICATIONS

Feature	Detail
Product Dimensions	41.61 x 11.81 x 31.89 inches
Item Weight	44 pounds
Item Model Number	TD-12302M
Manufacturer	Teamson Design Corp.
Material	Engineered Wood (MDF)
Recommended Age	3+ Years

WARRANTY & SUPPORT

For warranty information or product support, please contact Teamson Kids customer service directly. Refer to the contact details provided in your product packaging or visit the official Teamson Kids website.