Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Tupperware /
- > Tupperware 450ML Freezer Container Instruction Manual

Tupperware TUPPERWARE_474

Tupperware 450ML Freezer Container Instruction Manual

Model: TUPPERWARE_474

INTRODUCTION

The Tupperware 450ML Freezer Container is specifically designed for efficient and safe storage of food items in the freezer. Its robust and flexible construction helps prevent breakage in deep freezer conditions. The container features a distinctive snowflake design, indicating its primary utility for frozen storage. This manual provides essential information for the proper use and care of your container.

SETUP

1. Unpacking

Remove the Tupperware Freezer Container from its packaging. Ensure all components, including the container base and lid, are present and undamaged.

2. Initial Cleaning

Before first use, wash the container and lid thoroughly with warm soapy water. Rinse completely and allow to air dry, or dry with a clean cloth. This removes any manufacturing residues.

3. Lid Attachment

Place the lid squarely over the container base. Press down firmly on the center of the lid, then work your way around the edges to ensure a complete and secure seal. A proper seal is crucial for preventing freezer burn and maintaining food freshness.



Image: Top view of the Tupperware 450ML Freezer Container with its lid securely in place.

OPERATING INSTRUCTIONS

1. Filling the Container

Fill the container with your desired food item. Leave a small amount of headspace (approximately 1/2 inch) to allow for expansion during freezing, especially for liquids or foods with high water content.

2. Sealing for Freezer Storage

Ensure the rim of the container is clean and free of food particles before applying the lid. Press the lid firmly onto the container until it snaps into place, creating an airtight seal. This seal is vital for protecting food from freezer burn and preserving its quality.



Image: The Tupperware 450ML Freezer Container, showing its rectangular shape and orange lid.

3. Freezing Guidelines

Place the sealed container in the freezer. The container's flexible material is designed to withstand freezing temperatures without becoming brittle. The snowflake design on the container serves as a visual indicator of its freezer-safe properties.



Image: A close-up view highlighting the embossed snowflake pattern on the side of the container, signifying its freezer utility.

4. Thawing Guidelines

When ready to use, remove the container from the freezer. Allow frozen contents to thaw in the refrigerator or at room temperature as appropriate for the food type. The container's flexibility aids in easy removal of frozen contents.

5. Material Information

This container is made from high-quality, food-safe virgin plastic, indicated by the 'Code 4' marking, which typically refers to HDPE (High-Density Polyethylene). HDPE is known for its durability, chemical resistance, and suitability for freezer use.

Maintenance and Care

1. Cleaning

The Tupperware Freezer Container is dishwasher safe. For best results and to prolong the life of the product, place it on the top rack of your dishwasher. Alternatively, hand wash with warm soapy water and a soft sponge or cloth. Avoid abrasive cleaners or scouring pads that could scratch the surface.

2. Drying and Storage

Ensure the container and lid are completely dry before storing to prevent odors or mildew. Store with the lid slightly ajar or separated to allow air circulation.



Image: The Tupperware 450ML Freezer Container with its lid removed, demonstrating its two main components.

3. Important Considerations

- **Not Microwaveable:** This container is designed for freezer storage only and is **not** suitable for microwave use.
- Avoid Sharp Objects: Do not use sharp utensils inside the container, as this may scratch or damage the

plastic.

• Stain Prevention: To minimize staining, rinse the container immediately after use, especially after storing foods with strong colors like tomato sauce or turmeric.

TROUBLESHOOTING

• Lid Not Sealing Properly:

Check if the rim of the container or the lid has any food debris or moisture. Ensure the lid is aligned correctly before pressing down. If the lid appears warped, it may need replacement.

• Food Odors Persisting:

Thoroughly wash the container with warm soapy water and a small amount of baking soda to neutralize odors. Ensure the container is completely dry before storage.

• Container Appears Brittle in Freezer:

While designed for flexibility, extreme temperature fluctuations or impacts can affect plastic. Ensure the container is not overfilled, especially with liquids, and avoid dropping it when frozen.

SPECIFICATIONS

Model Number	TUPPERWARE_474
Capacity	450 Milliliters
Material	Food-safe Virgin Plastic (HDPE - Code 4)
Container Shape	Rectangular
Closure Type	Snap
Dishwasher Safe	Yes (Top Rack Recommended)
Microwaveable	No
Item Weight	0.1 Kilograms (3.52 ounces)
Package Dimensions	6.77 x 5.04 x 2.44 inches
Special Feature	Flexible, Freezer Safe
Included Components	Container with Lid


WARRANTY INFORMATION

This Tupperware product comes with a warranty. For specific details regarding the warranty period, coverage, and claims process, please refer to the original product packaging or visit the official Tupperware website. Retain your proof of purchase for warranty purposes.

SUPPORT

For further assistance, product inquiries, or to explore other Tupperware products, please visit the official Tupperware website or contact their customer service department. You can also visit the Tupperware Store on Amazon.

Related Documents - TUPPERWARE 474





<u>Tupperware BreadSmart™ and ToastSmart™: Optimal Bread Storage Solutions</u>

Discover the Tupperware BreadSmart™ and ToastSmart™, innovative countertop solutions designed for optimal bread preservation. Learn about their CondensControl™ technology, usage, care, and warranty.