

[manuals.plus](#) /

› [Formuler](#) /

› [Formuler Original Remote Control User Manual - Model FOR0095](#)

Formuler FOR0095

Formuler Original Remote Control User Manual

Model: FOR0095

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Formuler Original Remote Control, Model FOR0095. This remote is designed to seamlessly control your compatible Formuler IPTV boxes, ensuring a user-friendly experience.

2. PRODUCT OVERVIEW

The Formuler Original Remote Control is an ergonomic and intuitive device designed for specific Formuler media players. It provides full functionality for program selection, menu navigation, and special features without complex setup procedures for the primary Formuler device.



Figure 2.1: Front and side view of the Formuler Original Remote Control, highlighting its ergonomic design and button layout.

2.1. Compatible Devices

This remote control is specifically designed for the following Formuler devices:

- Formuler Z8
- Formuler Z7+
- Formuler Z7+ 5G
- Formuler ZX
- Formuler ZX 5G
- Formuler Z Prime
- Formuler Z Alpha
- Formuler Z Nano



Figure 2.2: The Formuler remote control displayed with several compatible Formuler IPTV box models, illustrating its intended use with these devices.

3. SETUP

3.1. Battery Installation

The remote control requires **2 AAA batteries** for operation. Follow these steps to install the batteries:

1. Remove the battery compartment cover on the back of the remote control by sliding it downwards.
2. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Replace the battery compartment cover by sliding it back into place until it clicks securely.

3.2. Programming TV/STB/Source Keys (Learning Mode)

The remote control features programmable keys (TV, STB, Source) that can learn functions from other remote controls. This allows you to control basic functions of your TV or other devices directly from the Formuler remote. To program these keys:

1. Press and hold the **TV** or **STB** key for 5 seconds until the LED indicator begins to blink slowly. This indicates the remote is in Learning Mode.
2. Press the key on the Formuler remote that you wish to program (e.g., Power button under TV). The LED will blink rapidly.
3. Aim your original TV/STB remote control directly towards the front of the Formuler remote (infrared sensors should be aligned). Press and hold the corresponding button on your original remote (e.g., Power button).
4. The LED on the Formuler remote will blink three times and then stay solid, indicating successful learning.
5. Repeat steps 2-3 for any other keys you wish to program (e.g., Volume Up, Volume Down, Mute).
6. To exit Learning Mode, press any other button on the Formuler remote that is not being programmed, or wait for 10 seconds for it to exit automatically. The LED will turn off.

installation steps



- remove the cover from the remote control batteries
- insert the new AAA batteries into the remote control
- you can check if the remote control is working

*Batteries not included

Figure 3.1: Visual guide for battery installation and the three-step process for programming the remote control's learning keys.

4. OPERATING INSTRUCTIONS

The Formuler Original Remote Control provides intuitive access to all functions of your compatible Formuler device. Familiarize yourself with the button layout for optimal use.



Figure 4.1: The Formuler remote control in use, demonstrating its comfortable grip and ease of operation while controlling a Formuler device connected to a television.

4.1. Key Functions

- **Power (TV/STB):** Turns the connected device (TV or Formuler box) on or off.
- **Source:** Cycles through input sources on your TV (if programmed).
- **Number Pad (0-9):** Used for direct channel entry or inputting numbers.
- **Navigation (Up/Down/Left/Right/OK):** Navigates through menus and confirms selections.
- **Back:** Returns to the previous screen or menu.
- **Exit:** Exits the current application or menu.
- **Volume (+/-):** Adjusts the volume level.
- **Channel (CH +/-):** Changes channels.
- **EPG:** Accesses the Electronic Program Guide.
- **Favorite:** Accesses favorite channels or content.
- **Color Buttons (Red, Green, Yellow, Blue):** Perform context-sensitive functions within applications or menus.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Controls media playback.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Formuler remote control, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Dispose of old batteries responsibly according to local regulations.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. TROUBLESHOOTING

If you encounter issues with your Formuler Original Remote Control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries. Obstruction between remote and device.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed directly at the device.
Specific buttons not working (e.g., TV Power)	Button not programmed correctly in Learning Mode.	Re-program the specific button using the Learning Mode instructions (Section 3.2). Ensure proper alignment of remotes during programming.
Remote works intermittently	Low battery power. Infrared interference.	Replace batteries. Move away from strong light sources or other electronic devices that might cause interference.
Device does not respond to remote commands	Remote is not compatible with the device. Device is off or unresponsive.	Verify your Formuler device model is listed under compatible devices (Section 2.1). Ensure the device is powered on and functioning correctly.

7. SPECIFICATIONS

Detailed technical specifications for the Formuler Original Remote Control (Model FOR0095):

- **Model Number:** FOR0095
- **Product Dimensions:** 8.27 x 1.85 x 0.71 inches (21 x 4.7 x 1.8 cm)
- **Item Weight:** 3.17 ounces (90 grams)
- **Batteries Required:** 2 x AAA batteries
- **Color:** Black
- **Special Feature:** Ergonomic design, Learning Function for TV/STB/Source keys
- **Max Number of Supported Devices:** 1 (Formuler device, plus programmable keys for TV/STB/Source)



Figure 7.1: Dimensional overview of the Formuler remote control, indicating its length, width, and thickness in centimeters.

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Formuler Original Remote Control, please refer to the documentation included with your Formuler device or visit the official Formuler website. You may also contact Formuler customer service directly for assistance.

	<p>Formuler IR1 Remote: Basic Operations and App Guide</p> <p>Learn how to use your Formuler IR1 Remote for basic operations, programming TV control keys, and utilizing the Formuler Remote app for hotkey customization and system navigation.</p>
	<p>Formuler Z10 Pro (01) User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the Formuler Z10 Pro (01) media receiver. Learn about features, setup, operation, and troubleshooting.</p>
	<p>Handleiding Formuler MYTV Online 3.0 IPTV App</p> <p>Uitgebreide handleiding voor de Formuler MYTV Online 3.0 IPTV App, met details over functies, installatie en gebruik voor een verbeterde media-ervaring.</p>
	<p>FORMULER GTV Quick Setup Guide & Safety Information</p> <p>Comprehensive guide for setting up your FORMULER GTV Set Top Box, including installation steps, what's in the box, and essential safety information. Supports multiple languages.</p>
	<p>FORMULER Z10 SE Quick Setup Guide and Safety Information</p> <p>Comprehensive guide for setting up your FORMULER Z10 SE media receiver, including installation steps, box contents, safety precautions, technical specifications, and regulatory compliance information.</p>
	<p>Formuler Z11 Pro Max Quick Setup Guide & Safety Information</p> <p>A comprehensive guide to setting up and safely operating your Formuler Z11 Pro Max set-top box, including installation steps, package contents, and important safety precautions.</p>