Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Max & Lily 18-911-151

Max & Lily L-Shape Twin Over Twin Bunk Bed with Bookcase Instruction Manual

Model: 18-911-151

Product Overview

The Max & Lily L-Shape Twin Over Twin Bunk Bed with Bookcase is designed to provide a functional and space-saving sleeping solution. This bunk bed features a top twin bunk, a lower twin bed that can be moved independently, and an integrated bookcase. Constructed from solid New Zealand pine wood, it offers durability and a modern aesthetic with its slatted head and footboards and color-matched hardware.

Key features include tall guardrails on the top bunk for safety, an angled ladder with anti-slip steps, and reversible ladder and shelving unit placement to suit various room configurations. Each sleeping surface is designed to support up to 400 pounds.



Image: The Max & Lily L-Shape Twin Over Twin Bunk Bed with Bookcase, showcasing its design and integrated storage.

Important Safety Information

- Always use a mattress no thicker than 8 inches on the top bunk.
- Do not exceed the weight capacity of 400 pounds per sleeping surface.
- Keep guardrails in place at all times on the top bunk.
- Follow assembly instructions carefully to ensure stability and safety.
- This product meets or exceeds federal safety standards for children’s furniture.
- Ensure the ladder is securely attached before use.
- Only one person should occupy the top bunk at a time.

Setup and Assembly

Assembly of the Max & Lily L-Shape Bunk Bed requires two or more adults. All necessary instructions, upper/lower slat rolls, and hardware are included with your purchase. The ladder and shelving unit are designed to be reversible, allowing for installation on either the left or right side during assembly to best fit your room layout.

Carefully unpack all components and verify against the parts list provided in the assembly guide. Follow the step-by-step instructions to ensure proper and secure construction. Ensure all bolts and screws are tightened securely, but do not overtighten to avoid damaging the wood.




Image: Dimensional diagram of the bunk bed, illustrating its length, width, height, and underbed clearance.



Image: The bunk bed frame without mattresses, highlighting the slat support system.

Operating Instructions

Mattress Requirements

- For optimal fit and safety, use a 5-inch thick mattress on the top bunk.
- Do not exceed an 8-inch mattress thickness on the top bunk to maintain adequate guardrail height.
- The lower bed accommodates a standard twin-size mattress.

Weight Capacity

Each sleeping surface (top bunk and lower bed) is designed to support a maximum resting weight of 400 pounds. Adhering to this limit ensures the structural integrity and safety of the bed.



Image: Illustration of the 400 lb weight capacity per bed, supported by plywood slats and a metal bar.

Ladder Use

The angled ladder features wide, anti-slip steps for comfortable and secure climbing. Always face the ladder when ascending or descending. Ensure the ladder is firmly in place before use.



Image: Detail of the bunk bed ladder, highlighting the anti-slip grooved steps.

Bookcase Use

The integrated bookcase provides convenient storage for books, toys, and other essentials. Distribute weight evenly across the shelves and avoid overloading.



Image: A child utilizing the built-in bookcase for storage.

Maintenance

To maintain the appearance and longevity of your Max & Lily bunk bed, follow these guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the durable, low VOC finish.
- **Hardware:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain structural stability.
- **Environment:** Avoid placing the bed in direct sunlight or near heat sources, which can cause wood to dry out or warp. Maintain a stable room temperature and humidity.

Troubleshooting

Bed Wobbles After Assembly

If the bed feels unstable or wobbles, ensure all assembly hardware (bolts, screws, and connectors) is fully tightened. Check that all components are correctly aligned according to the instruction manual. Uneven flooring can also contribute to wobbling; consider using furniture pads or shims if necessary.

Missing or Damaged Parts

If you discover any missing or damaged parts upon unboxing, do not proceed with assembly. Contact Max & Lily customer support immediately with your product model number and a description of the issue for assistance with replacements.

Specifications

Feature	Detail
Brand	Max & Lily
Model Number	18-911-151
Color	Clay
Size	Twin
Product Dimensions (L x W x H)	81.5" x 42.5" x 68.5"
Item Weight	171 pounds
Material	Solid New Zealand Pine Wood
Finish Type	Wood, Low VOC
Weight Capacity (per sleeping surface)	400 pounds
Compatible Mattress Size	Twin
Assembly Required	Yes
Special Features	Color Matching Hardware, Reversible Ladder & Shelving Unit
UPC	814679021712

Warranty Information

This Max & Lily bunk bed is covered by a **1-year manufacturer's warranty**. This warranty typically covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims. For specific details regarding coverage and how to make a claim, refer to the warranty documentation included with your product or contact Max & Lily customer support.

Customer Support

For further assistance, questions, or to report any issues with your Max & Lily L-Shape Twin Over Twin Bunk Bed with Bookcase, please contact Max & Lily customer service. Have your model number (18-911-151) and purchase information ready to expedite your request.

You can find more information and contact details on the official Max & Lily website or through their brand store on Amazon:

Visit the Max & Lily Store on Amazon

© 2023 Max & Lily. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z4DTDKV

More documents and user manuals: **https://manuals.plus/**