**HUAWEI E5576-320**

# Huawei E5576-320 Mobile WiFi Hotspot User Manual

Model: E5576-320 | Brand: HUAWEI

## 1. Introduction

Welcome to the user manual for your Huawei E5576-320 Mobile WiFi Hotspot. This device provides high-speed 4G LTE connectivity, allowing you to connect multiple devices to the internet on the go. Its compact design and long-lasting battery make it an ideal companion for travel and remote work. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device.




*Figure 1: Huawei E5576-320 Mobile WiFi Hotspot, a compact white device with a black stripe across the front, featuring indicator lights and the HUAWEI logo.*

# 2. Product Overview

## Key Features:

- **4G LTE Cat4 Connectivity:** Enjoy download speeds up to 150 Mbps and 3G download speeds up to 43.2 Mbps.
- **Multi-Device Support:** Connect up to 16 different Wi-Fi devices simultaneously, including laptops, smartphones, tablets, and gaming consoles.
- **Long-Lasting Battery:** Equipped with a 1500mAh replaceable battery, providing up to 6 hours of working time.
- **Wi-Fi Repeater Function:** Can function as a Wi-Fi hotspot or repeat an existing Wi-Fi signal.
- **Enhanced Security:** Features Wi-Fi isolation to ensure online safety and control connected devices.
- **Easy Connection:** Supports 2D Barcode for convenient connection and LTE/3G/Wi-Fi auto offload.
- **HUAWEI Mobile WiFi App Support:** Manage your device settings easily through the dedicated mobile application.

## Package Contents:

- Huawei E5576-320 Mobile WiFi Hotspot
- 1500mAh Lithium Polymer Battery
- USB Charging Cable
- Quick Start Guide (Multi-language)
- Warranty Card

# 3. Setup

## 3.1. Inserting the SIM Card

1. Remove the back cover of the device by gently prying it open from the designated notch.
2. Locate the SIM card slot. The Huawei E5576-320 uses a standard 6-pin SIM card.
3. Insert your SIM card into the slot with the gold contacts facing down and the notched corner aligned correctly. Push until it clicks into place.
4. Ensure the SIM card is securely seated.

## 3.2. Inserting the Battery

1. After inserting the SIM card, place the 1500mAh Lithium Polymer battery into its compartment, aligning the gold contacts on the battery with the pins in the device.
2. Gently press down on the battery until it is securely in place.
3. Replace the back cover, ensuring it snaps firmly into position.

## 3.3. Charging the Device

1. Connect the smaller end of the provided USB charging cable to the micro-USB port on the side of the Huawei E5576-320.
2. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.

3. The battery indicator light will illuminate to show that the device is charging. A solid green light typically indicates a full charge.

# 4. Operating Instructions

## 4.1. Powering On/Off

- **To Power On:** Press and hold the power button (located on the side) for approximately 3 seconds until the indicator lights illuminate.
- **To Power Off:** Press and hold the power button for approximately 3 seconds until the indicator lights turn off.

## 4.2. Connecting Devices to Wi-Fi

1. Ensure your Huawei E5576-320 is powered on and has an active SIM card with a data plan.
2. On your Wi-Fi enabled device (smartphone, laptop, tablet), search for available Wi-Fi networks.
3. Select the network name (SSID) corresponding to your Huawei hotspot. The default SSID and Wi-Fi key are usually found on a sticker inside the battery compartment or on the device packaging.
4. Enter the Wi-Fi key when prompted.
5. Once connected, your device will have internet access through the hotspot.

## 4.3. Indicator Lights

The Huawei E5576-320 features several indicator lights to provide status information:

- **Signal Indicator:** Displays the strength of the 4G/3G network signal.
  - **Green:** Strong signal.
  - **Orange:** Medium signal.
  - **Red:** Weak or no signal.
- **Battery Indicator:** Shows the battery level.
  - **Green:** Sufficient battery.
  - **Orange:** Low battery.
  - **Red:** Very low battery, needs charging.
- **Wi-Fi Indicator:** Indicates the Wi-Fi status.
  - **Green:** Wi-Fi is active and devices are connected.
  - **Off:** Wi-Fi is off or no devices are connected.

# 5. Maintenance

## 5.1. Battery Care

- To prolong battery life, avoid exposing the device to extreme temperatures.
- Charge the battery regularly, but avoid overcharging or completely draining it frequently.
- If the device will not be used for an extended period, charge the battery to about 50% before storing it.

### 5.2. Cleaning

- Use a soft, dry cloth to clean the exterior of the device.
- Do not use liquid cleaners or aerosols.
- Keep the charging port free of dust and debris.

## 6. Troubleshooting

| Problem | Possible Solution |
|---|---|
| Device does not power on. | Ensure the battery is correctly inserted and charged. Connect to a power source and try again. |
| No network signal. | Check if the SIM card is properly inserted. Move to an area with better network coverage. Contact your service provider to ensure your SIM card is active and has a data plan. |
| Cannot connect to Wi-Fi. | Verify the Wi-Fi SSID and password. Ensure the device's Wi-Fi is enabled. Restart both the hotspot and the connecting device. |
| Slow internet speed. | Check signal strength. Reduce the number of connected devices. Move closer to the hotspot. Contact your service provider for network performance issues. |
| Device heats up during use. | It is normal for the device to warm up during extended use or charging. If it becomes excessively hot, disconnect it from power and stop using it. |

## 7. Specifications

| Feature | Detail |
|---|---|
| Model Name | E5576-320 |
| Dimensions | 3.94 x 0.28 x 2.28 inches |
| Item Weight | 3.53 ounces |
| Battery | 1500mAh Lithium Polymer (replaceable) |
| Working Time | Up to 6 hours |
| 4G Bands (Europe, Asia, Middle East, Africa) | LTE FDD B1/B3/B7/B8/B20/B28/B38 (2100/1800/2600/900/800Mhz/B700/B2600) MHz |
| 3G Bands | UMTS B1/B8 (2100/900Mhz) MHz |
| LTE Speed | Cat4 150 Mbps download; 50 Mbps upload |
| Wi-Fi Standard | 802.11a/b/g/n; WEP/WPA/WPA2 |
| Max Connected Devices | 16 |

| Feature | Detail |
| --- | --- |
| SIM Card Type | Standard 6-pin SIM |
| Manufacturer | HUAWEI Tech |

## 8. Warranty and Support

Your Huawei E5576-320 Mobile WiFi Hotspot comes with a standard manufacturer's warranty. Please refer to the included Warranty Card for detailed terms and conditions, including warranty period and coverage.
For technical support, product registration, or further assistance, please visit the official HUAWEI consumer website or contact their customer service. Keep your purchase receipt and product serial number handy for any warranty claims.
*Note: This device is NOT compatible with USA, Canada, and Mexico providers. It is intended for use in Europe, Asia, the Middle East, and Africa.*


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question