

Ambimall ABM-1868

Ambimall Modern Floor Lamp Instruction Manual

Model: ABM-1868

Brand: Ambimall

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Ambimall Modern Floor Lamp. Designed with a simple yet elegant aesthetic, this 60-inch tall floor lamp is suitable for various indoor settings, including living rooms, bedrooms, offices, dining rooms, and kitchens. Its minimalist design and functional features aim to enhance your home's lighting and ambiance.

PRODUCT FEATURES

- **Versatile Design:** Features a black pole and a white linen shade, complementing various decor styles from industrial to modern.
- **Optimal Height:** Stands 60 inches tall, providing ample illumination for different room sizes.
- **E26 Base Compatibility:** Designed for E26 base bulbs (bulb not included). LED bulbs are recommended for energy efficiency and longevity.
- **Convenient Foot Pedal Switch:** Easily turn the lamp on and off with a simple press of the foot pedal.
- **Stable and Lightweight:** Equipped with a weighted base for stability, yet lightweight (5.7 pounds) for easy repositioning.



Figure 1: Overview of the Ambimall Modern Floor Lamp.



Figure 2: The floor lamp seamlessly integrates into different home environments, providing soft, ambient lighting.

SETUP AND ASSEMBLY

Assembly of your Ambimall Floor Lamp is straightforward and requires no additional tools. Please follow these steps:

1. Unpack all components from the box. Verify that all parts are present: lamp base, pole sections, lamp shade, and foot pedal switch.
2. Carefully twist the pole sections together, ensuring they are securely connected.
3. Screw the assembled pole into the lamp base until it is firm and stable.
4. Assemble the lamp shade. The shade material typically wraps around a metal frame. Secure the edges as instructed in the packaging.
5. Attach the assembled lamp shade to the top of the lamp pole.
6. Insert an E26 base bulb (not included) into the lamp socket.
7. Plug the power cord into a standard 120V electrical outlet.



Figure 3: Product dimensions for placement consideration.



Figure 4: The lamp is compatible with various E26 base bulbs. Bulb is not included.

Your browser does not support the video tag.

Video 1: An overview of the Ambimall Simple Floor Lamp, demonstrating its features and ease of assembly. This video is provided by the seller.

OPERATING INSTRUCTIONS

To operate your Ambimall Floor Lamp, simply use the integrated foot pedal switch located on the power cord. Press the switch once to turn the lamp ON, and press it again to turn the lamp OFF.

For optimal ambiance, it is recommended to use a 2700K warm white LED light bulb. This lamp is also compatible with smart bulbs, allowing for advanced control over brightness and color settings via compatible smart home systems (smart bulb not included).






Figure 5: The convenient foot pedal switch for easy operation.



Figure 6: Example of various light temperatures achievable with compatible bulbs (bulb not included).

MAINTENANCE

To maintain the appearance and functionality of your lamp:

- **Cleaning:** Ensure the lamp is unplugged before cleaning. Wipe the metal pole and base with a soft, dry cloth. For the linen shade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Always unplug the lamp before replacing the bulb. Allow the old bulb to cool completely. Screw in a new E26 base bulb. Do not exceed the recommended wattage for the bulb (refer to bulb packaging for specific wattage,

typically up to 60W for incandescent equivalent LED).

TROUBLESHOOTING

If your Ambimall Floor Lamp is not functioning as expected, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	1. Power cord not fully plugged in. 2. Bulb is loose or burnt out. 3. Wall outlet is not functioning. 4. Foot pedal switch is faulty.	1. Ensure the power cord is securely plugged into a live outlet. 2. Tighten the bulb or replace it with a new E26 bulb. 3. Test the outlet with another device. 4. Contact customer support if the switch is unresponsive after checking other causes.
Lamp flickers.	1. Loose bulb connection. 2. Incompatible bulb type.	1. Tighten the bulb. 2. Ensure you are using a compatible E26 base bulb.

If the problem persists after attempting these solutions, please contact Ambimall Customer Support.

SPECIFICATIONS

Attribute	Detail
Model Number	ABM-1868
Brand	Ambimall
Product Dimensions	10.24"D x 7.87"W x 60"H
Item Weight	5.7 Pounds
Finish Type	Iron
Base Material	Metal
Shade Material	Linen
Shade Color	White
Bulb Base	E26 Medium
Light Source Type	LED (Recommended)
Recommended Color Temperature	2700 Kelvin (Warm White)
Switch Type	Foot Pedal (Push Button)
Power Source	Corded Electric
Voltage	120 Volts
Assembly Required	Yes
Included Components	Shade

Attribute	Detail
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Ambimall Modern Floor Lamp, please contact Ambimall Customer Service directly. Keep your purchase receipt and model number (ABM-1868) handy for faster service.

For further assistance, you may visit the [Ambimall Store on Amazon](#).

© 2025 Ambimall. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question