

[Manuals.plus](#) /

› [ROMP](#) /

› ROMP Jazz Rabbit Vibrator Instruction Manual

ROMP Jazz

ROMP Jazz Rabbit Vibrator Instruction Manual

1. INTRODUCTION

The ROMP Jazz is a dual-stimulation rabbit vibrator designed for G-spot and clitoral stimulation. It features multiple vibration modes, a flexible form, and is crafted from body-safe silicone. This manual provides essential information for the safe and effective use, maintenance, and care of your device.

2. SAFETY INFORMATION

- Read all instructions thoroughly before first use and retain for future reference.
- This product is intended for external use only.
- Do not use the device if it appears damaged, cracked, or shows any signs of overheating during operation or charging. Discontinue use immediately.
- Consult a healthcare professional if you have any medical conditions or concerns regarding the use of this product.
- Keep the device out of reach of children.
- Use only with water-based lubricants. Oil-based lubricants can damage the silicone material.
- Avoid prolonged exposure to direct sunlight or extreme temperatures.

3. PRODUCT OVERVIEW

The ROMP Jazz is engineered for a comprehensive experience, combining innovative design with user-friendly features.



Image: The ROMP Jazz Rabbit Vibrator, showcasing its dual-stimulation design and vibrant color.

Key Features:

- **Dual Stimulation:** Designed to provide both G-spot and clitoral stimulation.
- **6 Vibration Modes:** Offers a variety of intensities, from gentle to powerful.
- **4 Pattern Modes:** Includes diverse vibration patterns for varied sensations.
- **Flexible Form:** The device features a flexible head for adaptable use.
- **100% Waterproof:** Suitable for use in the bath or shower and easy cleaning.
- **Body-Safe Silicone:** Made from ultra-soft, smooth, and safe silicone material.
- **Soft Tip:** Ensures comfortable contact.
- **Two-Button Control:** Simple and intuitive operation.
- **Rechargeable:** Convenient USB charging.
- **Runtime:** Approximately 60 minutes on a full charge.

The image is a full-page advertisement for the ROMP Jazz vibrator. It features a close-up of a person's face, which is partially obscured by a large, bright pink vibrator. The vibrator has a curved, flexible head and a textured, ribbed body. A dashed yellow line with arrows at both ends curves over the top of the vibrator's head, indicating its flexibility. In the top left corner, there is a yellow triangle containing the text 'ROMP' in bold black letters. The background is a soft, out-of-focus pink and purple gradient. The overall aesthetic is modern and sensual.

ROMP

Flexible Head

ROMP Jazz features a flexible head and is perfect for relieving any tension

Image: Visual representation of ROMP Jazz features, including 6 vibration modes and waterproof design.

4. SETUP

Charging the Device:

1. Before initial use, fully charge your ROMP Jazz vibrator.
2. Locate the charging port, typically at the base of the device.
3. Insert the provided USB charging cable into the port.
4. Connect the other end of the USB cable to a compatible USB power source (e.g., computer, wall adapter).
5. The indicator light on the device will illuminate or flash to show that it is charging. Once fully charged, the light will typically change color or turn off.
6. A full charge provides approximately 60 minutes of use.



Image: Close-up of the ROMP Jazz charging port with the cable inserted.

5. OPERATING INSTRUCTIONS

Basic Operation:

1. **Power On/Off:** Press and hold the power button (usually marked with a circle and vertical line) for 2-3 seconds to turn the device on or off.
2. **Change Vibration Modes:** Once powered on, press the mode button (often marked with waves or a pattern icon) to cycle through the 6 distinct vibration modes.
3. **Change Pattern Modes:** The ROMP Jazz also features 4 unique pattern modes. Continue pressing the mode button to explore these patterns.
4. **Adjust Intensity:** Use the '+' and '-' buttons (if present, or repeated presses of the mode button may increase intensity within a mode) to adjust the vibration intensity to your preference.



Image: Detail of the ROMP Jazz control buttons for power and mode selection.

Usage Tips:

- Apply a generous amount of water-based lubricant to the device and the desired area before use.
- Experiment with different vibration modes and patterns to discover what feels best.
- The flexible head allows for comfortable positioning and targeting of specific areas.

6. MAINTENANCE

Cleaning:

1. Clean your ROMP Jazz vibrator thoroughly before and after each use.
2. Since the device is 100% waterproof, you can rinse it under warm running water.
3. Use a mild, antibacterial soap or a specialized toy cleaner. Gently lather and rinse completely.
4. Pat the device dry with a lint-free cloth or allow it to air dry completely before storage.



Image: The ROMP Jazz vibrator being rinsed under water, demonstrating its waterproof feature.

Storage:

- Store your clean and dry ROMP Jazz in a cool, dry place.
- Keep it away from direct sunlight, extreme temperatures, and other toys made of different materials to prevent potential damage or reactions.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on or vibrate.	Low battery or device malfunction.	Ensure the device is fully charged. If the issue persists after charging, contact customer support.
Device is getting hot during use or charging.	Potential internal malfunction.	Discontinue use immediately. Unplug from charger if applicable. Contact customer support.
Vibrations are weak or inconsistent.	Low battery or motor issue.	Recharge the device fully. If the problem continues, contact customer support.

8. SPECIFICATIONS

Model: Jazz

Material: Body-safe Silicone

Dimensions: 1.42 x 2.8 x 8.27 inches

Weight: 3.53 ounces

Waterproof: Yes (100%)

Vibration Modes: 6

Pattern Modes: 4

Runtime: Up to 60 minutes

Manufacturer: WOW Tech

9. WARRANTY AND SUPPORT

ROMP products are manufactured by WOW Tech. The ROMP Jazz Rabbit Vibrator typically comes with a 2-year warranty from the manufacturer, covering defects in materials and workmanship.

For warranty claims, technical support, or any product-related inquiries, please contact WOW Tech USA customer service. Please note that warranty coverage may be affected if the product was purchased from an unauthorized reseller. For further assistance, visit the official ROMP website or contact WOW Tech USA directly.

10. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: Official product video demonstrating the features and use of the ROMP Jazz Rabbit Vibrator.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07Z6KF6TX>

More documents and user manuals: <https://manuals.plus/>