

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [WEWE](#) /
- › [WEWE Vintage Kitchen Faucet Model A1008-04-06MB Instruction Manual](#)

WEWE A1008-04-06MB

WEWE Vintage Kitchen Faucet Model A1008-04-06MB Instruction Manual

Comprehensive guide for installation, operation, and maintenance.

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your WEWE Vintage Kitchen Faucet, Model A1008-04-06MB. Please read this guide thoroughly before beginning installation or use to ensure proper function and longevity of your product.



Image 1.1: The WEWE Vintage Kitchen Faucet, Model A1008-04-06MB, in matte black finish.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.

- Keep small parts away from children.

3. PACKAGE CONTENTS

Verify that all components are present before starting installation:

- WEWE Kitchen Faucet (Main Unit)
- Mounting Accessories
- User Manual (This document)
- Weight (for pull-down hose)
- Deck Plate (for 3-hole installation)

4. SPECIFICATIONS

Brand	WEWE
Model Name	A1008-04-06MB
Color	08 Matte Black
Material	Metal (SUS304 Stainless Steel body)
Mounting Type	Deck Mount (Single Hole or 3 Hole)
Number of Handles	1
Maximum Flow Rate	1.8 Gallons Per Minute (gpm) @ 80 psi
Spout Height	8.8 Inches
Spout Reach	8.8 Inches
Hose Length	70 Inches (Pull-down hose)
Supply Hose Size	3/8" (Hot: 31.5", Cold: 33.5")
Product Dimensions	8.8"D x 10"W x 15.7"H



Image 4.1: Faucet dimensions and compatibility for 1-hole or 3-hole sink installations.

5. SETUP AND INSTALLATION

The WEWE Vintage Kitchen Faucet is designed for straightforward installation, suitable for both 1-hole and 3-hole kitchen sinks. No specialized tools are typically required.

5.1 Before You Begin

1. Turn off the water supply to your sink.
2. Clear the area under your sink for easy access.
3. Ensure you have all package contents as listed in Section 3.
4. For 3-hole sinks, use the included deck plate. For 1-hole sinks, the deck plate is optional.

5.2 Installation Steps

1. **Prepare the Sink Hole:** Ensure the sink hole diameter is between 1.38" and 1.5". If installing on a 3-hole sink, place the deck plate over the holes.
2. **Mount the Faucet:** Insert the faucet body through the hole(s) in the sink/deck plate. From underneath, secure it with the provided mounting hardware (washer and nut). Hand-tighten first, then

use a wrench for final tightening.

3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines (3/8" connections) to your existing water valves. The hot water line is 31.5" long, and the cold water line is 33.5" long. *Note: If your existing connections are not 3/8", 1/2" male adapters (ASIN: B09D2TW9D1) or 1/2" female adapters (ASIN: B08VRPYWLM) may be required and are available separately.*
4. **Install the Weight:** Attach the counterweight to the pull-down hose approximately 6-8 inches from the bottom of the faucet body. This ensures smooth retraction of the sprayer.
5. **Test for Leaks:** Slowly turn on the main water supply. Check all connections for leaks. Run the faucet for a few minutes to flush out any debris and check for proper hot and cold water flow.



Image 5.1: Simplified installation process for the WEWE faucet.



SMOOTH DOCKING TECHNOLOGY

The pull-down nozzle with a flexible hose can be docked smoothly by a counterweight.

Image 5.2: The pull-down design allows for extended reach and flexibility.

6. OPERATING INSTRUCTIONS

Your WEWE kitchen faucet features a single handle for water control and a multi-function pull-down sprayer.

6.1 Water Flow and Temperature Control

- **Turn On/Off:** Lift the single handle to turn on the water. Push down to turn off.
- **Adjust Temperature:** Move the handle left for hot water and right for cold water. The handle is designed to provide cold water first when pulled forward, which can help prevent accidental scalding.

- **Adjust Flow:** The further you lift the handle, the greater the water flow.



Image 6.1: The single handle allows for precise control of water temperature and flow.

6.2 Pull-Down Sprayer Functions

The pull-down sprayer offers three distinct spray modes for various tasks:

- **Stream Mode:** Ideal for filling pots and general water delivery.
- **Spray Mode:** Provides a wider spray for rinsing dishes and general cleaning.
- **Sweep Mode:** A powerful blade of water designed for heavy-duty rinsing and removing stubborn food debris.

To switch between modes, press the corresponding button on the sprayer head. The sprayer also features a 360-degree swivel for enhanced maneuverability around the sink.



3-FUNCTIONAL SPRAY NOZZLES

Three spray patterns for everything from rinsing vegetables to washing dishes.

Image 6.2: The sprayer head with three functional spray nozzles.

SWIVEL KITCHEN FAUCET



Image 6.3: The 360-degree swivel feature provides flexible use.

7. MAINTENANCE

Regular cleaning and maintenance will help preserve the finish and functionality of your WEWE kitchen faucet.

7.1 Cleaning the Faucet

- Use a soft cloth and mild soap to clean the exterior of the faucet. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the matte black finish.
- The "SPOT RESIST" finish helps prevent fingerprints and water spots, making cleaning easier.

7.2 Cleaning the Nozzle

- The sprayer head features "EASY CLEAN NOZZLE" soft rubber spray holes. To remove mineral buildup, gently rub the rubber nozzles with your finger or a soft brush.
- This helps maintain consistent water flow and prevents splashing.



Image 7.1: Easy-clean nozzle design for simple maintenance.

8. TROUBLESHOOTING

If you encounter issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Flow	<ul style="list-style-type: none"> ◦ Partially closed water supply valves. ◦ Clogged aerator/nozzle. ◦ Kinked supply lines. 	<ul style="list-style-type: none"> ◦ Ensure hot and cold water supply valves are fully open. ◦ Clean the sprayer nozzle (refer to Section 7.2). ◦ Check supply lines under the sink for kinks or obstructions.
Leaks at Connections	<ul style="list-style-type: none"> ◦ Loose connections. ◦ Damaged O-rings or washers. 	<ul style="list-style-type: none"> ◦ Carefully tighten all connections. Do not overtighten. ◦ Inspect O-rings and washers for damage and replace if necessary.
Sprayer Does Not Retract Fully	<ul style="list-style-type: none"> ◦ Counterweight improperly positioned or obstructed. 	<ul style="list-style-type: none"> ◦ Check the position of the counterweight on the pull-down hose. Ensure it is not obstructed by pipes or other items under the sink.

9. WARRANTY AND SUPPORT

Your WEWE Vintage Kitchen Faucet is backed by a limited warranty. For specific details regarding warranty coverage, please refer to the warranty card included with your product or contact WEWE customer support.

Customer Support

For technical assistance, replacement parts, or any questions not covered in this manual, please contact WEWE customer support through their official website or the retailer where the product was purchased.

Manufacturer: Aonecer

