Mastrad Folding Kitchen Scale

Mastrad Folding Kitchen Scale User Manual

Model: Folding Kitchen Scale

1. Introduction

The Mastrad Folding Kitchen Scale is designed for accurate measurement of ingredients in various units. Its compact, foldable design and stainless steel construction make it a practical tool for any kitchen. This manual provides instructions for the proper setup, operation, and maintenance of your kitchen scale.

Key features include:

- Accurate weighing up to 11.03 lbs (5 kg).
- Measures in grams (g), kilograms (kg), pounds (lb), and ounces (oz).
- Backlit digital display for clear readability.
- Foldable stainless steel arms for compact storage.
- Integrated hook design for hanging storage.
- Four non-slip feet for stability during use.

2. Package Contents

Verify that all items are present in the package:

- Mastrad Folding Kitchen Scale
- User Manual (this document)
- Batteries (typically included and pre-installed or separate)



Image: The retail packaging for the Mastrad Folding Kitchen Scale, showing the product name and key features.

3. Setup

3.1. Unpacking

1. Carefully remove the kitchen scale and all accessories from the packaging.
2. Retain the packaging for future storage or transport.

3.2. Battery Installation

The scale typically comes with batteries included. If batteries are not pre-installed or need replacement:

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the required batteries (e.g., AAA or CR2032, refer to compartment label) ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

3.3. Initial Placement

Place the scale on a flat, stable, and level surface to ensure accurate readings. Avoid placing it on soft or uneven surfaces.

4. Operating Instructions

4.1. Unfolding the Scale

To prepare the scale for use, gently unfold the stainless steel arms until they are fully extended and locked into position. The scale is designed to provide a stable platform for weighing when unfolded.



Image: The Mastrad Folding Kitchen Scale shown in its fully unfolded position, ready for use.

4.2. Power On/Off

- To turn on: Press the **ON/OFF** button. The display will illuminate and show "0" or "0.0" when ready.

- To turn off: Press and hold the **ON/OFF** button for a few seconds, or the scale will automatically shut off after a period of inactivity to conserve battery life.

4.3. Unit Selection

To change the unit of measurement (g, kg, lb, oz):

1. With the scale on, press the **UNIT** button (or similar button, typically labeled "MODE" or "UNIT").
2. The display will cycle through the available units. Stop when your desired unit is shown.

4.4. Tare Function (Zeroing)

The Tare function allows you to weigh multiple ingredients in the same container or to subtract the weight of a container:

1. Place an empty container on the scale. The display will show its weight.
2. Press the **TARE** button (or the **ON/OFF** button if it doubles as Tare). The display will reset to "0".
3. Add your ingredient to the container. The display will show only the weight of the ingredient.
4. Repeat the Tare process for additional ingredients.

4.5. Weighing Ingredients

1. Ensure the scale is on and displaying "0" in your desired unit.
2. Place the item(s) to be weighed directly onto the scale's platform or into a container placed on the scale (using the Tare function if needed).
3. Read the weight displayed on the backlit screen.
4. Avoid overloading the scale beyond its maximum capacity of 11.03 lbs (5 kg).

5. Maintenance

5.1. Cleaning

- Wipe the scale with a soft, damp cloth.
- Do not immerse the scale in water or use abrasive cleaners.
- Ensure the scale is completely dry before storing.

5.2. Storage

To store the scale:

1. Ensure the scale is clean and dry.
2. Fold the stainless steel arms inward until the scale is in its compact form.
3. You can store it in a drawer or hang it using the integrated hook design.



Image: The Mastrad Folding Kitchen Scale shown in its folded, compact position, ideal for storage.

5.3. Battery Replacement

When the display shows a "Lo" indicator, it is time to replace the batteries. Follow the battery installation steps in Section 3.2.

6. Troubleshooting

Problem	Possible Cause	Solution
Scale does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity or replace batteries.
"Lo" displayed.	Low battery power.	Replace batteries.

Problem	Possible Cause	Solution
"Err" or "O-Ld" displayed.	Scale overloaded.	Remove item(s) immediately. Do not exceed 11.03 lbs (5 kg).
Inaccurate readings.	Uneven surface, scale not zeroed, or external interference.	Place on a flat, stable surface. Ensure scale is zeroed before weighing. Avoid drafts or vibrations.

7. Specifications

Feature	Detail
Brand	Mastrad
Model	Folding Kitchen Scale
Material	Stainless Steel
Color	Silver
Weight Limit	11.03 Pounds (approx. 5 kg)
Readout Accuracy	0.01 pounds
Display Type	LED, Digital, Backlit
Units of Measurement	Grams (g), Kilograms (kg), Pounds (lb), Ounces (oz)
Form Factor	Foldable
Item Weight	9.1 ounces
Package Dimensions	11.54 x 2.72 x 1.3 inches
ASIN	B07Z87G43W
UPC	885902767509

8. Warranty and Support

Warranty information for your Mastrad Folding Kitchen Scale is typically provided within the product packaging or can be found on the official Mastrad website. Please refer to these resources for details regarding warranty coverage and terms.

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact Mastrad customer service through their official website or the contact information provided in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question