

LG G8 ThinQ

LG G8 ThinQ Smartphone User Manual

Model: G8 ThinQ | Brand: LG

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your LG G8 ThinQ smartphone. Please read this manual thoroughly before operating your device to ensure optimal performance and longevity. The LG G8 ThinQ features a 6.1" QHD+ FullVision OLED Display, 128GB internal storage, 6GB RAM, and a 3500mAh battery. This specific device is locked to Verizon.



Image 1: Front and back view of the LG G8 ThinQ smartphone.

2. SAFETY INFORMATION

- **Battery Safety:** Do not disassemble, crush, or puncture the battery. Avoid exposing the battery to high temperatures or fire. Dispose of batteries according to local regulations.
- **Water Resistance:** While the device may offer some water resistance, avoid intentional submersion or exposure to high-pressure water.
- **Charging:** Use only LG-approved chargers and cables. Unplug the charger when not in use or during electrical storms.
- **Hearing Protection:** Avoid listening to audio at high volume levels for extended periods to prevent hearing damage.
- **Driving Safety:** Do not use your phone while driving. Always prioritize safe driving practices.

3. GETTING STARTED

3.1. What's in the Box

Your LG G8 ThinQ package should contain the following items:

- LG G8 ThinQ Smartphone

- Adapter
- USB Cable

3.2. Initial Setup

1. **Charge the Device:** Before first use, fully charge your LG G8 ThinQ using the provided adapter and USB cable.
2. **Power On:** Press and hold the Power button (usually on the right side) until the LG logo appears.
3. **Follow On-Screen Prompts:** The device will guide you through initial setup, including language selection, Wi-Fi connection, Google account setup, and security settings.
4. **Verizon Activation:** As this is a Verizon-locked device, ensure you have an active Verizon SIM card and follow any specific activation steps provided by Verizon.

4. OPERATING YOUR DEVICE

4.1. Basic Navigation

The LG G8 ThinQ utilizes a touchscreen interface for most operations. Swipe, tap, and pinch gestures are used to navigate menus, open apps, and interact with content. Physical buttons control power, volume, and may include a dedicated Google Assistant button.

4.2. Display Features

Your device features a vibrant 6.1" QHD+ FullVision OLED Display, offering rich colors and deep blacks. Adjust brightness and display settings in the phone's settings menu for optimal viewing.

4.3. Camera Usage

The LG G8 ThinQ is equipped with a 16MP main camera and an 8MP front camera. Open the Camera app to capture photos and videos. Various modes and settings are available to enhance your photography experience.





Image 2: The LG G8 ThinQ display and rear camera setup.

4.4. Dual Screen Functionality (with optional accessory)

The LG G8 ThinQ supports an optional Dual Screen accessory (sold separately) that allows for enhanced multitasking and viewing experiences. When attached, the accessory provides a second screen, effectively doubling your display area. This is particularly useful for running two applications simultaneously or extending content across both screens.

Your browser does not support the video tag.

Video 1: Demonstration of the LG G8 ThinQ with its optional Dual Screen accessory, showcasing its multitasking capabilities.

Your browser does not support the video tag.

Video 2: Overview of case options for smartphones, including the LG G8 ThinQ's Dual Screen case, highlighting durability and functionality.

5. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the device. Avoid harsh chemicals or abrasive materials.

- **Software Updates:** Regularly check for and install software updates to ensure your device has the latest features and security patches. Navigate to Settings > System > Update center > Software update.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for daily use.

6. TROUBLESHOOTING

- **Device Not Powering On:** Ensure the battery is charged. If the issue persists, try a forced restart by holding the Power and Volume Down buttons simultaneously for about 10 seconds.
- **Screen Unresponsive:** If the screen is frozen, perform a forced restart.
- **Battery Draining Quickly:** Check background app usage, reduce screen brightness, and disable unnecessary features like GPS or Bluetooth when not in use.
- **Network Connectivity Issues:** Verify your SIM card is properly inserted and that mobile data is enabled. Try toggling Airplane Mode on and off.
- **Factory Reset:** As a last resort, if software issues persist, you may perform a factory reset. **Warning: This will erase all data on your device. Back up important data before proceeding.** Navigate to Settings > System > Restart & reset > Factory data reset.

7. SPECIFICATIONS

Feature	Detail
Model Name	G8 ThinQ
Display	6.1" QHD+ FullVision OLED Display (2560 x 1440 resolution, 60Hz refresh rate)
Processor	Snapdragon CPU (2.84 GHz)
RAM	6 GB
Internal Storage	128 GB
Rear Camera	16 MP
Front Camera	8 MP
Battery Capacity	3500 mAh Li-ion (non-removable)
Operating System	Android
Connectivity	Cellular, Infrared, GPS, Wireless
Dimensions	7.72 x 4.29 x 2.36 inches (Package)
Item Weight	5.9 ounces
Color	Black
Audio Jack	No headphone jack

8. WARRANTY AND SUPPORT

This LG G8 ThinQ is a renewed product. Amazon Renewed products are fully functional and come with generic or original accessories and packaging. It is backed by a 90-day return policy for refund or replacement.

For specific warranty details or technical support, please refer to the documentation provided with your renewed device or contact the seller directly. You may also visit the official LG support website for general product information.

