

[Manuals.plus](#) /

› [Osprey](#) /

› Osprey Poco Plus Child Carrier Backpack Instruction Manual

Osprey Poco Plus

Osprey Poco Plus Child Carrier Backpack Instruction Manual

Model: Poco Plus | Brand: Osprey

INTRODUCTION

The Osprey Poco Plus Child Carrier is designed to provide a safe, comfortable, and convenient way to carry your child during outdoor activities such as hiking, strolling, and everyday tasks. Its thoughtful design includes features for both child and adult comfort, ample storage, and sun protection, making it an ideal companion for family adventures.

WHAT'S IN THE BOX

- Osprey Poco Plus Child Carrier

KEY FEATURES

- **Double Halo Harness:** Features front-facing arm loops for easy child loading and buckling.
- **Adjustable Adult Harness & Fit-on-the-Fly Hipbelt:** Ensures a comfortable fit for various adult torso sizes.
- **Removable Drool Pad:** For hygiene and easy cleaning.
- **Toy Attachment Loops:** Keeps child's toys secure and accessible.
- **Zippered Lower Compartment:** Large enough for essentials like a diaper changing kit.
- **Extra Storage:** Additional pockets on the main body and hipbelts for convenience.
- **Built-in Sunshade:** Protects your child from harmful sun rays.
- **Integrated Mirror:** Allows you to check on your child without removing the pack.
- **Hydration Sleeve:** Dedicated compartment for a water bladder (bladder not included).

SETUP AND ADJUSTMENT

Proper adjustment of the Poco Plus carrier is crucial for both your comfort and your child's safety. Follow these steps to ensure a correct fit:

1. Adjusting the Adult Harness

The adult harness features a fully adjustable back panel to accommodate different torso lengths. Locate the adjustment mechanism on the back panel (often a hook-and-loop or ladder-lock system) and slide it up or down until the shoulder straps sit comfortably on your shoulders and the hipbelt aligns with your hips. Ensure the load lifter straps (above the shoulders) are at a 45-

degree angle.





Image: Rear view of the Osprey Poco Plus, highlighting the adjustable back panel and shoulder straps for adult fit.



Image: Detailed view of the adult harness adjustment system, allowing customization for various torso sizes.

2. Adjusting the Fit-on-the-Fly Hipbelt

The hipbelt can be extended or retracted to fit different waist sizes. Pull the hipbelt straps forward to tighten, ensuring the padded sections wrap around your hips for optimal load transfer. The hipbelt should bear most of the child's weight, not your shoulders.

3. Securing Your Child in the Harness

Place your child into the carrier. Fasten the double halo harness, ensuring the front-facing arm loops are used for easy access. Adjust all straps (shoulder, chest, and crotch) snugly but comfortably, leaving no slack. The child's head should be above the top of the carrier's frame.



Image: The child's seating area, showing the padded double halo harness for secure and comfortable placement.

4. Child Seat and Foot Stirrup Adjustment

The child's seat height is adjustable to ensure they are at a comfortable and safe level. Adjust the seat so your child's chin is above the front of the carrier. The foot stirrups are also adjustable; ensure they are positioned so your child's legs are comfortably supported and not dangling.







Image: Adjustable foot stirrups designed to support the child's legs and prevent discomfort during extended wear.

5. Deploying the Built-in Sunshade

The integrated sunshade is stored in a zippered pocket at the top of the carrier. Unzip the pocket, pull out the sunshade, and secure its clips into the designated slots on the carrier frame. This provides UPF 50+ sun protection for your child.



Image: The built-in sunshade fully extended, offering protection from the sun for the child.

OPERATING INSTRUCTIONS

1. Carrying the Child

Once your child is securely harnessed and all adjustments are made, carefully lift the carrier onto your back. Fasten the hipbelt first, then the shoulder straps, and finally the sternum strap. Adjust all straps to distribute the weight evenly and comfortably. The carrier's sturdy frame allows it to stand independently on a flat surface for easier loading and unloading.





Image: Front view of the Osprey Poco Plus, showcasing its compact design and integrated stand.



Image: Side view of the carrier, illustrating the robust frame and padded support.

2. Utilizing Storage Compartments

The Poco Plus offers various storage options. The large zippered lower compartment is ideal for bulkier items like diapers, wipes, and extra clothing. Smaller zippered pockets on the hipbelt are perfect for quick-access items like snacks, keys, or a phone. Mesh side pockets can hold water bottles or other small essentials.



Image: The various storage compartments of the Poco Plus, including the large lower zippered pocket and hipbelt pockets.

3. Hydration System Integration

A dedicated sleeve for a hydration bladder is located behind the back panel. Insert your hydration bladder into the sleeve and route the drinking tube through the designated port on the shoulder strap for easy access while on the move.

4. Using the Integrated Mirror

The small, detachable mirror is stored in one of the hipbelt pockets. Use it to quickly check on your child without needing to remove the carrier.

MAINTENANCE

Cleaning Instructions

The Osprey Poco Plus is designed for easy maintenance. For general cleaning, spot clean with mild soap and water. The removable drool pad can be machine washed. Always air dry the carrier completely before storage to prevent mildew.

SPECIFICATIONS

Brand	Osprey
Model	Poco Plus
Color	Blue Sky
Material	Nylon
Strap Type	Adjustable Strap
Product Care	Machine Wash (removable drool pad), Spot Clean (carrier)
Age Range	Kid
Item Weight	3.58 Kilograms
Minimum Weight Recommendation	16 Pounds
Maximum Weight Recommendation	48.5 Pounds
Item Dimensions (D x W x H)	16"D x 29"W x 9"H
Closure Type	Zipper

VIDEO GUIDE: OSPREY POCO PLUS OVERVIEW

Video: A detailed overview of the Osprey Poco Plus Child Carrier, demonstrating its features, adjustments, and storage options. This video provides visual instructions for setup and use.

WARRANTY AND SUPPORT

The Osprey Poco Plus Child Carrier is covered by the **Osprey All Mighty Guarantee**. This warranty covers defects in materials and workmanship for the lifetime of the product. For warranty claims or support, please visit the official Osprey website or contact their customer service.

Note: The All Mighty Guarantee excludes Poco Child Carrier and Accessories, Raptor Pro and Soelden/Sopris Pro, which carry a limited five- or seven-year AMG depending on their practical lifespan. Please refer to Osprey's official warranty policy for full details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question