

Ahuja BTA 660

AHUJA BTA 660 Portable Wireless Bluetooth Speaker

User Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your AHUJA BTA 660 Portable Wireless Bluetooth Speaker. Please read these instructions thoroughly before using the product and retain them for future reference. The BTA 660 is a versatile portable PA system designed for various applications, featuring Bluetooth connectivity, USB playback and recording, wireless microphones, and a rechargeable battery.

2. KEY FEATURES

- **Portable Design:** Equipped with a trolley handle for easy transport.
- **Rechargeable Battery:** Integrated 7Ah rechargeable battery for cordless operation, offering approximately 4 hours of average battery life.
- **Wireless Connectivity:** Bluetooth for streaming audio from compatible devices.
- **Dual Microphone Inputs:** Two microphone inputs, including two wireless microphones.
- **Switchable Microphone Priority:** Prioritizes Mic-1 input over other audio sources.
- **Digital Echo:** Built-in digital echo effect for microphone inputs.
- **MP3 Player & Recorder:** USB port for MP3 playback and direct recording.
- **Auxiliary Input:** For connecting external audio sources via a 3.5mm or RCA cable.
- **Remote Control:** For convenient operation.

3. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following:

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not open the casing. Refer all servicing to qualified service personnel.
- Ensure proper ventilation. Do not block ventilation openings.
- Use only the power adapter supplied with the unit.

- Protect the power cord from being walked on or pinched.
- Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Clean only with a dry cloth.
- Disconnect the unit during lightning storms or when unused for long periods.

4. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- AHUJA BTA 660 Portable Wireless Bluetooth Speaker
- 2 Wireless Microphones
- Remote Control
- Power Adapter/Charging Cable
- User Manual (this document)

5. CONTROLS AND CONNECTIONS

Familiarize yourself with the various controls and connection ports on your BTA 660 speaker.



Image: Front view of the AHUJA BTA 660 speaker, highlighting its portable design with a trolley handle. The main speaker grille is visible, along with a side panel that typically houses control knobs and input ports.

While the image above provides a general view, specific controls and connections are typically located on the rear or side

panel. These include:

- **Power Switch:** To turn the unit ON/OFF.
- **Volume Controls:** Master volume, microphone volume, echo level.
- **Microphone Inputs:** 2 x 1/4" jack inputs for wired microphones.
- **AUX Input:** RCA or 3.5mm jack for external audio devices.
- **USB Port:** For USB drive playback and recording.
- **Mode Button:** To switch between Bluetooth, USB, and AUX modes.
- **Charging Port:** For connecting the power adapter.
- **LED Indicators:** For power, charging status, and Bluetooth pairing.

6. SETUP

6.1 Initial Charging

Before first use, fully charge the speaker's internal battery. Connect the supplied power adapter to the charging port on the speaker and plug it into a suitable power outlet (240 Volts AC). The charging indicator LED will illuminate. A full charge takes approximately 8 hours.

6.2 Powering On/Off

Locate the power switch on the unit. Flip it to the "ON" position to power on the speaker. Flip it to "OFF" to power off the speaker.

7. OPERATING INSTRUCTIONS

7.1 Bluetooth Connectivity

1. Turn on the BTA 660 speaker.
2. Press the "Mode" button until "Bluetooth" mode is selected. The Bluetooth indicator LED will flash, indicating it's in pairing mode.
3. On your smartphone, tablet, or laptop, enable Bluetooth and search for available devices.
4. Select "AHUJA BTA 660" from the list of devices.
5. Once paired, the Bluetooth indicator LED will stop flashing and remain solid. You can now stream audio wirelessly. The Bluetooth range is approximately 10 meters.

7.2 USB Playback and Recording

1. Insert a USB flash drive (formatted to FAT32) containing MP3 audio files into the USB port.
2. Press the "Mode" button to select "USB" mode. The speaker will automatically begin playing MP3 files.
3. Use the playback controls (Play/Pause, Next/Previous Track) on the speaker or remote control.
4. **To Record:** In USB mode, press the "Record" button. All audio inputs (microphones, AUX, Bluetooth) will be recorded onto the USB drive. Press "Record" again to stop.

7.3 Microphone Usage (Wireless & Wired)

1. **Wireless Microphones:** Ensure the wireless microphones are powered on and have fresh batteries. They should automatically connect to the speaker. Adjust their individual volume controls on the speaker.
2. **Wired Microphones:** Connect wired microphones to the 1/4" MIC Input jacks. Adjust their volume using the dedicated MIC volume knob.
3. **Digital Echo:** Use the "Echo" knob to add a reverberation effect to the microphone audio.
4. **Mic Priority:** The BTA 660 features a switchable priority function for Mic-1. When activated, audio from Mic-1 will

automatically lower the volume of other audio sources (Bluetooth, USB, AUX) when spoken into.

7.4 AUX Input

Connect an external audio device (e.g., CD player, laptop) to the AUX input jacks using an appropriate audio cable. Press the "Mode" button to select "AUX" mode. Adjust the volume on both the speaker and the connected device.

7.5 Trolley Handle

Extend the integrated trolley handle for easy transportation of the speaker. Retract it when not in use.

8. MAINTENANCE

- **Cleaning:** Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, fully charge the speaker before storing it for extended periods. Recharge the battery every 3-6 months if not in regular use. Avoid completely draining the battery frequently.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery drained; Power switch off; Power adapter not connected.	Charge the battery; Turn on the power switch; Connect the power adapter.
No sound	Volume too low; Incorrect input mode; Device not connected properly.	Increase master volume and source volume; Select correct mode (Bluetooth, USB, AUX); Ensure cables are securely connected.
Bluetooth not pairing	Speaker not in pairing mode; Device too far; Previously paired device connected.	Ensure speaker is in Bluetooth pairing mode (flashing LED); Move device closer (within 10m); Disconnect from other devices or forget device on your phone.
Microphone not working	Microphone off; Batteries low (wireless); Volume low; Incorrect input.	Turn on microphone; Replace batteries; Increase microphone volume; Ensure wired mic is in correct input.
Poor sound quality	Source audio quality; Interference; Speaker placement.	Use high-quality audio files; Move away from other electronic devices; Adjust speaker position.

10. SPECIFICATIONS

Brand	Ahuja
Model Number	BTA 660
Speaker Maximum Output Power	40 Watts
Frequency Response	15000 Hz
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo

Mounting Type	Tabletop Mount
Product Features	Portable, Wireless
Maximum Range (Bluetooth)	10 metres
Control Method	Remote
Woofers Driver Diameter	10 Inches
Tweeter Driver Diameter	1 Inches
Battery Average Life	4 Hours
Power Source	Battery Powered
Number of Batteries	1 (12V battery included)
Input Voltage	240 Volts
Battery Charge Time	8 Hours
Battery Capacity	7 Amp Hours
Item Dimensions (D x W x H)	9D x 10W x 9H Centimeters
Item Weight	999 Kilograms (Note: This weight seems unusually high for a portable speaker. Please verify with product packaging.)

11. WARRANTY AND SUPPORT

The AHUJA BTA 660 Portable Wireless Bluetooth Speaker comes with a **12-month (1 year) manufacturer warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or service inquiries, please contact your authorized Ahuja dealer or visit the official Ahuja website for contact information. Please retain your purchase receipt as proof of purchase for warranty validation.