

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Mastela](#) /
- › [Mastela 3-in-1 Deluxe Multi-Functional Bassinet \(Model 08105\) User Manual](#)

Mastela 08105

Mastela 3-in-1 Deluxe Multi-Functional Bassinet (Model 08105) User Manual

Important: Please read these instructions carefully before assembly and use, and keep them for future reference.

PRODUCT OVERVIEW

The Mastela 3-in-1 Deluxe Multi-Functional Bassinet is designed to provide a safe and comfortable environment for your baby. It functions as a bassinet, infant seat, and can transition to a toddler seat, offering versatility as your child grows. This product features multiple recline positions, swing angles, soothing melodies, and Bluetooth connectivity for music playback. It also includes a canopy with an integrated mosquito net and a 5-point harness for enhanced safety.



An image of the Mastela 3-in-1 Deluxe Multi-Functional Bassinet in its upright position, showcasing its design with a canopy, soft padding, and a stable base.

SAFETY INFORMATION

To ensure the safety of your child, please adhere to the following guidelines:

- Always use the 5-point harness to secure your child in the bassinet.
- Never leave your child unattended in the bassinet.
- Do not use the bassinet if any parts are damaged, broken, or missing.
- Ensure the bassinet is placed on a flat, stable, and level surface.
- Keep the bassinet away from open flames, heaters, and other heat sources.
- This product is intended for infants who cannot sit up unassisted. Discontinue use when the child can sit up unassisted or weighs more than the maximum recommended weight (refer to specifications).
- Always supervise your child when using the swing or recline functions.
- This product is not intended for prolonged sleep.

PACKAGE CONTENTS

Carefully unpack all components and verify them against the list below:

- Bassinet Frame
- Seat Unit with 5-point Harness
- Canopy with Integrated Mosquito Net
- Head Support Cushion
- Remote Control
- Power Adapter (if applicable)
- Instruction Manual (this document)



An image showing the Mastela 3-in-1 Deluxe Multi-Functional Bassinet alongside its retail packaging, indicating the contents of the box.

SETUP AND ASSEMBLY

Follow these steps to assemble your bassinet:

1. Unfold the bassinet frame on a flat, stable surface. Ensure all locking mechanisms click securely into place.
2. Attach the seat unit to the frame. Align the connectors and push firmly until the seat is securely fastened.
3. Install the canopy by attaching it to the designated points on the seat unit.
4. Place the head support cushion inside the seat unit for added comfort.
5. Connect the power adapter (if included) to the bassinet's power port and then to a suitable electrical outlet.




Full recline position



15 melodies with volume control



Side-to-side movement in 5 ideal angles



A diagram illustrating key features of the Mastela 3-in-1 Deluxe Multi-Functional Bassinet, including the 5-point harness, canopy with mosquito net, 3 timer settings, volume control, full recline position, 5 swing angles, remote control, Bluetooth connectivity, and 15 melodies.

OPERATING INSTRUCTIONS

Power On/Off

Press the power button located on the base unit or the remote control to turn the bassinet on or off.

Swing Function

Use the swing speed buttons on the base or remote control to select one of the 5 available swing angles or speeds. Start with the lowest setting and adjust as needed for your baby's comfort.

Recline Positions

Adjust the seat recline by pressing the recline adjustment button (typically found on the side or back of the seat unit) and moving the seat to the desired full recline or more upright position. Ensure it locks into place.

Melodies and Volume Control

Select from the 15 built-in melodies using the music buttons on the base or remote. Adjust the volume using the dedicated volume control buttons.

Bluetooth Connectivity

To play music from your smartphone, activate Bluetooth on your device and search for available devices. Select "Mastela Bassinet" or a similar name to pair. Once connected, you can stream audio through the bassinet's speakers.

Timer Settings

Utilize the timer function to set the operating duration for specific time intervals (e.g., 15, 30, or 60 minutes). The bassinet will automatically stop after the selected time.

Remote Control

The included remote control allows convenient operation of all functions from a distance. Ensure batteries are correctly installed and replaced when necessary.



An image of the Mastela 3-in-1 Deluxe Multi-Functional Bassinet with its canopy extended and integrated mosquito net deployed, providing protection for the infant.

MAINTENANCE AND CARE

- **Cleaning Fabric Components:** The product care instructions specify "Hand Wash Only" for the material. Remove the fabric seat cover and head support. Hand wash gently with mild soap and cold water. Do not use bleach. Rinse thoroughly and air dry completely before reattaching.

- **Cleaning Frame:** Wipe the frame and plastic components with a damp cloth and a mild, non-abrasive soap. Dry thoroughly with a clean cloth.
- **Storage:** When not in use, store the bassinet in a clean, dry place away from direct sunlight and extreme temperatures. The bassinet folds easily for convenient carrying or storing.
- **Inspection:** Regularly inspect all parts for signs of wear, damage, or loose fasteners. Discontinue use immediately if any damage is found and contact customer support for replacement parts or advice.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bassinet does not power on.	No power connection or depleted batteries.	Ensure the power adapter is securely plugged into the bassinet and a working electrical outlet. If using batteries (for remote), check and replace them if necessary.
Swing function is not working.	Obstruction, incorrect setting, or motor issue.	Ensure no objects are blocking the swing mechanism. Verify a swing speed is selected. If the issue persists, contact support.
No sound from melodies or Bluetooth.	Volume too low, Bluetooth not connected, or audio source issue.	Increase the volume using the control buttons. Re-pair your Bluetooth device. Check the audio output on your connected device.
Bassinet feels unstable.	Improper assembly or uneven surface.	Recheck all assembly steps to ensure components are securely locked. Ensure the bassinet is placed on a flat, level, and stable surface.

SPECIFICATIONS

- **Brand:** Mastela
- **Model:** 08105
- **Type:** 3-in-1 Deluxe Multi-Functional Bassinet / Travel Bassinet
- **Item Weight:** 300 Grams (0.3 kg)
- **Package Dimensions:** 32.99 x 22.81 x 5.89 cm
- **Material Care:** Hand Wash Only (for fabric components)
- **Features:** 5 Swing Angles, Full Recline Position, 15 Melodies, Volume Control, 3 Timer Settings, Bluetooth Connectivity, Remote Control, Canopy with Integrated Mosquito Net, 5-Point Harness.
- **Manufacturer:** Other
- **ASIN:** B07ZC23CSW
- **Date First Available:** 25 June 2023

WARRANTY AND SUPPORT

For warranty information, technical support, or to inquire about replacement parts, please contact your retailer or the manufacturer directly. It is recommended to keep your proof of purchase for any warranty claims.

Manufacturer: Other

Brand: Mastela