

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Blaupunkt](#) /

› [Blaupunkt B-Stream TV Box User Manual](#)

Blaupunkt B-Stream TV Box

Blaupunkt B-Stream TV Box User Manual

Model: B-Stream TV Box

1. INTRODUCTION

Welcome to the user manual for your Blaupunkt B-Stream TV Box, an 8 GB media player designed to enhance your home entertainment experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly before using your TV Box.

2. WHAT'S IN THE BOX

Carefully unpack all items and ensure you have received the following components:

- Blaupunkt B-Stream TV Box (Main Unit)
- Remote Control
- Power Adapter
- HDMI Cable

3. SETUP

3.1 Connecting Your Device

1. **Connect to TV:** Use the provided HDMI cable to connect the HDMI port on the Blaupunkt B-Stream TV Box to an available HDMI input on your television.
2. **Connect Power:** Plug the power adapter into the DC IN port on the TV Box, then plug the other end into a wall outlet.
3. **Connect to Network (Optional):** For wired internet, connect an Ethernet cable from your router to the LAN port on the TV Box. For Wi-Fi, you will configure this during the initial setup.

3.2 Initial Setup Wizard

Upon first power-on, the TV Box will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network (if not using wired Ethernet).
- Sign in with your Google account to access Google TV services and apps.
- Accept terms and conditions.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Interface

Use the remote control to navigate the Google TV interface. The directional pad allows you to move between items, and the 'OK' button selects them. Dedicated buttons may include Home, Back, Volume, and App shortcuts.

4.2 Using Google TV

The Blaupunkt B-Stream TV Box runs on Google TV, providing access to a wide range of streaming services, apps, and content. You can:

- Browse and stream movies and TV shows.
- Download and install apps from the Google Play Store.
- Use voice commands via the remote control (if supported).

4.3 Connecting to Wi-Fi

If you need to change your Wi-Fi network or connect for the first time after initial setup:

1. Go to **Settings** on the Google TV home screen.
2. Select **Network & Internet**.
3. Choose your desired Wi-Fi network from the list and enter the password.

5. MAINTENANCE

5.1 Cleaning the Device

To maintain the appearance and functionality of your TV Box:

- Unplug the device from the power outlet before cleaning.
- Use a soft, dry, lint-free cloth to wipe the exterior surfaces.
- Do not use liquid cleaners, aerosols, or abrasive solvents.

5.2 Software Updates

Your Blaupunkt B-Stream TV Box may receive software updates to improve performance and add new features. These updates are typically delivered automatically over the internet. Ensure your device is connected to the internet for updates. The guaranteed software updates until date is currently unknown.

6. TROUBLESHOOTING

If you encounter issues with your Blaupunkt B-Stream TV Box, refer to the following common problems and solutions:

6.1 No Power

- Ensure the power adapter is securely connected to the TV Box and the wall outlet.
- Try plugging the adapter into a different outlet.

6.2 No Signal on TV

- Verify the HDMI cable is firmly connected to both the TV Box and your television.
- Ensure your TV is set to the correct HDMI input source.
- Try a different HDMI port on your TV or a different HDMI cable.

6.3 Network Connection Issues

- For Wi-Fi, check if your router is working correctly. Try restarting your router.
- Ensure you have entered the correct Wi-Fi password.
- For wired connection, ensure the Ethernet cable is properly connected.

6.4 Remote Control Not Responding

- Check and replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the TV Box.
- If the remote uses Bluetooth, you may need to re-pair it according to the on-screen instructions (usually found in Settings > Remotes & Accessories).

7. SPECIFICATIONS

Below are the technical specifications for the Blaupunkt B-Stream TV Box:

Feature	Detail
Brand	Blaupunkt
Model Name	B-Stream
Item Model Number	TV Box
Product Dimensions	2.79 x 24.64 x 16.51 cm; 2.15 kg
Memory Storage Capacity	8 GB
Connectivity Technology	Wi-Fi
Resolution	1080p
Supported Internet Services	Google TV

Feature	Detail
Controller Type	Remote Control
Form Factor	TV Box
Colour	Red
Compatible Devices	Television
Manufacturer	Blaupunkt
Date First Available	17 Feb. 2021
Guaranteed Software Updates Until	unknown

8. WARRANTY AND SUPPORT

Your Blaupunkt B-Stream TV Box comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please visit the official Blaupunkt support website or contact their customer service.

You can visit the [Blaupunkt Store on Amazon](#) for more information.

9. ILLUSTRATIVE VISUALS

The following images are provided for illustrative purposes. Please note that they may not depict the exact product or its components, but rather general product-related concepts or features.



Image Description: A vibrant red background featuring numerous white snowflake patterns. In the center, a lush green Christmas tree is decorated with various colorful spherical ornaments and topped with a golden star. This image represents a festive theme.



Image Description: A shower curtain featuring the same festive Christmas tree design as the previous image, shown installed in a bathroom setting. The bathroom has white brick walls, a white bathtub, and a patterned floor, illustrating a product in use within a home environment.



Image Description: A close-up view of a fabric material, likely a curtain, showing several rustproof metal buttonholes. The text "Rustproof Metal Buttonholes" and "Fixed more firmly" are visible, highlighting a durable feature of the material.

Includes 12 Free Hooks

*Faster disassembly and installation




Image Description: An arrangement of twelve white, C-shaped plastic hooks, typically used for hanging curtains. Text on the image states "Includes 12 Free Hooks" and "Faster disassembly and installation," emphasizing ease of use and included accessories.

Cleaning Instructions



Image Description: A graphic displaying five icons related to product care and features. These include symbols for "Machine Washable" (at 40 degrees), "Water-proof," "Quick Drying," "Ironing," and "Environmental Protection," providing a visual summary of maintenance guidelines.

