

Outsunny 84B-285V01WT

Outsunny Wooden Adirondack Chair Instruction Manual

Model: 84B-285V01WT

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and warnings before assembling and using this product. Failure to follow these instructions may result in injury or product damage.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 330 lbs (150 kg).
- **Outdoor Use:** This chair is designed for outdoor use. While weather-resistant, it is recommended to use a cover when not in use to protect it from harsh weather conditions and extend its lifespan.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use. Regularly check all connections for tightness.
- **Placement:** Place the chair on a stable, level surface to prevent tipping.
- **California Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

2. PRODUCT OVERVIEW

The Outsunny Wooden Adirondack Chair (Model 84B-285V01WT) is a classic outdoor lounge chair made from fir wood, featuring a comfortable tilted backrest, wide armrests, and an integrated cup holder. It is suitable for various outdoor settings such as patios, gardens, backyards, and fire pit areas.



Image 1: The Outsunny Wooden Adirondack Chair in white, showcasing its classic design and integrated cup holder.

Key Features:

- **Material:** Durable Fir Wood construction.
- **Design:** Classic Adirondack style with a tilted backrest and wide armrests for comfort.
- **Convenience:** Integrated cup holder for beverages.
- **Weather Resistant:** Painted finish provides protection against outdoor elements.
- **Versatile:** Suitable for various outdoor environments.

3. ASSEMBLY INSTRUCTIONS

This Adirondack chair is designed for easy assembly. All necessary hardware is included, and back boards are pre-drilled for convenience.

Before You Begin:

- Unpack all components and verify against the parts list (refer to your product packaging for the complete list).
- Ensure you have adequate space for assembly.
- Keep children and pets away from the assembly area.

Step-by-Step Assembly:

1. **Attach Backrest Slats:** Secure the pre-drilled backrest slats to the backrest frame using the provided screws. Ensure they are evenly spaced and firmly attached.
2. **Assemble Seat Base:** Connect the seat slats to the side supports of the seat base. Tighten all screws securely.
3. **Attach Armrests:** Fasten the armrests to the side supports of the chair. Ensure the armrest with the cup holder is placed on the desired side.
4. **Connect Backrest to Seat:** Attach the assembled backrest to the seat base using the designated hardware. The tilted design should be apparent.
5. **Final Connections:** Secure any remaining structural components and ensure all screws are fully tightened. Do not overtighten.



Image 2: Dimensional diagram of the Adirondack chair, illustrating its overall size and key measurements for assembly and placement.

Your browser does not support the video tag.

Video 1: Official assembly guide for the Outsunny Adirondack Chair (Model 01-0016), demonstrating the step-by-step process. Note: Model number in video title may vary, but assembly principles are similar.

4. OPERATING INSTRUCTIONS

The Outsunny Wooden Adirondack Chair is designed for comfortable relaxation in various outdoor settings.

Using Your Chair:

- **Seating:** Sit comfortably in the chair, utilizing the wide armrests and tilted backrest for support.
- **Cup Holder:** Place beverages in the integrated cup holder for easy access.
- **Placement:** Position the chair in your desired outdoor area, such as a patio, garden, or by a fire pit. Ensure it is on a stable surface.



SIMPLE AND COMFORTABLE

Close to nature, you will appreciate her beauty



Image 3: A closer look at the chair's features, including the convenient cup holder, tilted seat and back, sturdy armrests, and slatted design.



STABLE STRUCTURE

Made of natural fir wood



150 kg/330 lbs



Sturdy



Durable

Image 4: The Adirondack chair demonstrated in both indoor and outdoor environments, highlighting its versatility.

5. MAINTENANCE AND CARE

Proper maintenance will ensure the longevity and appearance of your Outsunny Wooden Adirondack Chair.

- **Cleaning:** Wipe clean with a damp cloth. For more thorough cleaning, use mild soap and water with a soft brush. Rinse thoroughly and allow to air dry.
- **Protection:** To protect the wood from prolonged exposure to sun and rain, it is highly recommended to use a furniture cover when the chair is not in use.
- **Inspection:** Periodically inspect all screws and connections to ensure they remain tight. Tighten as needed.
- **Storage:** During off-seasons or extended periods of non-use, store the chair in a dry, protected area to prevent weather damage.

Create your own paradise



Image 5: A visual guide emphasizing the recommendation to use a furniture cover (not included) to extend the chair's lifespan.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Adirondack chair.

- **Wobbling:** If the chair feels unstable or wobbly, check all assembly screws and ensure they are tightened securely. Make sure the chair is placed on a flat, even surface.
- **Wood Discoloration/Fading:** Prolonged exposure to direct sunlight and harsh weather can cause wood to fade or discolor. Regular use of a furniture cover and periodic re-sealing or painting can help mitigate this.
- **Minor Cracks/Splits:** Wood is a natural material and can develop minor cracks or splits due to changes in temperature and humidity. These are often cosmetic and do not affect structural integrity. Ensure proper maintenance as described above.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	Outsunny
Model Number	84B-285V01WT
Color	White
Material	Fir Wood
Overall Dimensions (D x W x H)	37.4"D x 28.3"W x 36.6"H
Seat Height	15 Inches
Seat Depth	19.7 inches
Arm Height	22 Inches
Weight Capacity	330 lbs (150 kg)
Item Weight	18 Pounds
Assembly Required	Yes
Included Components	Arm Pad, Cup Holder, Slatted Backrest

Your browser does not support the video tag.

Video 2: An overview video of the Outsunny Wooden Adirondack Chair, highlighting its features and design.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Outsunny customer service directly. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the official Outsunny store for more information:[Outsunny Store](#)