

[Manuals.plus](#) /

› [Kuryakyn](#) /

› Kuryakyn Sidekix Mini Speaker Instruction Manual

Kuryakyn 2204

Kuryakyn Sidekix Mini Speaker Instruction Manual

Model: 2204

1. INTRODUCTION

The Kuryakyn Sidekix Mini Speaker (Model 2204) is a compact, portable wireless audio solution designed for on-the-go use. It delivers powerful, distortion-free audio from any Bluetooth-enabled device and offers additional functionalities such as a remote camera shutter and hands-free phone capabilities. Its small size allows for easy portability, fitting conveniently in your pocket.



Figure 1: Front view of the Kuryakyn Sidekix Mini Speaker.

2. WHAT'S IN THE BOX

Your Kuryakyn Sidekix Mini Speaker package includes the following items:

- 1 x Sidekix Mini Speaker

- 1 x USB Charging Cable
- 1 x Fastening Cord

3. KEY FEATURES

- **Wireless Audio Streaming:** Connects to any Bluetooth-enabled device for powerful, distortion-free sound.
- **True Stereo Sound:** Pair with an additional Sidekix mini speaker (sold separately) for an enhanced stereo audio experience.
- **Multi-Functionality:** Offers remote camera shutter control, hands-free phone functionality, and Bluetooth streaming up to 150 ft.
- **Extended Playback:** Provides 4 hours of battery life on a 2-hour charge via 3.7V USB.
- **Compact Design:** Universal fit, measuring 36.8 x 43 mm, making it highly portable.
- **Durable Construction:** IPX67 rated for water resistance, allowing submersion up to 3 feet as long as the port cover is securely closed.
- **Mounting Versatility:** Features a 1/4-20 inch tripod mount on the bottom for various mounting options.



Figure 2: The compact Sidekix Mini Speaker shown alongside a larger speaker for size comparison.



Figure 3: Two Sidekix Mini Speakers, demonstrating their ability to be paired for stereo sound.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge your Sidekix Mini Speaker. Connect the provided USB charging cable to the speaker's charging port and plug the other end into a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging time is approximately 2 hours for 4 hours of playback.

4.2 Power On/Off

To power on the speaker, press and hold the power button until you hear an audible confirmation. To power off, press and hold the power button again.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED light).
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "Kuryakyn Sidekix" from the list.
4. Once connected, the LED indicator will turn solid, and you will hear a confirmation tone.

For a visual guide on the speaker's features and pairing, please watch the official product video:

Your browser does not support the video tag.

Video 1: An overview of the Kuryakyn Sidekix Mini Speaker, demonstrating its features and connectivity.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Audio Playback

After successful pairing, open your preferred music application on your device and begin playback. Use the volume controls on your device or the speaker's integrated controls (if available) to adjust the audio level.

5.2 Hands-Free Phone Functionality

When connected to your smartphone, the Sidekix Mini Speaker can be used for hands-free calls. Incoming calls will be routed through the speaker. Use the speaker's multi-function button to answer or end calls.

5.3 Remote Camera Shutter

The speaker can act as a remote shutter for your smartphone camera. With your phone's camera app open and the speaker connected via Bluetooth, press the designated button on the speaker to remotely capture photos.



Figure 4: The Sidekix Mini Speaker positioned next to a smartphone, illustrating its connectivity for audio and remote functions.

6. MOUNTING OPTIONS

The Kuryakyn Sidekix Mini Speaker features a standard 1/4-20 inch threaded mount on its base, allowing for versatile attachment to various accessories such as tripods, selfie sticks, or specialized mounts. This enhances its utility in different environments, from a desktop to outdoor adventures.



Figure 5: The Sidekix Mini Speaker on a wooden surface, highlighting its compact and stable design.

7. MAINTENANCE

To ensure the longevity and optimal performance of your Kuryakyn Sidekix Mini Speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Avoid abrasive cleaners or solvents.
- **Water Resistance:** Always ensure the rubber cover for the charging port is securely closed to maintain its IPX67 water resistance rating. Do not submerge the speaker if the cover is open.
- **Storage:** Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight.
- **Battery Care:** For long-term storage, charge the battery to approximately 50% every few months to prevent deep discharge.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully using the provided USB cable.
Unable to pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode. Turn device Bluetooth off and on. Move speaker closer to device (within 150 ft).

Problem	Possible Cause	Solution
Low or distorted sound.	Volume too low; audio source issue; speaker placed improperly.	Increase volume on both speaker and connected device. Try a different audio source. Ensure speaker is on a stable surface and not obstructed.
Short battery life.	Speaker used at high volume; old battery.	Reduce volume. Ensure full charge cycles. Battery degradation over time is normal.

9. SPECIFICATIONS

Feature	Specification
Model Name	Sidekix
Model Number	2204
Speaker Type	Multimedia
Connectivity Technology	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	150 Feet (45.72 Meters)
Speaker Maximum Output Power	3 Watts
Frequency Response	20Hz-20KHz
Battery Life	4 Hours (playback)
Charging Time	2 Hours
Battery Capacity	300 mAh
Input Voltage	3.7 Volts
Product Dimensions (D x W x H)	1.45" x 1.69" x 1.45" (36.8 x 43 mm)
Item Weight	3.2 ounces
Is Waterproof	FALSE (Water Resistant: IPX67)
Compatible Devices	Smartphone, Tablet, MP3 Player, Laptop
Control Method	Remote

10. WARRANTY AND SUPPORT

The Kuryakyn Sidekix Mini Speaker comes with a limited warranty. For detailed warranty information, product support, or to purchase accessories, please visit the official Kuryakyn website or their store on Amazon.

[Visit the Kuryakyn Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07ZDW95JN>

More documents and user manuals: <https://manuals.plus/>