

- Manuals.plus /
- > [Geek](#) /
 - > Geek Robocook Zeta 8L Electric Pressure Cooker User Manual

Geek YBW80B

Geek Robocook Zeta 8L Electric Pressure Cooker User Manual

Model: YBW80B

1. PRODUCT OVERVIEW

The Geek Robocook Zeta is an 11-in-1 automatic electric pressure cooker designed for versatile cooking. It combines multiple kitchen appliances into one unit, offering functions such as pressure cooking, rice cooking, sautéing, steaming, and more. This appliance features a user-friendly control panel with preset menus for various dishes.



Image 1.1: Front view of the Geek Robocook Zeta Electric Pressure Cooker.

Key Features:

- **11-in-1 Functionality:** Replaces multiple kitchen appliances, offering pressure cooking, rice cooking, sautéing, steaming, and more.
- **13 Indian Preset Menus:** Specialized programs for dishes like Rice, Dal, Channa, Gravy, Biryani, Khichadi, Chicken, and Sambar.
- **8 Litre Capacity:** Stainless steel inner pot (SS304 quality) suitable for 6-8 members.
- **Automatic Operation:** Features automatic cooking and a delay timer.
- **Safety Standards:** BIS Safety Standard certified with a safe pressure release mechanism.



11-IN-1

ELECTRIC PRESSURE COOKER

Image 1.2: Diagram illustrating the 11-in-1 functions of the Robocook Zeta, including pressure cooker, rice cooker, steamer, sauté, slow cooker, and more.

2. IMPORTANT SAFETY INSTRUCTIONS

Before using your Geek Robocook Zeta, please read all instructions carefully to prevent property damage, personal injury, or product damage. Keep this manual for future reference.

- Always ensure the lid is properly closed and locked before operating under pressure.
- Do not fill the inner pot above the MAX fill line to avoid overfilling and potential pressure issues.
- Never force the lid open while the cooker is pressurized. Wait for the pressure to release completely.
- Use caution when releasing steam, as it is hot and can cause burns. Keep hands and face away from the steam release valve.
- Ensure the sealing ring is correctly installed and free from damage before each use.
- Do not immerse the main unit in water or other liquids. Clean with a damp cloth only.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless

supervised or instructed by a responsible person.

- Unplug the appliance from the outlet when not in use and before cleaning.

3. SETUP AND FIRST USE

Unpacking:

1. Carefully remove all contents from the packaging.
2. Verify that all included components are present: Main unit, Inner Pot, Measuring Cup, Rice Paddle, and Power Cord.
3. Remove any protective films or packaging materials from the appliance.

Cleaning Before First Use:

1. Wash the inner pot, sealing ring, and lid components (steam release valve, anti-block shield) with warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. Ensure all parts are dry before assembly.

Assembly:

1. Place the inner pot into the main unit. Ensure it sits flat and securely.
2. Install the sealing ring firmly around the lid's inner rim.
3. Align the lid with the base, ensuring the arrow on the lid points to the 'Open' position on the base. Close the lid by rotating it clockwise until the arrow aligns with the 'Close' position.
4. Ensure the steam release handle is set to the 'Sealing' position for pressure cooking.

4. OPERATING INSTRUCTIONS

The Geek Robocook Zeta offers various cooking functions and preset menus for ease of use.

Basic Operation Steps:

1. **Prepare Ingredients:** Place your ingredients and liquid into the inner pot.
2. **Close Lid:** Securely close the lid and ensure the steam release handle is in the 'Sealing' position.
3. **Select Function:** Press the 'ON/OFF' button to power on. Choose your desired cooking function or preset menu from the control panel.
4. **Adjust Settings (if applicable):** For some functions, you can adjust cooking time or pressure level using the '+' and '-' buttons.
5. **Start Cooking:** The cooker will automatically begin the preheating process, then start cooking.
6. **Pressure Release:** Once cooking is complete, the cooker will beep. Allow for natural pressure release or use the quick release method (turn steam release handle to 'Venting' position) with caution.
7. **Open Lid:** Once pressure is fully released, open the lid by rotating it counter-clockwise.



13 PRESET MENUS

Just a touch of a button and
they'll be ready for you.

Image 4.1: Close-up of the control panel showing the 13 Indian preset menus and other function buttons.

Preset Menus:

The Robocook Zeta features 13 dedicated Indian preset menus for common dishes. Simply select the desired menu, and the cooker will automatically set the optimal cooking time and pressure.

- Rice
- Dal
- Channa
- Gravy
- Biryani
- Khichadi
- Chicken
- Sambar
- Pongal/Idly

- Fish
- Meat
- No Veg
- Sauté

Additional functions include 'Keep Warm/Cancel' and 'Delay Timer' for convenience.





RICE



DAL



CURRY



GRAVY



PULAV



BIRIYANI



FISH



CHICKEN

and many more.

COOK ALMOST EVERYTHING

From Starters to Dessert – Does it All

Image 4.2: Examples of various Indian dishes like Rice, Dal, Curry, Gravy, Pulav, Biryani, Fish, and Chicken that can be prepared using the Robocook Zeta.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure the longevity and safe operation of your electric pressure cooker.

Cleaning the Inner Pot:

The stainless steel inner pot can be washed with warm, soapy water. For stubborn food residues, soak the pot before cleaning. The inner pot is not dishwasher safe.

Cleaning the Lid:

Remove the sealing ring, steam release valve, and anti-block shield from the lid. Wash these components with warm, soapy water. Ensure the steam release valve and anti-block shield are clear of any food particles. Rinse and dry thoroughly before reassembling.

Cleaning the Main Unit:

Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid. Ensure the heating element and surrounding areas are clean and dry.

Storage:

Store the cooker in a dry place. It is recommended to store the lid inverted on the inner pot to prevent the sealing ring from compressing permanently.

6. TROUBLESHOOTING

If you encounter any issues with your Geek Robocook Zeta, refer to the following common troubleshooting tips:

- **Cooker not building pressure:** Ensure the lid is properly closed and locked, and the steam release handle is set to 'Sealing'. Check if the sealing ring is correctly installed and not damaged.
- **Food not cooking properly:** Verify that the correct cooking function and time were selected. Ensure sufficient liquid was added according to the recipe.
- **Error codes on display:** Refer to the full user manual for specific error code meanings and solutions. Generally, unplugging the unit and plugging it back in after a few minutes can resolve minor electronic glitches.
- **Steam leaking from lid:** Check the sealing ring for proper placement and any signs of wear or damage. Ensure the anti-block shield and steam release valve are clean and properly seated.

For persistent issues, contact customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	Geek
Model Number	YBW80B
Capacity	8 Litres
Material	Stainless Steel (Inner Pot: SS304)
Color	Silver
Product Dimensions	33D x 35W x 33H Centimeters
Item Weight	5.5 Kilograms
Control Method	Touch
Operation Mode	Automatic
Dishwasher Safe (Inner Pot)	No
Included Components	Inner Pot, Measuring Cup, Rice Paddle, Power Cord

8. WARRANTY AND SUPPORT

Warranty Information:

The Geek Robocook Zeta comes with a 2-year warranty from the date of purchase. Please retain your purchase receipt as proof of warranty.

Customer Support:

For any product-related queries, service requests, or technical assistance, please contact Geek customer care:

- **Toll-Free Number:** 1800 121 922922
- **Email:** care@harkin.in

Geek offers free doorstep service by expert technicians across India, covering over 19000+ Pincodes, 440+ Cities, and 28+ States. Conditions apply.



RETAINS NUTRITION+

Preserves all the nutritional quotient in the ingredients giving your family the best of health

Image 8.1: Map illustrating the widespread availability of Geek's free doorstep service across India, along with contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07ZF8BJVW>

More documents and user manuals: <https://manuals.plus/>