

SupplySource AC Adapter Charger

SupplySource AC Adapter Charger for Android TV Box M9C pro 4K User Manual

INTRODUCTION

Thank you for choosing the SupplySource AC Adapter Charger. This manual provides detailed instructions for the safe and efficient use of your new power supply, designed for compatibility with the Android TV Box Model M9C pro 4K. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

Your SupplySource AC Adapter Charger is manufactured with high-quality materials and incorporates multiple smart features to ensure safety and reliability. Adherence to these guidelines is crucial for optimal performance and longevity.

- **Over Charge Protection:** Prevents damage from excessive charging.
- **Over Voltage Protection:** Safeguards against input voltage surges.
- **Short-circuit Protection:** Automatically shuts down in case of a short circuit.
- **Over Current Protection:** Protects against excessive current flow.
- **Over Temperature Protection:** Prevents overheating of the adapter.

BUILT IN WITH SAFETY ELECTRONICS



Over Charge
Protection



Over Voltage
Protection



Short-circuit
Protection



Over Current
Protection



Over Temp
Protection



24 Months
Warranty



Image: The AC adapter highlighting its built-in safety electronics, including protections against overcharge, over voltage, short-circuit, over current, and over temperature. It also indicates a 24-month warranty.

Important Precautions:

- Ensure the adapter is used in a well-ventilated area to prevent overheating, especially during prolonged use.
- Avoid placing the adapter on soft surfaces or near heat sources that could obstruct airflow.
- Do not expose the adapter to excessive humidity or liquids.
- Verify that the DC output and tip size of the adapter match your device's requirements before connecting.

PRODUCT OVERVIEW

This AC adapter charger is designed to provide reliable power to your Android TV Box Model M9C pro 4K. It features a robust construction with high-quality copper core wire for extended durability.



Image: A side profile view of the SupplySource AC adapter, illustrating its compact design and the approximate 4-foot length of its power cable.

SETUP INSTRUCTIONS

1. **Verify Compatibility:** Before connecting, ensure that the DC output voltage and current, as well as the physical tip size of this adapter, are compatible with your Android TV Box Model M9C pro 4K. Incorrect specifications can damage your device.
2. **Connect to Device:** Insert the barrel connector of the adapter firmly into the power input port of your Android TV Box.
3. **Connect to Power Outlet:** Plug the AC adapter into a standard 100-240V wall outlet. Ensure the outlet is easily accessible.
4. **Power On:** Once connected, your Android TV Box should receive power. Refer to your TV Box's manual for specific power-on procedures.

OPERATING INSTRUCTIONS

The SupplySource AC Adapter Charger operates automatically once connected to a power source and a compatible device. It provides a stable power supply within its specified input voltage range.

- **Input Voltage:** The adapter is designed to operate with an input voltage range of 100-240V AC.
- **Continuous Use:** For continuous operation, ensure the adapter is placed in an area with adequate ventilation to dissipate heat.

MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your AC adapter.

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connector for any signs of wear, fraying, or damage. If any damage is observed, discontinue use immediately.

TROUBLESHOOTING

If you encounter issues with your AC adapter, please refer to the following common troubleshooting steps:

- **Device Not Powering On:**
 - Ensure the adapter is securely plugged into both the wall outlet and your Android TV Box.
 - Check if the wall outlet is functional by plugging in another device.
 - Verify that the adapter's specifications (voltage, current, tip size) match your device's requirements.
- **Adapter Overheating:**
 - Ensure the adapter is in a well-ventilated area and not covered by any objects.
 - Disconnect the adapter for a few minutes to allow it to cool down.
 - If overheating persists, discontinue use and contact support.
- **Intermittent Power:**
 - Check all connections for looseness.
 - Inspect the cable for any visible damage or kinks.

If these steps do not resolve the issue, please refer to the Warranty and Support section.

SPECIFICATIONS

Feature	Specification
Brand	SupplySource
Input Voltage Range	100-240V AC
Frequency Range	60 Hz

Connector Type	Barrel Connector
Compatible Devices	Android TV Box Model M9C pro 4K (and other compatible devices)
Material	Metal, Plastic
Power Source	Corded Electric
Certifications	CE, FCC

WARRANTY AND SUPPORT

This SupplySource AC Adapter Charger comes with a**24-month warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

Warranty Exclusions:

- Damage caused by misuse, accident, unauthorized modification, or improper installation.
- Damage from exposure to liquids, extreme temperatures, or environmental conditions.
- Normal wear and tear.

Customer Support:

For technical assistance, warranty claims, or any questions regarding your SupplySource AC Adapter Charger, please contact your retailer or the manufacturer's customer service. Please have your product model and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07ZFBFRS7>

More documents and user manuals: <https://manuals.plus/>