

[manuals.plus](#) /

- › [1MORE](#) /
- › [1MORE True Wireless ANC Earbuds User Manual](#)

## 1MORE EHD9001TA

# 1MORE True Wireless ANC Earbuds User Manual

Model: EHD9001TA

## 1. PRODUCT OVERVIEW

---

The 1MORE True Wireless ANC In-Ear Headphones are designed to deliver superior audio quality with advanced features. These earbuds incorporate dual drivers for rich sound, two levels of active noise cancellation (ANC) for immersive listening, and a pass-through mode for environmental awareness. They are THX Certified, ensuring high-fidelity audio performance. Equipped with the latest Qualcomm chipset and Bluetooth 5 technology, they offer seamless aptX and AAC transmission, compatible with both Android and iOS devices. The earbuds support both wired and wireless charging for convenience.



An image showing the 1MORE True Wireless ANC Earbuds, with one earbud removed from its open charging case, highlighting its design and the compact charging solution.

## 2. SAFETY INFORMATION

---

- Do not disassemble or modify the earbuds or charging case. This may cause malfunction or fire.
- Avoid exposing the product to extreme temperatures (below 0°C or above 45°C).
- Do not use the product during a thunderstorm to avoid electric shock.
- Keep the product away from water or other liquids.
- Do not use corrosive cleaners or strong detergents to clean the product.
- Prolonged exposure to high volume levels may cause permanent hearing damage. Adjust volume to a moderate level.

## 3. WHAT'S IN THE Box

---

The product package includes the following items:

- 1MORE True Wireless ANC Earbuds
- Charging Case
- User Manual
- USB-C Charging Cable
- Various sizes of ear tips

## 4. SETUP

---

### 4.1 Charging

Before first use, fully charge the earbuds and the charging case. The charging case has a battery capacity of 410 mAh, and each earbud has a 55 mAh battery.

1. **Charging the Earbuds:** Place the earbuds into the charging case. They will begin charging automatically. Earbud charging time is approximately 1 hour.
2. **Charging the Case (Wired):** Connect the USB-C charging cable to the charging port on the case and to a power source.
3. **Charging the Case (Wireless):** Place the charging case on a compatible wireless charging pad.

*The LED indicators on the case and earbuds will show charging status.*

### 4.2 Wearing the Earbuds

Proper fit is crucial for optimal sound quality and noise cancellation. The earbuds come with various sizes of ear tips to ensure a snug and comfortable fit.

1. Select the ear tips that provide the best seal and comfort for your ears. If the earbud tips do not match your ear canals or the headset is not worn properly, sound quality or call performance may be affected.
2. Gently insert the earbud into your ear canal.
3. Rotate the earbud slightly until it feels secure and comfortable. The earbud should form a good seal to maximize noise cancellation and bass response.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** The earbuds automatically power off and begin charging when placed back into the charging case.

### 5.2 Bluetooth Pairing

To connect your 1MORE True Wireless ANC Earbuds to a device:

1. Ensure the earbuds are charged and in the charging case.
2. Open the charging case. The earbuds will enter pairing mode automatically (indicated by flashing LED lights).

3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "1MORE ANC Earbuds" or similar in the list of available Bluetooth devices.
5. Select the earbuds to connect. Once connected, the LED indicators will stop flashing.

*The Bluetooth range is approximately 10 meters (33 feet).*

## 5.3 Controls

The earbuds feature intuitive touch controls on each earbud for various functions:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Left)	Volume Down
Double Tap (Right)	Volume Up
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right)	Switch ANC Modes (ANC On / Pass-Through / ANC Off)

## 5.4 Active Noise Cancellation (ANC) and Pass-Through Mode

The earbuds offer two levels of active noise cancellation and a pass-through mode:

- **ANC On:** Reduces ambient noise for an immersive listening experience. Dual ANC microphones and a dedicated DSP analyze and block environmental and in-ear noises.
- **Pass-Through Mode:** Allows you to hear your surroundings while still enjoying your audio, useful for awareness in busy environments.
- **ANC Off:** Standard listening mode without active noise cancellation.

*Cycle through these modes by long-pressing the touch control area on either earbud.*

## 6. MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials. Regularly clean the ear tips and mesh to prevent wax buildup.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.

## 7. TROUBLESHOOTING

---

- **Earbuds not charging:** Ensure the charging case is charged. Check that the earbuds are properly seated in the charging case and that the charging contacts are clean.
- **Earbuds not pairing:** Make sure Bluetooth is enabled on your device and the earbuds are in pairing mode. Try turning Bluetooth off and on again on your device. If issues persist, try resetting the earbuds (refer to 1MORE support for specific reset instructions).

- No sound or low volume:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly seated in your ears and that the correct ear tips are used to form a good seal.
- Intermittent connection:** Ensure you are within the 10-meter Bluetooth range. Avoid obstacles between the earbuds and your device. Minimize interference from other wireless devices.
- ANC not effective:** Ensure the earbuds are properly sealed in your ear canals. Cycle through the ANC modes to confirm it is activated.

## 8. SPECIFICATIONS

<b>Model Name</b>	EHD9001TA
<b>Connectivity Technology</b>	Bluetooth 5.0
<b>Ear Placement</b>	In Ear
<b>Noise Control</b>	Active Noise Cancellation
<b>Audio Driver Type</b>	Hybrid Driver (Dual Driver)
<b>Frequency Range</b>	20 Hz - 20,000 Hz
<b>Bluetooth Range</b>	10 Meters
<b>Earbud Battery Capacity (Single)</b>	55 mAh
<b>Charging Case Battery Capacity</b>	410 mAh
<b>Earbud Charging Time</b>	Approx. 1 hour
<b>Control Method</b>	Touch, Voice
<b>Water Resistance Level</b>	Water Resistant
<b>Item Weight (Earbud)</b>	8 Grams (0.282 ounces)
<b>Product Dimensions</b>	6.4 x 6 x 2.5 inches
<b>Manufacturer</b>	1MORE USA Inc
<b>UPC</b>	190280101532

## 9. WARRANTY AND SUPPORT

1MORE products are covered by a limited warranty. For detailed warranty information, product registration, and technical support, please visit the official 1MORE website or contact their customer service.

**Official 1MORE Website:** [www.1more.com](http://www.1more.com)

For further assistance, refer to the contact information provided on the 1MORE website or the original product packaging.

© 2024 1MORE. All rights reserved.