



Manuals.plus /

› SupplySource /

› SupplySource AC DC Adapter Charger for APEMAN PV760 FUNAVO 918A eXu EXBDVD-109 DVD Player User Manual

SupplySource AC DC Adapter Charger

SupplySource AC DC Adapter Charger User Manual

For APEMAN PV760, FUNAVO 918A, eXu EXBDVD-109 DVD Players

1. INTRODUCTION

Thank you for choosing the SupplySource AC DC Adapter Charger. This manual provides essential information for the safe and efficient use of your new power adapter. Please read these instructions carefully before use and retain them for future reference.

This adapter is designed to provide reliable power to compatible portable DVD players, including the APEMAN PV760, FUNAVO 918A, and eXu EXBDVD-109 models.

2. SAFETY INFORMATION

- **Compatibility Check:** Before connecting, ensure the DC output voltage and tip size of this adapter match your device's requirements. Incorrect voltage or tip size can damage your device.
- **Ventilation:** When in use for extended periods, ensure the adapter is in a well-ventilated area and not covered. Avoid placing it on heat-sensitive surfaces or materials that could restrict airflow.
- **Humidity:** Keep the adapter in a suitable humidity environment. Avoid exposure to water or excessive moisture.
- **Surface Contact:** Do not place the adapter directly on skin products or other materials that may be sensitive to heat generated during operation.
- **Safety Features:** This SupplySource adapter is manufactured with built-in safety electronics to protect against incorrect voltage (IV), short circuits (SC), and internal overheating (IO). It is certified with CE and FCC standards.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact support for assistance.

BUILT IN WITH SAFETY ELECTRONICS



Over Charge
Protection



Over Voltage
Protection



Short-circuit
Protection



Over Current
Protection



Over Temp
Protection



24 Months
Warranty



This image illustrates the safety features integrated into the SupplySource AC DC Adapter, including protection against overcharge, over voltage, short-circuit, over current, and over temperature, along with a 24-month warranty.

3. PRODUCT OVERVIEW

The SupplySource AC DC Adapter Charger is a reliable power supply unit designed for various portable DVD players. It converts standard AC wall power into the DC power required by your device.

Key Features:

- **Universal Input:** Supports input voltage range of 100-240V, suitable for international use.
- **Safety Certifications:** CE and FCC certified for quality and safety.
- **Integrated Protections:** Features safeguards against incorrect voltage, short circuits, and internal overheating.
- **Cable Length:** Provides a 4-foot cable for flexible placement.



This image displays the compact design of the AC DC adapter and indicates its 4-foot cable length, providing ample reach for various setups.

4. SETUP INSTRUCTIONS

1. **Verify Compatibility:** Before plugging in, confirm that the DC output voltage and connector tip size of this adapter match the specifications required by your DVD player (e.g., APEMAN PV760, FUNAVO 918A, eXu EXBDVD-109). This information is usually found on your device or its original power supply.
2. **Connect to Device:** Insert the barrel connector of the adapter firmly into the DC input port of your DVD player.
3. **Connect to Power Outlet:** Plug the 2-pin main power connector of the adapter into a standard 100-240V AC wall outlet.
4. **Power On:** Once connected, your device should receive power. Turn on your DVD player as per its own operating instructions.

5. OPERATING INSTRUCTIONS

The SupplySource AC DC Adapter operates automatically once connected to a power source and a compatible device. No user intervention is required for its basic function.

- Ensure the adapter is placed in an area with adequate ventilation to prevent overheating, especially during prolonged use.
- Avoid covering the adapter with cloths or other materials that could trap heat.
- Disconnect the adapter from the wall outlet when not in use for extended periods.

6. MAINTENANCE

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or sprays.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cable too tightly around the adapter to prevent damage to the internal wires.
- **Inspection:** Periodically inspect the power cord and connector for any signs of damage, such as fraying or bending. If damage is observed, discontinue use and replace the adapter.

7. TROUBLESHOOTING

Device Not Powering On:

- **Check Connections:** Ensure the adapter's barrel connector is fully inserted into your DVD player and the 2-pin plug is securely in the wall outlet.
- **Verify Power Outlet:** Test the wall outlet with another device to confirm it is supplying power.
- **Confirm Compatibility:** Double-check that the adapter's specifications (voltage, current, tip size) are correct for your specific DVD player model.
- **Inspect for Damage:** Examine the adapter's cable and housing for any visible damage. If damaged, do not use.

Adapter Feels Warm:

- It is normal for power adapters to become warm during operation. However, if it feels excessively hot to the touch, disconnect it immediately.
- Ensure adequate ventilation around the adapter. Remove any obstructions that might be blocking airflow.
- Avoid using the adapter in direct sunlight or enclosed spaces.

If troubleshooting steps do not resolve the issue, please contact customer support.

8. SPECIFICATIONS

- **Input Voltage Range:** 100-240V AC
- **Input Frequency:** 50-60Hz
- **Cable Length:** 4 feet (approximately 1.2 meters)
- **Connector Type:** Barrel connector
- **Main Power Connector Type:** 2 Pin (US standard)
- **Compatible Devices:** APEMAN PV760, FUNAVO 918A, eXu EXBDVD-109 DVD Players
- **Certifications:** CE, FCC
- **Material:** Metal, Plastic
- **Mounting Type:** Wall Mount

9. WARRANTY AND SUPPORT

This SupplySource AC DC Adapter Charger comes with a **24-month warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or any questions regarding the product, please contact SupplySource customer service through your original point of purchase or visit the official SupplySource website for contact information.

Please have your product model number and purchase details ready when contacting support.