

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VASAGLE](#) /

› [VASAGLE Kitchen Shelf, Microwave and Baker's Rack User Manual](#)

## VASAGLE KKS35X

# VASAGLE Kitchen Shelf, Microwave and Baker's Rack

## USER MANUAL

Model: KKS35X

## Introduction

---

Thank you for choosing the VASAGLE Kitchen Shelf. This manual provides essential information for the safe assembly, operation, and maintenance of your new kitchen rack. Please read these instructions carefully before assembly and keep them for future reference.

This versatile kitchen shelf is designed to provide stable and organized storage for your kitchen appliances and essentials, featuring a rustic brown finish and a sturdy black steel frame.

## Safety Instructions

---

- Always assemble the product on a clean, flat, and soft surface to prevent scratches and damage.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity for each shelf as specified in the "Specifications" section. Overloading can lead to instability and damage.
- Utilize the included anti-tipping device to secure the shelf to a wall, especially if children or pets are present. This significantly reduces the risk of tip-over accidents.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Avoid placing hot items directly on the shelves without protective padding.
- Do not stand or climb on the unit.



**Figure 1: Stability Features.** This image highlights the key stability features of the VASAGLE Kitchen Shelf, including the anti-tipping kit for wall attachment, the X-shaped bars providing structural rigidity, and the adjustable feet for leveling on uneven floors. These components are crucial for ensuring the safety and stability of the unit.

## Package Contents

Before beginning assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Steel Frame Components (various lengths and shapes)
- Particle Board Shelves (main top, middle, lower, side shelves)
- Wire Basket (pull-out design)
- S-shaped Hooks (6 pieces)
- Adjustable Feet
- Anti-tipping Kit (wall anchor, strap, screws)
- Assembly Hardware (screws, bolts, Allen key)
- Instruction Manual

## Assembly Instructions

---

Follow the numbered steps in the provided assembly guide. All parts are clearly labeled to facilitate a smooth assembly process.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a soft, clean surface. Identify each part using the provided parts list and diagrams.
2. **Assemble Frame:** Begin by connecting the main steel frame components according to the diagrams. Do not fully tighten screws until all parts are loosely assembled.
3. **Attach Shelves:** Secure the particle board shelves to the frame using the designated screws. Ensure the shelves are oriented correctly.
4. **Install Wire Basket:** Slide the wire basket into its designated runners. Ensure the safety button mechanism is correctly engaged to prevent accidental removal.
5. **Attach S-Hooks Bar:** Secure the bar for the S-hooks to the side of the frame.
6. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts.
7. **Adjust Feet:** Adjust the leveling feet at the bottom of the unit to ensure it stands stable and level on your floor.
8. **Install Anti-Tipping Device:** For safety, always install the anti-tipping device. Mark the wall, drill pilot holes, and secure the strap to both the shelf and the wall as instructed.

*Note: Two people are recommended for assembly to ensure stability and ease of handling larger components.*

## Operating and Usage Instructions

---

The VASAGLE Kitchen Shelf is designed for versatile storage in your kitchen or other areas. Its multi-level design allows for organized placement of various items.

- **Main Surface:** The large top surface (90 x 39 cm) is ideal for larger kitchen appliances such as microwaves, coffee makers, toasters, or blenders.
- **Upper Shelf:** The elevated upper shelf provides convenient space for spices, small decorative items, or frequently used condiments.
- **Middle and Lower Shelves:** These shelves offer ample space for pots, pans, cookbooks, storage containers, or other kitchen essentials.
- **Wire Basket:** The pull-out wire basket is perfect for storing fruits, vegetables, smaller dishes, or pantry items, allowing for easy access.
- **S-Hooks:** Utilize the six S-shaped hooks to hang ladles, spatulas, oven mitts, or other kitchen utensils, keeping them within reach and organized.

# Du rangement


Cette étagère de rangement bien compartimentée permet de ranger divers articles.



**Figure 2: Organized Storage.** This image demonstrates the various storage possibilities of the kitchen shelf, showcasing a microwave, coffee maker, blender, and other kitchen items neatly arranged on its multiple shelves and using the integrated hooks.

# Panier extractible avec bouton de sécurité

Pour accéder facilement aux articles, le panier ne tombe pas



**Figure 3: Pull-Out Wire Basket.** A detailed view of the pull-out wire basket, illustrating its design for easy access to contents and the safety button that prevents it from accidentally falling out when fully extended.

# 6 crochets en forme de S

Pour suspendre les louches, les spatules et les tasses.



**Figure 4: S-Shaped Hooks.** This image provides a close-up of the six S-shaped hooks, demonstrating how they can be used to conveniently hang kitchen utensils like ladles and spatulas, keeping them organized and readily accessible.

## Maintenance

---

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish. Dry immediately after cleaning.
- **Regular Checks:** Periodically inspect all connections and fasteners to ensure they remain tight. Re-tighten any

loose screws to maintain stability.

- **Avoid Moisture:** While the shelves are durable, prolonged exposure to excessive moisture should be avoided to prevent warping or damage to the particle board.
- **Weight Distribution:** Distribute weight evenly across the shelves to prevent stress on any single point and maintain the unit's balance.

## Troubleshooting

---

Problem	Possible Cause	Solution
Shelf is wobbly/unstable.	Screws are loose; uneven floor; adjustable feet not properly set.	Tighten all screws. Adjust the leveling feet until the unit is stable. Ensure the anti-tipping device is installed.
Parts do not align during assembly.	Incorrect orientation of parts; screws overtightened prematurely.	Loosen all screws, re-check part orientation against the manual diagrams, then re-tighten.
Missing or damaged parts.	Packaging error; shipping damage.	Do not proceed with assembly. Contact VASAGLE customer support with your purchase details and a list of missing/damaged parts.
Wire basket does not slide smoothly.	Obstruction in runners; basket not properly seated.	Check for any debris in the runners. Ensure the basket is correctly inserted and aligned.

## Specifications

---

**Model:** KKS35X

**Color:** Rustic Brown + Black

**Material:** Engineered Wood, Alloy Steel

**Overall Dimensions (L x W x H):** 90 x 40 x 132 cm (35.4 x 15.7 x 52 inches)

**Weight:** 15.7 kg (34.6 lbs)

**Max. Static Load Capacity per Shelf:**

- Top Small Shelf: 15 kg (33 lbs)
- Main Top Shelf: 25 kg (55 lbs)
- Middle Shelf: 15 kg (33 lbs)
- Lower Shelves (each): 5 kg (11 lbs)

**Number of Shelves:** 6

**Special Features:** Stable design, adjustable feet, anti-tipping device, pull-out wire basket, 6 S-hooks.

# Grande surface

La grande surface de 39 x 90 cm est suffisamment large pour accueillir vos appareils de cuisine.



**Figure 5: Product Dimensions.** This diagram provides a comprehensive overview of the kitchen shelf's dimensions, including its overall height, width, and depth, as well as the specific measurements for each shelf and compartment.



**Figure 6: Main Surface Area.** This image illustrates the spacious main surface of the kitchen shelf, highlighting its dimensions (90 cm width x 39 cm depth) and demonstrating its capacity to comfortably accommodate a microwave oven and other kitchen items.

## Warranty and Support

For any questions, concerns, or issues regarding your VASAGLE Kitchen Shelf, please contact the seller or manufacturer directly. Keep your purchase receipt or order number handy for faster service.

You can visit the official VASAGLE brand store for more information and support: [VASAGLE Brand Store](#)

