

MOKIBO MKB316_BK

INNOPRESSO Mokibo MKB316_BK Bluetooth Wireless Keyboard with Touchpad User Manual

Model: MKB316_BK

INTRODUCTION

Thank you for purchasing the INNOPRESSO Mokibo MKB316_BK Bluetooth Wireless Keyboard with Touchpad. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully before use to ensure optimal performance and longevity of your product.

PRODUCT OVERVIEW

The Mokibo MKB316_BK is a compact and lightweight Bluetooth wireless keyboard designed for tablets and other compatible devices. It features an innovative design that integrates a touchpad directly into the keyboard keys, allowing for seamless switching between typing and cursor control. This eliminates the need for a separate mouse, enhancing portability and convenience.




Image: The INNOPRESSO Mokibo MKB316_BK Bluetooth Wireless Keyboard with its integrated touchpad functionality.

Key Features:

- **Integrated Typing and Cursor Movement:** Seamlessly switch between typing and touchpad functions directly on the keyboard surface.
- **Instant Touchpad Activation:** Transition from typing to touchpad mode instantly for scrolling, zooming in, and zooming out.
- **Ultra-Portable Design:** Weighing only 245g and with a thickness of 7.5mm, it is designed for easy portability alongside your tablet.
- **Wide OS Compatibility:** Supports Windows 10, Android 9, and iOS/macOS 13 and later versions.

SETUP

1. Charging the Keyboard

Before initial use, fully charge the Mokibo keyboard using the included USB cable. Connect the micro USB port on the keyboard to a USB power source (e.g., computer, USB wall adapter).



Image: The Mokibo keyboard showing its dimensions (260mm x 130mm x 7.5mm) and the location of the micro USB charging port.

2. Powering On/Off

Locate the power switch on the back of the keyboard. Slide the switch to the 'ON' position to power on the device. Slide it to 'OFF' to power it down.



Image: Close-up of the back of the Mokibo keyboard, showing the power switch and product details including model number MKB316.

3. Bluetooth Pairing

1. Ensure the keyboard is powered on.
2. Activate Bluetooth on your device (tablet, smartphone, computer).
3. On the Mokibo keyboard, press and hold the Bluetooth pairing key (usually indicated by a Bluetooth icon or 'Fn' + a specific key, refer to the keyboard layout for exact key) until the indicator light flashes, signifying it is in pairing mode.
4. On your device, search for available Bluetooth devices. Select 'Mokibo MKB316_BK' (or similar name) from the list.
5. Follow any on-screen prompts to complete the pairing process. A successful connection will be indicated by a steady light on the keyboard.

4. Firmware Update (Important for iOS/iPadOS/macOS/Android Users)

For users operating with iOS, iPadOS, macOS, or Android devices, it is highly recommended to update the keyboard's firmware to the latest version. Refer to the product's official website or the included documentation for detailed firmware update procedures.

OPERATING INSTRUCTIONS

Typing Mode

The Mokibo keyboard functions as a standard QWERTY keyboard for typing. The keys are designed for comfortable and efficient input.



Image: A close-up view of the Mokibo keyboard keys, highlighting the keycap design for typing.

Touchpad Mode

The unique feature of the Mokibo keyboard is its integrated touchpad functionality. When you are not actively typing, the keyboard surface automatically transitions into a touchpad. This allows you to control the cursor, scroll, and perform multi-touch gestures directly on the keys.



Image: A hand demonstrating how to use the integrated touchpad feature on the Mokibo keyboard, where the keys themselves act as the touch surface.



Image: An illustration highlighting the active touchpad area on the Mokibo keyboard, which covers the main key section.

Multi-Device Switching

The Mokibo keyboard supports multi-pairing, allowing you to connect to several devices and switch between them. Refer to the specific function keys (often Fn + F1/F2/F3) for switching between paired devices.

MAINTENANCE

Cleaning

To clean the keyboard, power it off and disconnect it from any power source. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid using harsh chemicals, abrasives, or excessive moisture, as these can damage the device.

Storage

Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure it is powered off to conserve battery life.

TROUBLESHOOTING

Keyboard Not Connecting via Bluetooth

- Ensure the keyboard is powered on and fully charged.
- Verify that Bluetooth is enabled on your device.
- Put the keyboard into pairing mode again (refer to 'Bluetooth Pairing' section).
- Delete the keyboard from your device's Bluetooth list and attempt to re-pair.
- Try connecting to a different device to rule out an issue with your primary device.

Touchpad Not Responding

- Ensure your device's operating system is compatible and updated.
- Check if the keyboard's firmware is up to date, especially for iOS/iPadOS/macOS/Android.
- Restart both the keyboard and your connected device.
- Ensure no foreign objects or debris are on the keyboard surface that might interfere with touch detection.

Keys Not Responding

- Check the battery level and charge the keyboard if necessary.
- Ensure the keyboard is properly connected via Bluetooth.

- Restart the keyboard and your device.

SPECIFICATIONS

Brand	MOKIBO
Model Number	MKB316_BK
Color	Black
Connectivity Technology	Bluetooth
Compatible Devices	Tablet (Windows 10, Android 9, iOS/MacOS 13~)
Special Features	Integrated Trackpad, Lightweight Design
Included Components	USB Cable
Hand Orientation	Ambidextrous
Number of Keys	80
Product Weight	0.24 kg (245g)

WARRANTY AND SUPPORT

Warranty Information

This product comes with a **1-year warranty** from the date of purchase. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

Customer Support

For technical assistance, warranty claims, or any other inquiries, please contact INNOPRESSO customer support through their official website or the contact information provided with your purchase documentation.