

Subcold SUPER35

Subcold Super35 LED Mini Fridge Instruction Manual

INTRODUCTION

Thank you for choosing the Subcold Super35 LED Mini Fridge. This appliance is designed for efficient cooling of beverages and snacks, featuring a 35-liter capacity, LED lighting, and a secure lock. Please read this manual thoroughly before installation and operation to ensure proper use and maintenance.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the appliance is unplugged before cleaning or performing any maintenance.
- Do not operate the appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless

they are of the type recommended by the manufacturer.

PACKAGE CONTENTS

Upon unpacking, please ensure all items are present and undamaged:

- Subcold Super35 LED Mini Fridge Unit
- 2 x Removable Chrome Wire Shelves
- 2 x Keys for Security Lock
- Instruction Manual (this document)

SETUP AND INSTALLATION

1. Unpacking and Placement

Remove all packaging materials. Place the fridge on a firm, level surface away from direct sunlight or heat sources. Ensure there is adequate ventilation around the unit (at least 10cm clearance on sides and back) for efficient operation. Allow the unit to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

2. Installing Shelves

The fridge comes with two removable and adjustable chrome wire shelves. Insert the shelves into the desired slots inside the cabinet.



Figure 1: Interior of the fridge showing the removable and adjustable chrome wire shelves.

3. Reversible Door Installation

The door of the Subcold Super35 is reversible, allowing it to open from either the left or right side. If you wish to change the door swing direction, refer to the detailed instructions provided in the separate door reversal guide (not included in this general manual, typically found with the product or online). This process usually involves unscrewing hinges and reattaching them on the opposite side.

Dual-Glazed Tempered Glass Door

Quality build with high grade double glazed glass door for efficient cooling. Keeps the inside temperature at optimum level.



White LED Light

LED light inside the fridge that illuminates your contents when accessing in dark. It can be turned on/off with a simple switch.

Removable & Adjustable Shelves

The internal storage is customisable. There are 2 strong chrome wire shelves that are removable and adjustable.



Adjustable Thermostat

The adjustable thermostat inside gives you a temperature range of 3°C to 18°C. Perfect for all your beer, wine and drinks.

Reversible Door

The fridge is equipped with reversible door and adjustable feet to easily fit in anywhere just the way you need it.



Lockable with Key

Keeps your snacks and drinks safe and secure. Prevents any unauthorised access. 2 keys are provided with the fridge.

Figure 2: Detail of the reversible door hinge, allowing for flexible placement.

4. Security Lock and Key

The fridge is equipped with a security lock to keep contents safe. Insert the key into the lock located at the bottom of the door and turn to secure or unlock. Two keys are supplied.



Figure 3: The integrated security lock and keyhole for securing contents.

OPERATING INSTRUCTIONS

1. Power Connection

After allowing the fridge to stand for 2-4 hours, plug the power cord into a suitable 230V electrical outlet.

2. Temperature Control

The Subcold Super35 features an adjustable thermostat located inside the unit. Turn the dial to set the desired temperature. The temperature range is typically between 3°C and 18°C. A lower number on the dial usually indicates a colder setting.

Subcold Super35 ENERGY RATING




Figure 4: Adjustable thermostat dial for precise temperature control.

3. Internal LED Light

The fridge is equipped with an internal LED light to illuminate the contents. This light can typically be turned on or off via a switch located near the light fixture or control panel.

4. Loading the Fridge

Arrange bottles, cans, and snacks on the shelves. Avoid overloading the fridge, as this can restrict airflow and reduce cooling efficiency. Ensure items do not block the internal fan or air vents.



Figure 5: The fridge interior, demonstrating typical loading with beverages.

MAINTENANCE

1. Cleaning the Interior

Unplug the fridge before cleaning. Remove all contents and shelves. Wipe the interior surfaces with a soft cloth dampened with a mild detergent solution. Rinse with clean water and dry thoroughly. Do not use abrasive cleaners or solvents.

2. Cleaning the Exterior

Clean the exterior surfaces with a soft, damp cloth. For the glass door, use a glass cleaner. Ensure no water enters the electrical components.

3. Defrosting

This appliance features manual defrosting. Frost buildup can occur over time, especially in humid environments. When frost accumulation exceeds 5mm, unplug the unit and allow the frost to melt naturally. Place a towel at the bottom to absorb water. Do not use sharp objects to remove frost.

4. Door Seal Maintenance

Regularly check and clean the door gasket to ensure a tight seal. A damaged or dirty seal can lead to inefficient cooling and increased energy consumption.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Fridge does not operate	No power supply; Plug not properly inserted; Circuit breaker tripped.	Check power connection; Ensure plug is secure; Reset circuit breaker.
Fridge is not cold enough	Temperature setting too high; Door not closed properly; Excessive door opening; Warm items placed inside; Poor ventilation.	Adjust thermostat to a colder setting; Ensure door is fully closed; Reduce frequency of door opening; Allow warm items to cool before placing in fridge; Ensure adequate clearance around the unit.
Excessive noise	Fridge not level; Objects vibrating against the unit; Compressor noise (normal operation).	Adjust leveling feet; Ensure no objects are touching the fridge; Compressor noise is normal, especially when starting or stopping.
Internal LED light not working	Light switch off; LED bulb failure.	Check the light switch; Contact customer support for bulb replacement if necessary.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	SUPER35
Capacity	35 Litres (Gross), 33 Litres (Net)
Dimensions (W x D x H)	405 x 440 x 552 mm
Temperature Range	3°C - 18°C (Adjustable)
Cooling Method	Compressor
Voltage	230 Volts

Feature	Specification
Annual Energy Consumption	48 kWh/year
Noise Level	42 dB
Number of Shelves	2 (Chrome Wire, Removable & Adjustable)
Door Type	Dual Glazed Safety Glass, Reversible
Lock Type	Key Lock (2 keys supplied)
Item Weight	15.6 Kilograms
Certifications	CE, ROHS, WEEE Compliant

Product Information Sheet			
COMMISSION REGULATION (EU) 2017/1365 on the labelling of refrigerating appliances			
Supplier's name or trade mark: Subcold			
Supplier's address: Manufacturer: Subcold, 3 Drummond Square, Knoxfield Industrial Estate, Livingston, West Lothian EH54 6EH United Kingdom			
Model identifier: SUP35LED36L			
Type of refrigerating appliance:			
Low-noise appliance:	No	Design type:	Free-standing
Wine storage appliance:	No	Other refrigerating appliance:	Yes
General product parameters:			
Parameter:	Value:	Parameter:	Value:
Overall dimensions (in millimetres)	Height: 550 Width: 402 Depth: 430	Total volume (dm ³ or l)	33
EEI	69	Energy efficiency class	C
Achilles acoustical noise emissions (dB(A) re 1 pPa)	42	Achilles acoustical noise emission class	D
Annual energy consumption (kWh/y)	48	Climate class:	temperate
Minimum ambient temperature (T _{cl}) for which the refrigerator appliance is suitable	16	Maximum ambient temperature (T _{ch}) for which the refrigerator appliance is suitable	32
Winter setting:	No		
Compartment Parameters:			
Compartment type	Compartment parameters and values:		
	Compartment volume (dm ³ or l)	Volume needed to reach the setpoint temperature (litres) (V _{ref})	Defrosting type (auto-defrost, manual defrost)
	These are the storage conditions set out in Annex IV, Table B.	Freezing capacity (auto-defrost, manual defrost) (kg/24h)	

Figure 6: New EU Energy Rating Label for the Subcold Super35 LED Mini Fridge.

WARRANTY AND SUPPORT

The Subcold Super35 LED Mini Fridge comes with a **1 Year Full Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets high quality standards.

For warranty claims, technical support, or any inquiries regarding your product, please contact Subcold customer service. You can find more information and contact details on the official Subcold website: <https://subcold.com/>

All Subcold products are tested to high UK standards and come complete with CE and ROHS Certification, along with WEEE compliance.