

[Manuals.plus](#) /

› [EUGAD](#) /

› EUGAD L-Shape Computer Desk 4054908205520 Instruction Manual

EUGAD 4054908205520

EUGAD L-Shape Computer Desk Instruction Manual

Model: 4054908205520

1. INTRODUCTION

This manual provides detailed instructions for the assembly, safe operation, and proper maintenance of your EUGAD L-Shape Computer Desk. This desk is designed for versatile use in home or office environments, offering an L-shaped configuration with integrated shelving for efficient space utilization and storage.



Image 1.1: The EUGAD L-Shape Computer Desk in a typical setup.

2. SAFETY INFORMATION

- **Anchoring:** Always anchor the desk to a wall or floor to prevent accidental tipping, especially if children or pets are present.
- **Weight Limit:** Do not place objects exceeding 20 Kilograms (44 lbs) on the desk. Overloading can compromise stability and cause damage or injury.
- **Assembly:** Ensure all fasteners are securely tightened during assembly. Periodically check and re-tighten as needed.
- **Placement:** Place the desk on a flat, stable surface. Avoid uneven floors that could cause wobbling.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- L-shaped desktop panels (Light Oak MDF)
- Shelf panels (Light Oak MDF)
- Metal frame components (Black Alloy Steel)
- Height-adjustable anti-scratch feet
- Assembly hardware (screws, bolts, washers, nuts)
- Assembly tools (e.g., Allen key)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is straightforward and typically requires one person. Follow the step-by-step instructions provided in the included assembly guide. It is recommended to assemble the desk in the room where it will be used.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your assembly guide to identify each component.
3. **Assemble Frame:** Connect the metal frame components using the provided hardware. Ensure all connections are finger-tightened initially.
4. **Attach Shelves:** Secure the shelf panels to the designated frame sections.
5. **Attach Desktop:** Place the L-shaped desktop panels onto the assembled frame and secure them with the remaining hardware.
6. **Tighten All Fasteners:** Once all parts are in place, fully tighten all screws and bolts using the provided tools. Do not overtighten.
7. **Attach Feet:** Screw the height-adjustable anti-scratch feet into the bottom of the desk legs. Adjust them to ensure the desk is level and stable.



Image 4.1: Detailed views of desk features and connections.

5. OPERATING INSTRUCTIONS (USAGE)

The EUGAD L-Shape Computer Desk is designed for versatile use as a computer desk, study desk, writing desk, or general office workstation. Its L-shape allows for efficient placement in corners, maximizing your workspace.

- **Workspace:** Utilize the expansive L-shaped surface for multiple monitors, laptops, and other work essentials.
- **Storage:** The integrated shelves provide convenient storage for books, documents, office supplies, or a computer tower.
- **Adjustable Feet:** Use the adjustable feet to fine-tune the desk's height and ensure stability on uneven floors.



Image 5.1: The desk configured for computer use with items on shelves.

6. MAINTENANCE

Proper care will extend the life and appearance of your desk.

- **Cleaning:** Wipe the tabletop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. The tabletop is waterproof and scratch-resistant for easy cleaning.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration of the wood finish.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat damage to the desktop surface.

7. TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common solutions:

- **Desk is Wobbly:**
 - Ensure all assembly screws and bolts are fully tightened.
 - Adjust the height-adjustable feet on each leg to compensate for uneven flooring.
- **Missing Parts:**
 - Double-check all packaging materials. If parts are genuinely missing, contact EUGAD customer support with your model number and a description of the missing parts.
- **Scratches on Surface:**
 - While the tabletop is scratch-resistant, minor scratches can occur. For deeper scratches, consider using a furniture repair kit matching the light oak finish.

8. SPECIFICATIONS

Feature	Detail
Model Number	4054908205520
Dimensions (L x W x H)	120 x 74 x 71.5 cm
Tabletop Material	Engineered Wood (MDF)
Frame Material	Alloy Steel
Tabletop Color	Light Oak
Frame Color	Black
Item Weight	15.5 Kilograms
Maximum Weight Recommendation	20 Kilograms
Number of Shelves	1 (with two tiers)
Special Features	Adjustable feet, L-Shape design, Integrated shelves




Image 8.1: Dimensional diagram of the EUGAD L-Shape Computer Desk.

9. WARRANTY INFORMATION

This EUGAD L-Shape Computer Desk comes with a Limited Warranty. For specific details regarding coverage, duration, and terms, please refer to the warranty documentation included with your purchase or contact EUGAD customer support.

10. CUSTOMER SUPPORT

For further assistance, missing parts, or warranty claims, please contact EUGAD customer support. Have your model number (4054908205520) and purchase information ready when contacting support.

You can typically find contact information on the EUGAD official website or through the retailer where the product was purchased.

© 2024 EUGAD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question