

[Manuals.plus](#) /

› [WISE HEDGEHOG](#) /

› WISE HEDGEHOG Learning Clock Instruction Manual

WISE HEDGEHOG B07ZKMLMVP

WISE HEDGEHOG Learning Clock

Model: B07ZKMLMVP

INTRODUCTION

The WISE HEDGEHOG Learning Clock is an educational analog wall clock designed to assist children in learning how to tell time effectively. Its clear, colorful, and intuitive design simplifies the complex concept of time for young learners. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your learning clock.



Image: The WISE HEDGEHOG Learning Clock, featuring a white face with large, colorful numbers for hours and smaller numbers for minutes, along with clearly labeled hour and minute hands.



Silent, Will Not Keep Your Child Awake at Night or Distract Learning



Image: A child engaged in drawing, with the WISE HEDGEHOG Learning Clock visible in the background, illustrating its silent operation that does not distract from learning.

SETUP

Battery Installation

The WISE HEDGEHOG Learning Clock requires one (1) AA battery for operation. The battery is not included with the product.

1. Locate the battery compartment on the back of the clock.
2. Remove the battery compartment cover.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover securely.

Mounting the Clock

The clock is lightweight and designed for easy hanging. It can be placed in classrooms, playrooms, or children's bedrooms.

- Choose a suitable location on a wall where the clock will be easily visible to the child.

- Use an appropriate wall hook or nail (not included) to hang the clock securely. Ensure the hook is strong enough to support the clock's weight.

OPERATING INSTRUCTIONS

Setting the Time

To set the time, use the small dial located on the back of the clock mechanism. Rotate the dial clockwise or counter-clockwise until the hour and minute hands display the correct time.

Learning to Tell Time

The WISE HEDGEHOG Learning Clock is designed with several features to facilitate time-telling education:

- **Color-Coded Numbers:** The clock face features large, colorful numbers for hours (1-12) and smaller, corresponding numbers for minutes (00-59), making it easy to distinguish between them.
- **Labeled Hands:** The hour hand is clearly labeled "HOUR" and the minute hand is labeled "MINUTE" to help children identify their functions.
- **Quarter and Half Past Markings:** Phrases like "O'clock", "Quarter Past", "Half Past", and "Quarter To" are printed on the clock face to aid in understanding common time phrases.
- **Silent Sweep Movement:** The clock operates with a continuous sweep movement, ensuring no distracting ticking sounds, which is ideal for learning environments and bedrooms.



Completely Silent Non Ticking Kids Clock

Image: A teacher demonstrating the WISE HEDGEHOG Learning Clock to a group of attentive children, highlighting its use in an educational setting.

Included Ebook

Your purchase includes a free downloadable ebook titled "Guide to Teaching Kids How to Tell the Time". This resource

provides additional guidance and methods for parents and teachers to effectively teach time-telling skills.



Image: A tablet screen displaying the cover and content of the included downloadable ebook, 'Guide to Teaching Kids How to Tell the Time', which offers further educational support.

MAINTENANCE

Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the clock face or frame.

Battery Replacement

Replace the AA battery when the clock hands begin to slow down or stop moving. Follow the battery installation steps outlined in the Setup section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock is not moving or is running slow.	Battery is low or depleted.	Replace the AA battery with a new one. Ensure correct polarity.

Problem	Possible Cause	Solution
Clock is making a ticking sound (should be silent).	Internal mechanism issue or defect.	While the clock is designed to be silent, if a ticking sound develops, it may indicate a manufacturing defect. Contact customer support for assistance.
Hands are loose or misaligned.	Impact or rough handling.	Gently try to realign the hands by carefully rotating the setting dial on the back. If the issue persists or hands are visibly damaged, contact customer support.

SPECIFICATIONS

- **Product Dimensions:** 15.75 x 1.5 x 15.75 inches
- **Item Weight:** 1.06 pounds
- **ASIN:** B07ZKMLMVP
- **Batteries:** 1 AA battery required (not included)
- **Manufacturer:** Wise Hedgehog

WARRANTY AND SUPPORT

The WISE HEDGEHOG Learning Clock is sold by SimplyZenith and fulfilled by Amazon. For any product-related inquiries, issues, or support needs, please contact the seller directly through your Amazon order history. Amazon's standard return policy typically allows for returns or replacements within 30 days of receipt. For further assistance, you may visit the [WISE HEDGEHOG Store on Amazon](#).