Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > CHUNGHOP /
- > CHUNGHOP URK-01 Universal Remote Control for Roku Streaming Players User Manual

CHUNGHOP URK-01

CHUNGHOP URK-01 Universal Remote Control for Roku Streaming Players User Manual

Model: URK-01

Introduction Compatibility Setup Programming Learning
Keys Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the CHUNGHOP URK-01 Universal Remote Control. This remote is designed to enhance your Roku streaming experience by providing dedicated Roku controls and 12 programmable learning keys for other devices like your TV, soundbar, or receiver. Please read this manual carefully to ensure proper setup and operation.

Package Contents:

- 1 x CHUNGHOP URK-01 Universal Remote Control
- 1 x User Manual







Image: Front, side, and back views of the CHUNGHOP URK-01 Universal Remote Control. The front shows various buttons including power, navigation, volume, channel, and dedicated streaming service buttons. The back shows the battery compartment cover.

2. COMPATIBILITY

The CHUNGHOP URK-01 Universal Remote Control is compatible with a range of Roku streaming players and features a learning function for IR-enabled remote controls.

Compatible Roku Devices:

- Roku 1
- Roku 2
- Roku 4
- Roku Premier+
- Roku Express+
- Roku Ultra

Not Compatible With:

- Roku Sticks
- Roku TV (integrated Roku functionality in smart TVs)

• RF, IP, Bluetooth, or Wi-Fi only remotes (for learning function)



Image: A visual representation of compatible and incompatible Roku devices. On the left, several Roku streaming boxes are shown with a green checkmark, indicating compatibility. On the right, Roku Sticks and Roku TVs are shown with a red 'X', indicating incompatibility.

3. SETUP

3.1 Battery Installation

- 1. Open the battery compartment cover on the back of the remote control.
- 2. Insert two (2) AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
- 3. Close the battery compartment cover securely.






Image: The back of the CHUNGHOP URK-01 remote control with the battery cover removed, showing the slots for two AAA batteries and their polarity markings.

4. Programming Learning Keys

The URK-01 remote features 12 programmable keys (located in the top section) that can learn functions from your original IR remote controls for devices such as your TV, soundbar, or receiver. This allows you to consolidate frequently used functions onto one remote.



Image: A diagram of the CHUNGHOP URK-01 remote control, clearly labeling the top section as the 'Programming Section' (requiring an original TV/Sound Bar/Receiver remote) and the lower section as the 'Universal Roku Remote Section' (compatible with Roku 1, 2, 3, 4, Roku Express & Express+, Roku Premiere & Premiere+, Roku Ultra).

4.1 Identifying Programmable Keys

The 12 programmable keys are located at the top of the remote, including the TV Power, Heart, Up Arrow, Mute, Rewind, OK, Fast Forward, A, V, and B buttons. These keys are designed to learn functions from other IR remotes.



Image: A close-up view of the CHUNGHOP URK-01 remote control, with a magnified inset highlighting the 12 programmable keys. These keys are labeled 'TV', 'Heart', 'Up Arrow', 'Mute', 'Rewind', 'OK', 'Fast Forward', 'A', 'V', 'B', and two other directional keys.

4.2 Programming Steps

To program a learning key, you will need your original remote control for the device you wish to control (e.g., TV, soundbar). Ensure the original remote is functional and has fresh batteries.

- 1. Press and hold the **POWER** and **MUTE** buttons on the URK-01 remote simultaneously for approximately 3 seconds until the red LED indicator light turns on. Then release both buttons.
- 2. Press the specific key on the URK-01 remote that you wish to program (e.g., TV Power button). The red LED will flash rapidly, indicating it is ready to learn.
- 3. Place the URK-01 remote and your original remote control head-to-head, approximately 1 inch apart.
- 4. Press and hold the corresponding key on your original remote control (e.g., the Power button of your TV remote) until the red LED on the URK-01 remote turns solid, indicating successful learning.

- 5. Repeat steps 2-4 for any other keys you wish to program.
- 6. To exit programming mode, press the **POWER** and **MUTE** buttons on the URK-01 remote simultaneously for approximately 3 seconds. The red LED will turn off.



Image: A visual guide demonstrating how to program the CHUNGHOP URK-01 remote. It shows the URK-01 remote and an original remote facing each other, with infrared signals being transferred during the learning process.

Video: The Programming Steps for URK-01

Video: This video demonstrates the step-by-step process of programming the learning keys on the CHUNGHOP URK-01 Universal Remote Control. It visually guides the user through entering programming mode, selecting a key to learn, positioning the remotes, and confirming successful learning.

5. OPERATING INSTRUCTIONS

5.1 Roku Control Section

The lower section of the URK-01 remote is pre-programmed for compatible Roku streaming players. Simply point the remote at your Roku device and use the navigation, playback, and volume controls as you would with your original Roku remote.

5.2 Dedicated Shortcut Keys

The remote includes six dedicated shortcut keys for popular streaming services:

- Amazon
- NETFLIX
- Vudu
- PANDORA
- YouTube
- CRACKLE

Pressing these buttons will directly launch the corresponding application on your Roku streaming player, provided the app is installed and configured.



Image: A close-up view of the CHUNGHOP URK-01 remote control, with an inset highlighting the six dedicated shortcut buttons for Amazon, NETFLIX, Vudu, PANDORA, YouTube, and CRACKLE.

6. MAINTENANCE

6.1 Battery Replacement

When the remote's performance degrades or the LED indicator light does not respond, it is time to replace the batteries. Always replace both AAA batteries with new ones. Do not mix old and new batteries, or different types of batteries.

6.2 Cleaning

To clean the remote, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's surface or internal components.

7. TROUBLESHOOTING

• Remote not responding to Roku device:

Ensure the remote has fresh batteries. Verify line-of-sight between the remote and the Roku device. Confirm your Roku device is one of the compatible models (not a Roku Stick or Roku TV).

· Learning keys not programming:

Ensure your original remote is functional and has fresh batteries. Make sure the remotes are placed head-to-head, about 1 inch apart. Hold the original remote's button down until the URK-01's LED turns solid. If the signal light flashes but learning fails, try new batteries in the URK-01.

· Shortcut keys not working:

Ensure your Roku streaming player is powered on and connected to the internet. Verify that the corresponding streaming application is installed and logged in on your Roku device.

• LED indicator not lighting up:

Check battery installation and replace with new batteries if necessary.

8. Specifications

Brand	CHUNGHOP
Model Number	URK-01 (Item Model Number: 7731000173205)
Compatible Devices	Roku Streaming Player (Roku 1, 2, 4, Premier+, Express+, Ultra)
Max Number of Supported Devices	1 (Roku section) + Learning Keys for other IR devices
Special Feature	Universal, 12 Learning Keys
Power Source	2 x AAA Batteries (not included)
Item Weight	2.08 ounces
Package Dimensions	7.05 x 3.39 x 1.1 inches

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact CHUNGHOP customer service directly. Contact details can typically be found on the manufacturer's website or through your point of purchase.

Related Documents - URK-01



<u>Chunghop K-2018E Универсальный Пульт Дистанционного Управления - Руководство</u> <u>Пользователя</u>

Подробное руководство пользователя для универсального пульта дистанционного управления Chunghop K-2018E. Инструкции по настройке, использованию дополнительных функций, гарантии и утилизации.



CHUNGHOP K-2098E Universal A/C Remote Operating Instructions

This document provides operating instructions for the CHUNGHOP K-2098E Universal A/C Remote. It details setup methods, additional functions, and a comprehensive code table for compatibility with various air conditioner brands.



Chunghop RM-L988 Universal Remote Controller User Manual

Comprehensive user manual for the Chunghop RM-L988 Eleven-in-one Universal Remote Controller, detailing setup, functions, and code lists for various home appliances.



CHUNGHOP K-1028E Universal Air Conditioner Remote Control User Manual

User manual for the CHUNGHOP K-1028E universal air conditioner remote control. Learn setup, features, and compatibility with various AC brands.



Univerzális klíma távirányító UT-002 Használati és Kezelési Útmutató

Ez a dokumentum az Univerzális klíma távirányító (UT-002) használati és kezelési útmutatója. Tartalmazza a biztonsági előírásokat, specifikációkat, használati utasításokat, ápolási és tisztítási útmutatókat, valamint a leselejtezési információkat.



CHUNGHOP Q-988E Universal Air Conditioner Remote Control User Manual

User's manual for the CHUNGHOP Q-988E universal air conditioner remote control. Learn about product introduction, panel description, battery installation, and setting up the remote using digital auto-search or manual code input for various brands.