Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GuliKit NS07--Blue

GuliKit Route Air NS07 Bluetooth Audio Adapter User Manual

Model: NS07--Blue

Introduction

The GuliKit Route Air NS07 is a compact and efficient Bluetooth audio adapter designed specifically for the Nintendo Switch and Switch Lite. It allows users to connect their favorite Bluetooth headphones or speakers for a wireless audio experience, enhancing gaming immersion without the need for cables. This adapter features ultra-low latency aptX technology for real-time audio synchronization and supports simultaneous connection to two Bluetooth devices, making it ideal for shared gaming experiences.

Product Overview

The GuliKit Route Air NS07 is a slim, blue-colored adapter that plugs directly into the USB-C port of your Nintendo Switch console. It features two pairing buttons, labeled A and B, and LED indicators for connection status.



Image: The GuliKit Route Air NS07 Bluetooth adapter shown connected to a Nintendo Switch Lite, illustrating its compact design and how it integrates with the console. Also depicted are the included joystick grips.

Key Features:

- **Bluetooth Audio Transmitter:** Designed for Nintendo Switch, PS4, PC, and compatible with Bluetooth headphones and speakers.
- **Dual Device Support:** Pair and stream audio to two Bluetooth headphones/speakers simultaneously.
- **Ultra-Low Latency:** Utilizes aptX Low Latency technology to minimize audio delay for a seamless gaming experience.
- **Battery-Free Operation:** Powered directly by the console via its USB-C port, supporting pass-through charging.
- **Easy to Use:** Plug and Play functionality with quick pairing.




Image: A close-up side view of the GuliKit Route Air NS07 adapter, highlighting its ultra-slim profile of just 5mm, designed to be unobtrusive when connected to the console.

Setup Instructions

1. **Prepare Your Console:** Ensure your Nintendo Switch or Switch Lite is powered on.
2. **Insert the Adapter:** Gently insert the GuliKit Route Air NS07 adapter into the USB-C port at the bottom of your Switch console.



Image: The GuliKit Route Air NS07 adapter correctly inserted into the USB-C port of a Nintendo Switch Lite. A note advises to remove any protective case to ensure full insertion and proper function.

Important: *If you are using a protective case on your Switch, please remove it before inserting the adapter to ensure a secure and full connection.*

3. **Prepare Your Bluetooth Device:** Set your Bluetooth headphones or speakers to pairing mode. Refer to your device's manual for specific instructions on how to enter pairing mode (usually indicated by a blinking LED).
4. **Pairing the Adapter:**
    - Once the adapter is inserted, hold down either the "A" or "B" pairing button on the GuliKit Route Air NS07 for 4 seconds.
    - The white LED indicator on the adapter will begin to blink, indicating it is in pairing mode.
5. **Connection Confirmation:** Once pairing is successful, the LED on the adapter will turn to a constant white light. You should now hear audio from your Switch through your Bluetooth device.



Image: The GuliKit Route Air NS07 adapter shown with a pair of wireless earphones, illustrating its compatibility with various Bluetooth versions (5.0, 4.0, 3.0, 2.1) and its ability to connect to a wide range of wireless audio devices.

Operating Instructions

Connecting a Second Bluetooth Device:

The GuliKit Route Air NS07 supports connecting two Bluetooth audio devices simultaneously, allowing for shared audio experiences.

1. Ensure your first Bluetooth device is already connected and working.
2. Set your second Bluetooth headphones or speakers to pairing mode.
3. Press and hold the *other* pairing button (if you used A for the first device, use B for the second, or vice-versa) on the GuliKit Route Air NS07 for 4 seconds.
4. The LED will blink, indicating pairing mode. Once connected, the LED will become solid. Both devices will now receive audio from your Switch.



Image: A Nintendo Switch Lite with the GuliKit Route Air NS07 adapter connected, illustrating the benefit of real-time audio synchronization provided by aptX Low Latency technology for an enhanced gaming experience.

Pass-Through Charging:

The adapter is designed with a USB-C PD pass-through charging port. This allows you to charge your Nintendo Switch console while the GuliKit Route Air NS07 adapter is connected and in use. Simply plug your Switch charger into the USB-C port on the adapter.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the adapter or subjecting it to strong impacts. Do not attempt to disassemble the device.

Troubleshooting

No Audio / Cannot Connect:

- Ensure the adapter is fully inserted into the Switch's USB-C port. Remove any protective cases if necessary.
- Confirm your Bluetooth headphones/speakers are in pairing mode and are not connected to another device.
- Try restarting your Switch console and then re-attempt the pairing process.
- Ensure the volume on both your Switch and your Bluetooth device is turned up.

Audio Lag / Delay:

- While the adapter uses aptX Low Latency, some lag can occur depending on the Bluetooth device. Ensure your headphones/speakers also support aptX Low Latency for optimal performance.
- Reduce the distance between the adapter and your Bluetooth device.
- Minimize interference from other wireless devices (e.g., Wi-Fi routers, other Bluetooth devices).
- Try re-pairing the device.

Microphone Not Working (if applicable to your headphones):

- The GuliKit Route Air NS07 is primarily an audio *transmitter*. While some Bluetooth headphones have built-in microphones, the adapter's primary function is outputting audio from the Switch. Microphone functionality may vary or not be supported for all setups.
- Check if your headphones' microphone works with other devices to rule out a headphone issue.

Specifications

Brand:	GuliKit
Model Number:	NS07--Blue
Connectivity Technology:	Bluetooth, USB
Wireless Communication Standard:	Bluetooth 5.0 (backward compatible with 4.0, 3.0, 2.1)
Audio Codec:	aptX Low Latency
Compatible Devices:	Nintendo Switch, Switch Lite, PS4, PC, Bluetooth Headphones, Bluetooth Speakers
Connector Type:	USB Type C
Color:	Blue
Item Dimensions (L x W x H):	3.12 x 3.12 x 0.96 inches (approx.)
Item Weight:	1.48 ounces (approx.)

Warranty and Support

GuliKit products are designed for reliability and performance. For specific warranty information, please refer to the documentation included with your purchase or visit the official GuliKit website.
For further assistance, technical support, or frequently asked questions, please visit theGuliKit Store on Amazon or their official support channels.

© 2023 GuliKit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZNHP7WC

More documents and user manuals: **https://manuals.plus/**