Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHOUBENBEN HA-DAN-03

CHOUBENBEN Replacement Remote Control HA-DAN-03 Instruction Manual

For Danby Portable Air Conditioner Models

1. Introduction

This manual provides instructions for the CHOUBENBEN HA-DAN-03 replacement remote control, designed for use with specific Danby Portable Air Conditioner models. This remote control is a direct replacement and does not require programming. Please read this manual thoroughly before use to ensure proper operation.

2. Setup: Battery Installation

The remote control requires two AAA 1.5V batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the battery insertion points for two AAA 1.5V batteries.

3. Operating Instructions

This remote control operates without any prior programming. Once batteries are installed, it is ready for use with compatible Danby Portable Air Conditioners. Ensure there is a clear line of sight between the remote control and the air conditioner's infrared receiver.

Remote Control Layout and Button Functions


ON/OFF
FAN
MODE
SWING
TIMER
SLEEP
℃/°F
HA-DAN-03

Image: Front view of the remote control, displaying the LCD screen and all control buttons.

- **ON/OFF Button:** Powers the air conditioner on or off.
- **Temperature Adjustment Buttons (Up/Down Triangles):** Adjusts the desired temperature setting.
- **Fan Button:** Cycles through fan speed settings (e.g., Low, Medium, High, Auto).
- **Mode Button:** Selects the operating mode (e.g., Cool, Dry, Fan, Heat).
- **Swing Button:** Activates or deactivates the air swing function.
- **Timer Button:** Sets the timer for automatic on/off operations.
- **Sleep Button:** Activates the sleep mode for comfortable nighttime operation.
- **°C/°F Button:** Toggles the temperature display between Celsius and Fahrenheit.

Special Features



Image: Close-up of the remote's upper section, highlighting the green ON/OFF button and the temperature adjustment buttons, which are designed to glow in the dark.

Noctilucent Buttons: The ON/OFF and temperature adjustment buttons are designed with a noctilucent (glow-in-the-dark) feature for easier visibility in low-light conditions.



Image: The remote control emitting a red light from its infrared transmitter, indicating a signal is being sent.

Signal Indicator Light: A red indicator light illuminates when a button is pressed, confirming that a signal is being transmitted from the remote control.

4. Compatibility

This CHOUBENBEN HA-DAN-03 remote control is compatible with the following Danby Portable Air Conditioner models:

- 810900129A
- DPA140HEAUBDB
- DPA100E1BDB
- DPA120E1WDB
- 810900128F
- DPA100E1WDB
- DPA120E1BDB
- DPA100EAUWDB
- DPA100EAUBDB

- DPA120EAUWDB
- DPA120EAUBDB
- DPA120HEAUBDB
- DPA140HEBUBDB
- DPA140HEAUWDB

Note: This is not a universal remote control. It is specifically designed for the listed Danby models. If your model is not listed, compatibility cannot be guaranteed.

5. Troubleshooting

If the remote control is not functioning as expected, consider the following:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA 1.5V batteries.
  - Check if the signal indicator light illuminates when a button is pressed. If not, batteries may be dead or incorrectly installed.
- **Air Conditioner Not Responding:**
  - Ensure there is a clear line of sight between the remote control and the air conditioner's infrared receiver. Obstructions can block the signal.
  - Verify that the air conditioner is powered on and plugged into a working electrical outlet.
  - Confirm that your air conditioner model is listed in the compatibility section (Section 4).

6. Maintenance

To ensure the longevity and proper functioning of your remote control:

- Keep the remote control clean by wiping it with a soft, dry cloth. Avoid using liquid cleaners.
- Do not expose the remote control to direct sunlight, high temperatures, or high humidity.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- Avoid dropping the remote control or subjecting it to strong impacts.

7. Specifications

Model:	HA-DAN-03
Brand:	CHOUBENBEN
Battery Type:	2 x AAA 1.5V (not included)
Connectivity:	Infrared (IR)
Compatibility:	Specific Danby Portable Air Conditioner models (see Section 4)

8. Support

For further assistance or inquiries regarding this replacement remote control, please contact the seller or manufacturer directly. Please have your product model (HA-DAN-03) and your Danby Air Conditioner model number ready when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZNSY4VD

More documents and user manuals: **https://manuals.plus/**