

Peg Perego Aria Shopper Twin Cinder (DASTA1CIND)

Peg Perego Aria Shopper Twin Stroller User Manual

Model: Aria Shopper Twin Cinder (DASTA1CIND)

1. INTRODUCTION

Thank you for choosing the Peg Perego Aria Shopper Twin Stroller. This manual provides essential information for the safe and proper use, assembly, maintenance, and care of your stroller. Please read this manual thoroughly before using the product and keep it for future reference.

The Peg Perego Aria Shopper Twin is a lightweight and compact stroller designed for two children, offering comfort and convenience for parents on the go. Its robust aluminum frame ensures durability while maintaining a manageable weight.

2. SAFETY INSTRUCTIONS

Always prioritize safety when using the stroller. Failure to follow these instructions could result in serious injury.

- Always use the 5-point safety harness to secure your children in the stroller. Ensure it is properly adjusted and fastened.
- Never leave children unattended in the stroller.
- Ensure all locking devices are engaged before use.
- Do not overload the stroller or the storage basket. Refer to the specifications for maximum weight limits.
- Be cautious when folding and unfolding the stroller to prevent finger entrapment. Keep children clear of moving parts.
- Always engage the brakes when the stroller is stationary.
- Do not use the stroller on stairs or escalators.
- Regularly inspect the stroller for loose parts, damaged components, or worn fabric. Discontinue use if any damage is found.
- This stroller is designed for children from birth up to a maximum weight specified in the specifications section.

3. PRODUCT FEATURES

The Peg Perego Aria Shopper Twin Stroller is equipped with several features designed for comfort, safety, and convenience:

- **Adjustable Backrest and Footrest:** Allows for multiple reclining positions, including a near-flat position suitable for newborns, and adjustable leg support for growing children.
- **5-Point Safety Harness:** Provides secure restraint for each child with quick-release buckles.

- **Large Mesh Storage Basket:** Offers ample space for essentials beneath the seats.
- **Lockable Front Swivel Wheels:** Enhances maneuverability and can be locked for stability on uneven terrain.
- **Wheel Suspension System:** Provides a smoother ride over various surfaces.
- **Viewing Window:** A net on the canopy allows parents to easily see their children.
- **Compact Fold:** Designed to fold easily and compactly for storage and transport.
- **Removable and Washable Cover:** For easy cleaning and hygiene.
- **Lightweight Aluminum Frame:** Ensures durability without excessive weight.

4. ASSEMBLY AND SETUP

Follow these steps to assemble your Peg Perego Aria Shopper Twin Stroller:

1. **Unfolding the Stroller:**

Place the folded stroller on a flat surface. Release the folding latch, typically located on the side of the frame. Lift the handle upwards until the frame clicks into place, indicating it is fully open and locked. Ensure all locking mechanisms are securely engaged before placing children in the stroller.



Image: Front view of the unfolded Peg Perego Aria Shopper Twin Stroller.

2. Attaching Wheels (if necessary):

Some models may require wheel attachment. Align the wheel axle with the corresponding slot on the stroller frame and push firmly until it clicks into place. Pull on the wheel to ensure it is securely attached.

3. Adjusting Canopies:

Extend the individual canopies over each seat to provide shade. The canopies may have multiple positions or extendable visors. Utilize the viewing window on the canopy to check on your children.



Image: Side view of the Peg Perego Aria Shopper Twin Stroller, showing the extended canopies and seat recline.

4. Installing the Storage Basket:

Ensure the mesh storage basket beneath the seats is properly attached to the frame's designated points. This basket is designed to hold light items and essentials.



Image: Rear view of the Peg Perego Aria Shopper Twin Stroller, showing the individual seat backs and the large storage basket.

5. OPERATING INSTRUCTIONS

5.1. Securing Your Child

- Place your child in the seat.
- Fasten the 5-point safety harness by inserting the buckle tongues into the buckle housing until they click.
- Adjust the shoulder straps and waist straps to ensure a snug fit without being too tight. The harness should be at or slightly above your child's shoulders.
- To release, press the button on the buckle housing.

5.2. Adjusting the Backrest and Footrest

- To recline the backrest, locate the recline mechanism (usually a lever or strap) behind the seat and adjust to the desired position.

- To adjust the footrest, locate the adjustment levers or buttons on the sides of the footrest and move it up or down.

5.3. Using the Brakes

- To engage the brakes, press down firmly on the brake pedal located near the rear wheels until the stroller is stationary.
- To release the brakes, lift the brake pedal upwards. Always ensure the brakes are fully engaged when parking the stroller.

5.4. Locking/Unlocking Front Wheels

- To lock the front swivel wheels for stability on rough terrain, push down the locking lever on each front wheel assembly.
- To unlock for greater maneuverability, lift the lever up.

5.5. Folding the Stroller

- Ensure both children are removed from the stroller and the storage basket is empty.
- Engage the brakes.
- Locate the folding mechanism (refer to specific instructions on the stroller frame, often a button and lever combination on the handle or side).
- Follow the steps to collapse the stroller until it locks into its folded position.



Image: Side view of the Peg Perego Aria Shopper Twin Stroller, demonstrating its compact folded dimensions.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life of your stroller.

- **Cleaning the Fabric:** The removable cover can be washed by hand. Use mild soap and cold water. Do not bleach or tumble dry. Air dry completely before reattaching.
- **Cleaning the Frame:** Wipe the frame with a damp cloth and mild soap. Dry thoroughly. Do not use abrasive cleaners.
- **Wheel Maintenance:** Periodically clean dirt and debris from the wheels and axles. Lubricate moving parts with a silicone-based lubricant if they become stiff.

- **Storage:** Store the stroller in a dry place, away from direct sunlight and extreme temperatures, to prevent fading and material degradation.
- **Regular Inspection:** Regularly check all screws, rivets, and fasteners to ensure they are tight. Inspect the harness, buckles, and fabric for any signs of wear or damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller difficult to fold/unfold	Folding mechanism obstructed or not fully released.	Ensure all items are removed from the stroller. Check for any fabric or debris obstructing the mechanism. Apply light lubricant to moving parts if necessary.
Wheels squeak or are stiff	Dirt/debris in wheel bearings; lack of lubrication.	Clean wheels and axles thoroughly. Apply a silicone-based lubricant to the moving parts of the wheels.
Brakes not holding securely	Brake mechanism dirty or misaligned.	Clean the brake mechanism. Ensure the brake pedal is fully engaged. If the problem persists, contact customer support.
Harness difficult to buckle/unbuckle	Debris in buckle; misaligned buckle tongues.	Inspect the buckle for any obstructions. Ensure buckle tongues are inserted correctly.

8. SPECIFICATIONS

- **Brand:** Peg Perego
- **Model:** Aria Shopper Twin Cinder
- **Model Number:** DASTA1CIND
- **Product Dimensions (Unfolded):** 77.5 x 77 x 101 cm (Length x Width x Height)
- **Product Dimensions (Folded):** 27.5 x 77 x 101 cm (Length x Width x Height)
- **Item Weight:** 8.3 kg
- **Frame Material:** Aluminum
- **Harness Type:** 5 Point
- **Target Gender:** Unisex
- **Age Range Description:** Baby
- **Color:** Grey

9. WARRANTY AND SUPPORT

Peg Perego products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Peg Perego website. Keep your proof of purchase for warranty claims.

For technical support, spare parts, or service inquiries, please contact Peg Perego customer service through their official website or the contact information provided in your product packaging. When contacting support, please have your model number (DASTA1CIND) and purchase date ready.



© 2023 Peg Perego. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.