

## Livex 42682-07

# Livex Lighting 42682-07 2 Light Bronze Wall Sconce Instruction Manual

Model: 42682-07

## INTRODUCTION

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your Livex Lighting 42682-07 2 Light Bronze Wall Sconce. This fixture is part of the elegant Estate collection, designed to complement traditional and transitional interiors in dining rooms, bedrooms, or vanities.

## IMPORTANT SAFETY INFORMATION

**WARNING:** Risk of electric shock. Turn off power at the circuit breaker or fuse box before installation or servicing. Consult a qualified electrician if you are unsure about the installation process.

- Always disconnect power before working on the fixture.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not exceed the maximum wattage specified for the bulbs (60 watts per bulb).
- This fixture is designed for indoor use only.
- Handle glass components (if any) with care to prevent breakage.
- Please check your local laws before purchasing and installing this product.

## PACKAGE CONTENTS

Carefully unpack your fixture and identify all components. Keep the packaging materials until you are sure all parts are present and the fixture is installed correctly.

- 1 x Livex Lighting 42682-07 2 Light Bronze Wall Sconce fixture
- 1 x Mounting Backplate (5" Dia x 0.75" Depth)
- 2 x Candle Sleeves (for bulb holders)
- Hardware pack (screws, wire nuts, etc.)
- *Bulbs are not included.*



Figure 1: Livex Lighting 42682-07 2 Light Bronze Wall Sconce, showing its two candelabra-style light arms and circular backplate.

## SETUP AND INSTALLATION

Follow these steps to install your wall sconce. It is recommended to have a second person assist during installation.

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the wall outlet where you intend to install the sconce. Turn off the power completely. Verify power is off using a voltage tester.
2. **Prepare Mounting:** Remove the old fixture (if applicable). Attach the mounting backplate to the electrical junction box in the wall using the provided screws. Ensure it is securely fastened.
3. **Wire Connections:** Connect the fixture's wires to the corresponding house wires using the provided wire nuts.

- Connect the **black** (hot) wire from the fixture to the **black** (hot) wire from the junction box.
- Connect the **white** (neutral) wire from the fixture to the **white** (neutral) wire from the junction box.
- Connect the **green** or **bare copper** (ground) wire from the fixture to the **green** or **bare copper** (ground) wire from the junction box.

Ensure all connections are tight and no bare wire is exposed.

4. **Attach Fixture:** Carefully push the wired connections into the junction box. Align the fixture's backplate with the mounting screws on the mounting bracket and secure the fixture in place with the decorative nuts or screws.
5. **Install Candle Sleeves:** Place the provided candle sleeves over the bulb sockets.
6. **Install Bulbs:** Insert two candelabra (E12 base) bulbs, up to 60 watts each (not included), into the sockets.
7. **Restore Power:** Turn the power back on at the circuit breaker or fuse box. Test the fixture.



Figure 2: Dimensional drawing of the Livex Lighting 42682-07 Wall Sconce, indicating its width of 14 inches and height of 17.25 inches.

## OPERATING INSTRUCTIONS

Once installed, the Livex Lighting 42682-07 Wall Sconce operates via a standard wall switch connected to the electrical circuit. Simply toggle the wall switch to turn the light fixture on or off.

## MAINTENANCE

To maintain the appearance and longevity of your sconce, follow these simple maintenance guidelines:

- **Cleaning:** Dust the fixture regularly with a soft, dry cloth. For more thorough cleaning, wipe with a damp cloth using mild soap and water, then dry immediately. Avoid abrasive cleaners or solvents as they may damage the finish.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely before touching. Replace with candelabra (E12 base) bulbs, not exceeding 60 watts per bulb.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

TROUBLESHOOTING

If your sconce is not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker/fuse.
	Loose wire connections.	Turn off power, check all wire connections.
	Faulty bulb.	Replace bulb.
	Faulty wall switch.	Consult a qualified electrician.
Light flickers.	Loose bulb.	Tighten bulb.
	Loose wire connection.	Turn off power, check wire connections.
	Incorrect bulb type/wattage.	Ensure correct bulb type (E12) and wattage (max 60W).

SPECIFICATIONS

Brand	Livex Lighting
Model Number	42682-07
UPC	847284068933
Dimensions	14" W x 17.25" H
Weight	3 Pounds
Color/Finish	Bronze
Material	Alloy Steel
Style	Traditional
Light Fixture Form	Sconce
Number of Lights	2
Max Wattage per Bulb	60 watts
Voltage	120 Volts
Bulb Base	Candelabra (E12)
Installation Type	Wall Mount

Indoor/Outdoor Usage	Indoor
----------------------	--------

## WARRANTY AND SUPPORT

This Livex Lighting fixture comes with a **1-year manufacturer's warranty** from the date of purchase, covering defects in materials and workmanship under normal use.

For technical support, warranty claims, or additional product information, please visit the official Livex Lighting store or contact their customer service. You can find more information at the [Livex Lighting Brand Store on Amazon](#).



© 2024 Livex Lighting. All rights reserved.

Documents - Livex – 42682-07

no relevant documents