

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [XINJIA](#) /
- › [XINJIA Digital Quartz Watch User Manual - Model 2400017-001](#)

XINJIA 2400017-001

XINJIA Digital Quartz Watch User Manual

Model: 2400017-001 | Brand: XINJIA

INTRODUCTION

This manual provides detailed instructions for the XINJIA Digital Quartz Watch, Model 2400017-001. Please read this guide thoroughly to understand the watch's features, setup, operation, and maintenance. Proper use and care will ensure the longevity and optimal performance of your watch.



PROTECTION

≡ **XINJIA** ≡

MO TU WE TH FR

SA SU

AM

ALARM

6:06:54

• LIGHT
• MODE

• START
• RESET

WATER RESIST CF-422

1/100 SECOND

This image displays the XINJIA Digital Quartz Watch, featuring a black silicone strap and a clear rectangular digital display.

SETUP

Initial Time and Date Setting

Your XINJIA Digital Quartz Watch comes with a pre-installed battery. To set the time and date:

1. Press the **MODE** button (usually on the bottom left) repeatedly until the time display starts flashing.
2. Use the **SET** button (usually on the top right) to adjust the flashing digit (hours, minutes, seconds).
3. Press the **MODE** button again to move to the next setting (e.g., minutes, then month, day, year).
4. Once all settings are correct, press the **MODE** button one last time to exit the setting mode.

Strap Adjustment

The watch features a silicone strap with a buckle clasp. Adjust the strap by inserting the pin into the desired hole for a comfortable and secure fit on your wrist.

OPERATING INSTRUCTIONS

Time and Date Display

In normal mode, the watch displays the current time (hours, minutes, seconds). Press the **MODE** button once to cycle through different display modes, which may include date (month, day, year).

Alarm Function

To set the alarm:

1. Press the **MODE** button until the alarm setting screen appears (often indicated by 'AL' or a bell icon).
2. Use the **SET** button to adjust the alarm hour and minute.
3. Press **MODE** to confirm and exit.

To activate/deactivate the alarm, press the **SET** button while in the alarm display mode.

Stopwatch Function

To use the stopwatch:

1. Press the **MODE** button until the stopwatch screen appears (often indicated by 'ST' or 'STOP').
2. Press the **SET** button to start the stopwatch.
3. Press **SET** again to pause/resume.
4. To reset, press the **LIGHT** button (if available) while the stopwatch is paused.

Backlight

Press the **LIGHT** button (usually on the top left) to illuminate the display for a few seconds in low-light conditions.

MAINTENANCE

Cleaning

Wipe the watch case and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the plastic and silicone components.

Water Resistance

While the watch is designed for daily wear, specific water resistance ratings are not provided. Avoid prolonged

exposure to water, swimming, or showering to prevent internal damage.

Battery Replacement

The watch is powered by a quartz movement with one battery. When the display dims or functions become erratic, it may be time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and function.

TROUBLESHOOTING

- **Watch not displaying time:** Check if the battery needs replacement. Ensure no buttons are stuck.
- **Incorrect time/date:** Follow the 'Initial Time and Date Setting' instructions to reset.
- **Alarm not sounding:** Ensure the alarm is activated in the alarm setting mode. Check battery level.
- **Display is dim:** This usually indicates a low battery. Replace the battery.

If problems persist after attempting these solutions, contact customer support or a professional watch repair service.

SPECIFICATIONS

| | |
|-----------------------|-------------------|
| Brand | XINJIA |
| Model Number | 2400017-001 |
| Display Type | Digital |
| Movement Type | Quartz |
| Power Source | Battery Powered |
| Case Material | Plastic |
| Strap Material | Silicone |
| Clasp Type | Buckle |
| Case Diameter | 44 Millimeters |
| Case Thickness | 12.00 Millimeters |
| Band Width | 30 Millimeters |
| Band Length | 240 Millimeters |
| Item Weight | 54.43 Grams |

WARRANTY AND SUPPORT

Specific warranty information for the XINJIA Digital Quartz Watch, Model 2400017-001, is not provided in the product data. For details regarding warranty coverage, service, or technical support, please refer to the product packaging or contact the manufacturer directly.

