

Simba 253248000

Simba Hello Kitty Airplane Playset Instruction Manual

Model: 253248000

INTRODUCTION

This manual provides comprehensive instructions for the Simba Hello Kitty Airplane Playset. Please read this guide carefully before assembly and use to ensure proper operation and enjoyment of the product. This playset is designed to encourage imaginative play with Hello Kitty and her friends.

IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 4 years.

Always supervise children during play. Inspect all parts regularly for damage. Discard any broken or damaged parts immediately. Keep packaging materials away from children.

PACKAGE CONTENTS

Verify that all the following items are included in your package:

- 1 x Hello Kitty Airplane Playset (with opening roof)
- 3 x Non-articulated figures (Hello Kitty, Jodie, Fifi)
- 1 x Food service cart with trays
- Various food accessories (e.g., sandwiches, apples)
- 2 x Luggage pieces
- 1 x Laptop accessory
- 1 x Passport accessory (also functions as a notebook, 5x6.5cm)
- 1 x Camera accessory (functions as an ink stamp)
- Additional small accessories (e.g., cups, teapot)

SETUP AND INITIAL ASSEMBLY

1. **Unpack the Playset:** Carefully remove all components from the packaging. Ensure all plastic ties and protective materials are removed before play.
2. **Inspect Components:** Check all parts for any signs of damage or manufacturing defects. If any parts are damaged, do not proceed with assembly and contact customer support.
3. **Prepare the Airplane:** The airplane comes pre-assembled. No complex assembly is required.



Image 1: Overview of the Hello Kitty Airplane Playset and included accessories.

OPERATING INSTRUCTIONS

1. Opening the Airplane Roof

To access the interior play area of the airplane, gently lift the roof section. The roof is designed to open, revealing the cabin where figures and accessories can be placed.



Image 2: Demonstrates how to open the airplane's roof to access the interior.

2. Placing Figures and Accessories

The playset includes three non-articulated figures: Hello Kitty, Jodie, and Fifi. These figures can be placed inside the airplane cabin. Use the various accessories, such as the food cart, luggage, laptop, and passport, to create different travel scenarios.



Image 3: Figures and accessories arranged within the open airplane playset.



Image 4: The three included figures: Hello Kitty, Jodie, and Fifi.



Image 5: A selection of the detailed accessories, such as food, luggage, and a laptop.

3. Using Special Accessories

- **Passport:** The included passport accessory also functions as a small notebook (dimensions: 5x6.5cm) for creative play.
- **Camera:** The camera accessory doubles as an ink stamp, adding another interactive element to the playset.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the playset and accessories with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset and all its components in a clean, dry place away from direct sunlight and extreme temperatures to prevent damage and discoloration.
- **Inspection:** Periodically check all parts for wear and tear. Replace or discard any damaged components to ensure continued safe play.

TROUBLESHOOTING

- **Missing Parts:** If any parts are missing upon opening the package, please refer to the "Package Contents" section and contact customer support.
- **Difficulty Opening Roof:** Ensure no objects are obstructing the roof mechanism. Apply gentle, even pressure when opening. Do not force it.
- **Figures Not Fitting:** Ensure figures are placed correctly in their designated spots. The figures

are non-articulated and designed for specific seating positions.

SPECIFICATIONS

Product Model Number	253248000
Product Dimensions (L x W x H)	38.5 x 22.2 x 21 cm
Product Weight	0.78 grams
Manufacturer Recommended Age	4 - 10 years
Main Material	Plastic
Model Name	Hello Kitty - Airplane Playset
Cartoon Character	Hello Kitty
Color	Multi-colored

WARRANTY AND CUSTOMER SUPPORT

For any questions, concerns, or issues regarding your Simba Hello Kitty Airplane Playset, please contact the retailer or manufacturer's customer support. Please retain your proof of purchase for any warranty claims.

Manufacturer: Simba