Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > YA-MAN /
- > YA-MAN mysé Head Spa Lift for MEN Electric Scalp Massager MS-30G Instruction Manual

YA-MAN MS-30G

YA-MAN mysé Head Spa Lift for MEN Electric Scalp Massager

Model: MS-30G - Instruction Manual

1. Product Overview

The YA-MAN mysé Head Spa Lift for MEN (Model: MS-30G) is an electric scalp massager designed to provide a refreshing head spa experience. It features specialized attachments with hard materials tailored for men's firm muscles, offering comfortable stimulation for the scalp, face, neck, and shoulders. Its waterproof design (IPX7) allows for convenient use in the bath.



Image 1.1: Top view of the YA-MAN mysé Head Spa Lift for MEN device.

2. Product Components

The package includes the following items:

- Main Unit (YA-MAN mysé Head Spa Lift for MEN)
- Head Attachment
- Kneading Attachment

- · Charging Stand
- Instruction Manual (this document)



Image 2.1: All included components: main unit, head attachment, kneading attachment, and charging stand with power adapter.

3. Setup

3.1. Charging the Device

- 1. Connect the charging stand to a power outlet using the provided power adapter.
- 2. Place the main unit onto the charging stand. Ensure the charging contacts align properly.
- 3. The device will begin charging. A full charge typically takes approximately 3 hours.
- 4. Once fully charged, disconnect the device from the charging stand.

Note: The operating time after a full charge is approximately 20 minutes (at an ambient temperature of approximately 25°C). Charging and operating times may vary depending on battery level and charging environment.

3.2. Attaching/Detaching Attachments

- 1. To attach, align the desired attachment (Head or Kneading) with the main unit and press firmly until it clicks into place.
- 2. To detach, gently pull the attachment away from the main unit.



Image 3.1: Underside view with the standard head attachment.



Image 3.2: Underside view with the kneading attachment.

4. Operating Instructions

4.1. General Usage

- 1. Ensure the device is fully charged and the desired attachment is securely installed.
- 2. Press the power button to turn on the device.
- 3. Gently press the entire attachment vertically against the area you wish to treat (scalp, face, neck, or shoulders).

- 4. Move the device slowly across the skin, allowing the rotating heads to provide stimulation.
- 5. Adjust the intensity or mode if available (refer to specific model features).
- 6. After use, press the power button to turn off the device.

4.2. Specific Applications

- Scalp Care: Use the head attachment to gently massage the scalp, promoting thorough cleansing of pores, especially during shampooing due to its waterproof design.
- Face, Neck, and Shoulder Care: The kneading attachment can be used for these areas to provide a comfortable, stimulating massage.

5. Maintenance

5.1. Cleaning

- 1. After each use, especially if used with shampoo or other products, detach the attachment from the main unit.
- 2. Rinse both the attachment and the main unit under running water. Ensure no residue remains.
- 3. Wipe the device and attachments dry with a soft cloth.
- 4. Do not use alcohol, thinner, or abrasive cleaners, as these may damage the product.

5.2. Storage

- Store the device and its components in a cool, dry place, away from direct sunlight and high temperatures.
- · Keep out of reach of children.

6. Safety Warnings

- Immediately discontinue use if you experience pain, feel unwell, or notice any abnormalities on your scalp or skin.
- · Do not use on broken, irritated, or infected skin.
- Consult a doctor before use if you have any medical conditions, are pregnant, or have sensitive skin.
- Keep the device away from water sources when not in use, despite its waterproof rating, to prevent accidental damage to the charging stand or adapter.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.

7. Troubleshooting

- Device does not turn on: Ensure the device is fully charged. Check if the charging stand and adapter are
 properly connected to a power source.
- **Reduced performance:** Clean the attachments and the main unit thoroughly. Ensure the attachments are securely fitted. If the issue persists, the battery may need recharging.
- Unusual noise or vibration: Discontinue use immediately and contact customer support.

8. Specifications

Feature	Specification
Model Number	MS-30G

Manufacturer	YA-MAN
Product Dimensions (Main Unit)	Approx. W9.7 x D10.5 x H10.3 cm
Main Unit Weight	Approx. 287g (excluding attachments)
Materials (Main Unit)	ABS resin, Polycarbonate, Polyacetal
Materials (Attachments)	Silicone, Polycarbonate
Materials (Charging Stand)	ABS resin
Power Consumption	Approx. 3W (during charging)
Charging Time	Approx. 3 hours
Operating Time	Approx. 20 minutes (after full charge at 25°C)
Waterproof Rating	IPX7
Power Source	Rechargeable battery (Lithium-ion)
Color	Black

9. Warranty and Support

This product comes with a manufacturer's warranty. Please refer to the warranty card included in the packaging for details regarding coverage period and terms. For technical support, troubleshooting assistance, or warranty claims, please contact YA-MAN customer service through their official website or the contact information provided in your warranty documentation.

For further information, please visit the official YA-MAN website:www.ya-man.com

© 2023 YA-MAN. All rights reserved.

Related Documents - MS-30G



YAMAN VEDA Hyper Lift Brush PSM-200: Advanced Lift Care for Scalp, Face, and Body

Discover the YAMAN VEDA Hyper Lift Brush PSM-200, a versatile beauty device offering advanced lift care for the scalp, face, and body. Featuring EMS, Electrocurrent, Ion Cleansing, and Ion Introduction, it stimulates muscles and skin for a firmer, lifted appearance. Includes multiple attachments for comprehensive treatment.



YA-MAN ACETINO SMART IB-7 Facial and Body Massager User Manual

User manual for the YA-MAN ACETINO SMART IB-7, a home-use beauty device for facial and body treatments. Includes safety precautions, operating instructions, maintenance, and after-sales service information.



YA-MAN YJMF4 Blue Green Mask Lift User Manual

Comprehensive user manual for the YA-MAN YJMF4 Blue Green Mask Lift, providing detailed instructions on usage, safety precautions, maintenance, and troubleshooting for this home-care beauty device.



YA-MAN Photo Plus Deep Lift YJFA1 User Manual

User manual for the YA-MAN Photo Plus Deep Lift YJFA1, a home beauty device featuring RF, Ion cleansing, Ion moisturizing, EMS, Photo (LED), microcurrent, and cool modes for facial care.



YA-MAN YJMF4 Blue Green Mask Lift User Manual

Comprehensive user manual for the YA-MAN YJMF4 Blue Green Mask Lift home-care beauty device, covering setup, usage instructions, safety precautions, troubleshooting, and product specifications.



YA-MAN Photo Plus Deep Lift YJFA1 User Manual - Home Care Beauty Device

Comprehensive user manual for the YA-MAN Photo Plus Deep Lift YJFA1, a home-care beauty device featuring RF, EMS, lontophoresis, LED, and Micro-current technologies for facial skin treatment.