PURPLE LEAF ZYLRRC0911-00

PURPLE LEAF 9' X 11' Grey Cantilever Patio Umbrella Instruction Manual

1. Introduction and Overview

This manual provides essential information for the safe and effective assembly, operation, and maintenance of your PURPLE LEAF 9' X 11' Grey Cantilever Patio Umbrella. Please read all instructions carefully before use.



Figure 1: The PURPLE LEAF 9' X 11' Grey Cantilever Patio Umbrella.

2. Safety Information

- Always close the umbrella during strong winds, heavy rain, or other severe weather conditions to prevent damage or injury.
- Ensure the umbrella base is adequately weighted and stable before opening the canopy. An unstable base can lead to tipping.
- Keep children and pets away from the umbrella during opening and closing operations.
- Do not hang objects from the umbrella frame or ribs.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.

3. Package Contents

Verify that all components are present before beginning assembly. The umbrella base and umbrella cover are sold separately and are not included with this product.

- Umbrella Canopy (Grey, 240 GSM Yarn-Dyed Polyester)
- Aluminum Frame and Pole
- 8 Heavy-Duty Aluminum Ribs with Powder Coating
- Crank Handle Mechanism
- Foot Pedal for 360° Rotation
- Assembly Hardware and Tools (may vary)



Figure 2: All components of the umbrella are designed for durability and ease of use.

4. Setup and Assembly

Assembly typically requires two adults. Follow the steps below for proper setup.

1. **Secure the Base:** Ensure your chosen umbrella base (sold separately) is properly filled and secured according to its own instructions. The umbrella pole must be firmly attached to a stable base.
2. **Attach the Main Pole:** Connect the main aluminum pole to the base. Ensure all bolts are tightened securely.
3. **Install the Canopy Frame:** Carefully attach the canopy frame to the main pole. The frame features heavy-duty aluminum construction and 8 powder-coated ribs for wind resistance.
4. **Unpack the Canopy:** Before opening, remove any packaging materials, such as Styrofoam or tape, that may be securing the ribs within the canopy.
5. **Initial Opening:** Use the crank handle to slowly open the umbrella canopy. Ensure all ribs extend smoothly without obstruction.



Figure 3: Heavy-duty aluminum structural support for enhanced wind resistance.



Figure 4: The aviation-grade aluminum pole is 35% thicker for superior stability.

5. Operating Instructions

5.1 Opening and Closing the Umbrella

The umbrella features a patented ergonomic easy-open handle for smooth operation.

- **To Open:** Turn the crank handle clockwise until the canopy is fully extended.
- **To Close:** Turn the crank handle counter-clockwise until the canopy is fully retracted. Secure the canopy with the integrated strap if available.



Figure 5: Ergonomic aluminum crank handle for easy operation.

5.2 Adjusting Tilt and Rotation

The umbrella offers hands-free 360° rotation and 6-position height/angle adjustments.

- **360° Rotation:** Step on the foot pedal located at the base to unlock the rotation mechanism. Rotate the umbrella to the desired position and release the pedal to lock it in place.
- **6-Position Adjustment:** Use the adjustment lever on the main pole to select one of the six available height and angle positions. Ensure the lever locks securely into place after adjustment.



Figure 6: Shockproof design with embedded springs protects ribs during operation.

6. Maintenance

- **Canopy Cleaning:** Hand wash the canopy with mild detergent and water. Allow it to air dry completely before closing or storing.
- **Frame Cleaning:** Wipe the aluminum frame with a dry or damp cloth. Avoid abrasive cleaners that could damage the powder coating.
- **Storage:** When not in use for extended periods, or during off-season, close the umbrella and cover it with a suitable umbrella cover (sold separately). Store in a dry, protected area.
- **Inspection:** Periodically check all bolts, screws, and moving parts to ensure they are tight and functioning correctly.



Figure 7: The high-density 240 GSM yarn-dyed polyester canopy is UV-resistant and water-repellent.

7. Troubleshooting

- **Umbrella will not open/close smoothly:** Check for any obstructions in the canopy or ribs. Ensure the crank mechanism is free of debris.
- **Umbrella feels unstable:** Verify that the base is properly weighted and secured. Ensure all connections between the pole and base are tight.
- **Canopy fading:** While the canopy is fade-resistant for up to 3 years, prolonged exposure to intense sunlight without a cover can accelerate fading. Use an umbrella cover when not in use.

8. Specifications

Model Name	ZYLRRC0911-00

Size	9' X 11'
Color	Grey
Canopy Material	240 GSM Yarn-Dyed Polyester
Frame Material	Alloy Steel, Aluminum
Special Features	Fade Resistant, Heavy Duty Fabric, UV Resistant, Vented, Waterproof, Windproof, Water Repellent
Opening Mechanism	Crank Lift
Umbrella Tilt Mechanism	Manual Tilt
UPC	611550864136




Figure 8: Product dimensions for the 9' X 11' Cantilever Patio Umbrella.

9. Warranty and Support

This PURPLE LEAF product comes with the following warranty:

- **Fabric:** 3 Years
- **Components:** 1 Year

For customer support or warranty claims, please contact the seller, PurpleLeafLeisureLife, through your purchase platform. Please have your model name (ZYLRRC0911-00) and UPC (611550864136) available.

10. Product Videos

No official product videos from the seller are available for embedding in this manual. For additional visual information, please refer to the product page where customer-submitted videos may be available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question