Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC HA-F17M-B-U

JVC HA-F17M In-Ear Headphones User Manual

Comprehensive guide for your JVC HA-F17M In-Ear Headphones, covering setup, operation, maintenance, and troubleshooting.

1. Product Overview

The JVC HA-F17M In-Ear Headphones are designed for comfortable listening with integrated controls and sweat resistance, making them suitable for daily use and light physical activity.

Key Features

- **Sweat-Resistant (IPX2):** Designed to withstand sweat, ideal for workouts and active lifestyles.
- **Integrated Microphone and Remote:** Allows for hands-free calls and convenient control of music playback (play/pause, skip tracks).
- **Comfortable Design:** Soft rubber housings ensure a comfortable fit for extended wear.
- **Clear Audio:** Equipped with 9mm dynamic drivers for crisp and detailed sound.
- **Sound Isolation:** The in-ear design provides good acoustic isolation, blocking external noise.
- **1-meter Cable:** Sufficient cable length for everyday use with a slim plug for broad device compatibility.

Package Contents

- JVC HA-F17M In-Ear Headphones
- Cable with iPhone compatible plug (3.5mm Jack)



Image: JVC HA-F17M In-Ear Headphones, showing the earbuds, inline remote, and 3.5mm audio jack.

2. Setup

Connecting to Your Device

1. Locate the 3.5mm audio jack on your smartphone, tablet, or audio player. This is typically a small circular port.
2. Insert the 3.5mm plug of the JVC HA-F17M headphones firmly into the audio jack of your device until it clicks into place.
3. Ensure the plug is fully inserted to prevent sound distortion or intermittent connection.
4. Adjust the volume on your device to a comfortable listening level before playing audio.



Image: A close-up view of the JVC HA-F17M earbud, highlighting its ergonomic design.

3. Operating Instructions

The JVC HA-F17M headphones feature a single-button inline remote control for easy management of audio playback and calls.

Basic Functions (Single Button Remote)

- **Play/Pause Music:** Press the button once to play or pause the current audio track.
- **Skip to Next Track:** Press the button twice quickly to skip to the next song.
- **Go to Previous Track:** Press the button three times quickly to go back to the beginning of the current track or to the previous track.
- **Answer/End Call:** When a call comes in, press the button once to answer. During a call, press the button once to end the call.
- **Reject Call:** Press and hold the button for approximately 2 seconds to reject an incoming call.

- **Activate Voice Assistant:** Press and hold the button for approximately 3 seconds to activate your device's voice assistant (e.g., Siri, Google Assistant).



Image: The inline remote control and microphone on the JVC HA-F17M headphones, used for managing calls and music.

4. Maintenance and Care

Proper care will extend the lifespan and maintain the performance of your JVC HA-F17M headphones.

Cleaning

- Gently wipe the earbuds and cable with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water and mild soap, then wipe and immediately dry.
- Do not use abrasive cleaners, alcohol, or solvents, as these can damage the surface.
- Ensure the 3.5mm plug is clean and free of debris before inserting it into your device.

Storage

- When not in use, store the headphones in a clean, dry place, away from extreme temperatures.

- Avoid tangling the cable by coiling it neatly.
- Do not store heavy objects on top of the headphones.

Sweat Resistance (IPX2)

The JVC HA-F17M headphones are rated IPX2, meaning they are protected against dripping water when tilted up to 15 degrees from the normal position. This makes them suitable for light exercise and protection against sweat. However, they are not designed for submersion in water or exposure to heavy rain. Always wipe off sweat after use to maintain their condition.

5. Troubleshooting

If you encounter issues with your headphones, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
No sound or low volume	Volume on device is too low or muted. Headphone plug not fully inserted. Incorrect audio output selected on device. Damaged cable or plug.	Increase device volume. Check if device is muted. Ensure the 3.5mm plug is fully inserted into the audio jack. Verify your device's audio settings to ensure output is directed to the headphones. Try the headphones with another device. If the issue persists, the cable or plug may be damaged.
Sound distortion or crackling	Loose connection. Audio source quality is poor. Damaged cable or earbud.	Re-insert the 3.5mm plug firmly. Try playing a different audio file or from a different source. Inspect the cable for visible damage. If damaged, replacement may be necessary.
Microphone not working	Microphone port blocked or dirty. Device settings for microphone input. Incompatible device.	Ensure the microphone on the inline remote is not covered and is clean. Check your device's privacy settings to ensure the application has permission to use the microphone. While compatible with most smartphones, some older devices may have limited microphone functionality.
Remote control not responding	Incompatible device or application. Damaged remote.	Some functions may not be supported by all devices or music players. Try with a different device or app. If the remote is physically damaged or unresponsive across multiple devices, it may require replacement.

6. Specifications

Feature	Detail
Model Name	HA-F17M-B-U
Brand	JVC
Color	Black
Ear Placement	In-Ear
Connectivity Technology	Wired (3.5mm Jack)

Feature	Detail
Driver Unit	9mm Dynamic Drivers
Frequency Response	10Hz - 20kHz
Impedance	16 Ohm
Microphone Form Factor	Integrated
Control Type	Media Control (Single Button)
Water Resistance Level	IPX2 (Sweat Resistant)
Cable Length	1 meter
Weight	20 g
Material	Plastic

7. Warranty and Support

JVC products are manufactured to high quality standards and are backed by a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official JVC website.

For technical support, product inquiries, or warranty claims, please contact JVC customer service or visit the official JVC brand store:

Visit JVC Brand Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZQL498V

More documents and user manuals: **https://manuals.plus/**