

Nerf E6596F01

NERF Ultra One Motorized Blaster Instruction Manual

Model: E6596F01

1. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before using the NERF Ultra One Motorized Blaster. Failure to follow these instructions may result in injury.

- **CAUTION:** Do not aim at eyes or face.
- **TO AVOID INJURY:** Use only with official NERF Ultra darts. Other darts may not meet safety standards. Do not modify darts or the dart blaster.
- **WARNING: CHOKING HAZARD** - Small parts may be generated. Not for children under 3 years.
- Eyewear is recommended (not included) for all users and bystanders.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- NERF Ultra One Blaster
- 25-Dart Drum
- 25 Official NERF Ultra Darts
- Instruction Manual (this document)



Image 2.1: NERF Ultra One Blaster with 25 darts and frustration-free packaging.

3. SETUP

3.1 Battery Installation

The NERF Ultra One Blaster requires 4x 1.5V C alkaline batteries (not included).

1. Locate the battery compartment on the blaster.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert four (4) C alkaline batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

3.2 Loading Darts

The blaster features a high-capacity 25-dart drum and onboard dart storage.

1. Ensure the blaster is powered off before loading darts.
2. Insert official NERF Ultra darts one by one into the openings of the 25-dart drum. Push each dart firmly until it is fully seated.
3. For quick access during play, additional darts can be stored in the onboard dart storage slots located on the blaster's stock.



Image 3.1: Darts correctly loaded into the blaster's drum.

4. OPERATING THE BLASTER

4.1 Powering On and Firing

The NERF Ultra One is a motorized blaster designed for rapid dart firing.

1. Hold the blaster firmly with both hands.
2. Press and hold the acceleration button (typically located on the underside of the handle) to power up the motor. You will hear the motor spin up.
3. While holding the acceleration button, pull the trigger to fire a dart. Release the trigger to stop firing.
4. To fire continuously, keep both the acceleration button and trigger pressed.



Image 4.1: Proper two-hand grip for operating the blaster.

4.2 Dart Compatibility

The NERF Ultra One Blaster is engineered to work exclusively with official NERF Ultra darts. Using other types of darts may cause the blaster to malfunction or jam, and could potentially damage the product.

5. MAINTENANCE

Proper care will extend the life of your NERF Ultra One Blaster.

- **Cleaning:** Wipe the blaster with a dry or slightly damp cloth. Do not submerge the blaster in water or use harsh chemicals.
- **Dart Care:** Keep darts clean and dry. Avoid bending or damaging darts, as this can affect performance and cause jams.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight. Remove batteries if the blaster will not be used for an extended period.

6. TROUBLESHOOTING

If you encounter issues with your NERF Ultra One Blaster, refer to the following common solutions:

Problem	Possible Cause	Solution
Blaster does not power on or motor is weak.	Low or dead batteries; incorrect battery installation.	Replace with fresh 1.5V C alkaline batteries. Ensure correct polarity.
Darts are not firing or are jamming.	Incorrect darts used; darts are damaged; darts not fully loaded; obstruction in barrel.	Ensure only official NERF Ultra darts are used. Replace damaged darts. Push darts fully into the drum. Check for and carefully remove any obstructions.
Darts are not flying as far as expected.	Darts are worn or damaged; motor not fully spun up; environmental factors.	Use new, undamaged NERF Ultra darts. Ensure the acceleration button is held down until the motor reaches full speed before firing.

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

- **Product Dimensions:** 3.25 x 23.25 x 11.5 inches
- **Item Weight:** 3.79 pounds
- **Model Number:** E6596F01
- **Manufacturer Recommended Age:** 8 years and up
- **Batteries Required:** 4 C alkaline batteries (not included)
- **Dart Capacity:** 25 darts (drum)
- **Dart Type:** Official NERF Ultra Darts only
- **Manufacturer:** Hasbro
- **Release Date:** March 1, 2020



8. WARRANTY AND SUPPORT





For warranty information or further assistance, please refer to the manufacturer's official website or contact their customer support directly. Keep your proof of purchase for any warranty claims.

You can visit the official Nerf Store for more products and information [Nerf Official Store](#)

© 2025 Nerf / Hasbro. All rights reserved.

Related Documents - E6596F01

	Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.
	Nerf Roblox Arsenal Pulse Laser Blaster Instructions Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.

	<p>Nerf Pro Stryfe X Dart Blaster: User Manual and Safety Instructions</p> <p>Comprehensive guide to operating the Nerf Pro Stryfe X Dart Blaster, including charging, loading, firing, safety warnings, and storage. Features detailed instructions for safe play and regulatory information.</p>
	<p>Nerf Rough Cut 2X4 Elite Blaster User Manual</p> <p>User manual for the Nerf Rough Cut 2X4 Elite Blaster, detailing its features, operation, and safety precautions. Includes instructions for loading, single fire, and slam fire modes.</p>
	<p>Nerf N-Strike Elite Strongarm Blaster: User Guide</p> <p>Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.</p>
	<p>Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions</p> <p>Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.</p>