

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [HOMCOM](#) /

> [HOMCOM Mid-Century Modern Accent Chair \(Model 833-695V80BG\) Instruction Manual](#)

HOMCOM 833-695V80BG

HOMCOM Mid-Century Modern Accent Chair (Model 833-695V80BG) Instruction Manual

Your guide to assembly, use, and care.

[Safety Information](#) [Parts List](#) [Assembly Instructions](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Operating Warranty & Support](#)

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Failure to follow these instructions may result in injury or damage.

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 352 lbs (160 kg).
- **Placement:** Place the chair on a flat, stable surface.
- **Heat and Sharp Objects:** Keep the chair away from direct heat sources and sharp objects to prevent damage to the upholstery and foam.
- **Children:** Always supervise children around the chair.
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Periodically check all fasteners to ensure they remain secure.

2. PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Chair Backrest (1)
- Chair Seat (1)
- Armrests (2)
- Eucalyptus Wood Legs (4)
- Hardware Pack (Bolts, Washers, Allen Wrench)



Image: The main components of the HOMCOM Mid-Century Modern Accent Chair, including the backrest, seat, armrests, and legs.

3. ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Legs:** Locate the four eucalyptus wood legs. Attach each leg to the designated corner of the chair seat frame using the provided bolts and washers. Ensure they are securely tightened with the Allen wrench.
3. **Connect Armrests:** Align the armrests with the sides of the chair seat. Secure them using the appropriate bolts from the hardware pack. Do not fully tighten yet.
4. **Attach Backrest:** Slide the chair backrest into the slots on the seat and armrests. Ensure all alignment points are correctly engaged. Secure the backrest to the seat and armrests using the remaining bolts.
5. **Final Tightening:** Once all components are in place, fully tighten all bolts. Do not overtighten.
6. **Place Cushion:** Place the seat cushion onto the chair.



Image: A diagram illustrating the dimensions of the assembled chair, useful for planning placement.

4. OPERATING INSTRUCTIONS

This accent chair is designed for comfortable seating in various indoor settings.

- **Seating:** Sit centrally on the seat cushion. The wide backrest and padded seat with spring pack and elastic band provide relaxation.
- **Placement:** Ideal for living rooms, bedrooms, or offices. Its mid-century modern design complements various decor styles.
- **Stability:** The solid wood frame and eucalyptus wood legs ensure stability. Avoid standing on the chair or using it as a step stool.

SKIN-FRIENDLY COMFORT



Image: A person comfortably seated in the accent chair, demonstrating its intended use for relaxation.

5. MAINTENANCE

Proper care will extend the life and appearance of your chair.

- **Cleaning:** Wipe clean with a damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the upholstery with a soft brush or vacuum with an upholstery attachment.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.
- **Inspections:** Periodically check all bolts and connections to ensure they are tight. Re-tighten if necessary.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair feels wobbly	Loose bolts or uneven floor.	Check and tighten all assembly bolts. Ensure the chair is on a level surface.

Problem	Possible Cause	Solution
Fabric appears stained	Spill or dirt accumulation.	Blot spills immediately with a clean, dry cloth. For stubborn stains, consult a professional upholstery cleaner.
Buttons are loose	Wear and tear.	Contact customer support for guidance on re-securing buttons or repair options.

7. SPECIFICATIONS

Feature	Detail
Brand	HOMCOM
Model Number	833-695V80BG
Color	Beige
Material	Polyester (Upholstery), Wood (Frame), Foam (Fill)
Overall Dimensions (D x W x H)	33.75" x 29.25" x 40.25" (85.7 cm x 74.3 cm x 102.2 cm)
Seat Dimensions (D x W)	20.75" x 19" (52.7 cm x 48.3 cm)
Seat to Floor Height	18.5" (47 cm)
Seat Back Interior Height	26.75" (67.9 cm)
Weight Capacity	352 lbs (160 kg)
Item Weight	41 lbs (18.6 kg)
Assembly Required	Yes

ATTRACTIVE OUTLOOK



Image: Detailed view of the chair's aesthetic features, including the wingback design, button tufting, rolled armrests, and turned legs.

8. WARRANTY & SUPPORT

For specific warranty information, please refer to the documentation included with your purchase or contact HOMCOM customer support directly.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact HOMCOM customer service. Contact details can typically be found on the product packaging or the official HOMCOM website.

Online Support: Visit the [HOMCOM Store on Amazon](#) for additional product information and support resources.