Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HAOBO Home 8814

HAOBO Home Upholstered Headboard User Manual

Model: 8814 | Brand: HAOBO Home

Introduction

Thank you for choosing the HAOBO Home Upholstered Headboard. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your new headboard. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The HAOBO Home Upholstered Headboard in Oatmeal1, Queen size, shown attached to a bed frame with bedding.

Important Safety Information

Please observe the following safety precautions to prevent injury or damage to the product.

- Do not overtighten screws during assembly. Overtightening can strip threads or damage components.
- Ensure all wall anchors (if applicable for wall-mount option) are suitable for your specific wall type. Consult a professional if unsure.
- Keep fingers clear of all mounting points and moving parts during assembly and adjustment to avoid pinching.
- Always assemble the headboard on a soft, clean surface to prevent scratches or damage to the fabric and frame.
- Verify all connections are secure before use.

Package Contents

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Headboard panels (upholstered)
- Left leg
- Right leg
- Hardware (allen wrench, screws, washers)
- Instruction manual (this document)



Image: Rear view of the headboard, illustrating the attachment points for the legs and bed frame.

Setup and Assembly

The HAOBO Home Upholstered Headboard is designed for easy assembly. It attaches to any standard Full and Queen size bed frame.

1. **Unpack Components:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Attach Legs to Headboard:** Align the pre-drilled holes on the left and right legs with the corresponding holes on the headboard panels. Secure them using the provided screws and washers with the allen wrench. Ensure the legs are oriented correctly for height adjustment.
3. **Connect to Bed Frame:** Position the assembled headboard against your bed frame. The legs feature 3 holes on each leg for easy and quick adjustments to accommodate Full and Queen sizes. Align the holes on the headboard legs with the mounting brackets on your bed frame.
4. **Secure Headboard:** Insert screws through the aligned holes and tighten them securely. Do not overtighten.
5. **Final Check:** Ensure the headboard is stable and securely attached to the bed frame before use.



Image: Detail of the headboard's upholstered fabric and vertical stitching, highlighting its elegant style.

Operation: Height Adjustment

This headboard offers adjustable height to accommodate various mattress heights and personal preferences.

- The headboard can be adjusted to heights ranging from 40 inches to 56 inches (from floor to top of headboard).
- To adjust the height, loosen the screws connecting the legs to the bed frame.
- Slide the headboard up or down to the desired height using the multiple pre-drilled holes on the legs.
- Once the desired height is achieved, re-tighten all screws firmly to ensure stability.



Image: A visual representation of the headboard's adjustable height feature, showing minimum and maximum height settings.

Maintenance

Proper care will extend the life and appearance of your upholstered headboard.

- **Cleaning:** Wipe the upholstered fabric with a dry cloth to remove dust and light debris. For spills, blot immediately with a clean, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the fabric.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Placement:** Avoid placing the headboard in direct sunlight for prolonged periods, as this may cause fading of the fabric.

Troubleshooting

This section addresses common issues you might encounter with your headboard.

Problem	Possible Cause	Solution
Headboard feels wobbly or unstable.	Screws are loose or not fully tightened.	Check and tighten all screws connecting the legs to the headboard and the headboard to the bed frame. Ensure proper alignment.
Cannot adjust height.	Screws are too tight, or obstruction.	Loosen the screws connecting the headboard to the bed frame. Ensure no fabric or debris is obstructing the adjustment mechanism.
Missing parts upon unboxing.	Packaging error or transit damage.	Refer to the "Package Contents" section and contact HAOBO Home customer support immediately for assistance.

Specifications

Detailed specifications for the HAOBO Home Upholstered Headboard.

Feature	Detail
Model Number	8814
Size	Queen (also compatible with Full size bed frames)
Color	Oatmeal1
Upholstery Fabric Type	Linen
Product Dimensions (W x H)	32.89"W x 24.8"H (Headboard panel only)
Adjustable Height Range (Floor to Top)	40 to 56 inches
Mounting Type	Bed Frame Mount (Wall Mount possible with additional hardware, not included)
Item Weight	27.7 pounds
Manufacturer	HAOBO HOME



Image: Technical drawing displaying the width, height, and adjustable height range of the Queen size headboard.

Warranty Information

The HAOBO Home Upholstered Headboard comes with a **Limited Warranty**. For specific terms and conditions, please refer to the warranty card included with your product or contact HAOBO Home customer support.

Customer Support

For any questions, missing parts, or assistance with assembly or operation, please contact HAOBO Home customer support. You

can find more information and contact details by visiting the official HAOBO Home Store on Amazon:

Visit HAOBO Home Store

Official Product Videos

No official product videos from the seller were found in the provided data that meet the embedding criteria (m3u8 format and 'Seller' creator type).

© 2025 HAOBO Home. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZRPL48D

More documents and user manuals: **https://manuals.plus/**