

360 360 S7

360 S7 Robot Vacuum Cleaner User Manual

Model: 360 S7 | Brand: 360

PRODUCT OVERVIEW

The 360 S7 Robot Vacuum Cleaner is an advanced robotic cleaning device designed to efficiently vacuum and mop various floor types. Equipped with smart navigation, powerful suction, and app control, it provides a comprehensive solution for maintaining clean living spaces.



Image: The 360 S7 Robot Vacuum Cleaner shown alongside its mobile application interface, demonstrating its smart capabilities and connectivity.

SETUP GUIDE

1. Unboxing and Initial Placement

Carefully remove all components from the packaging. Place the charging dock against a wall in an open area, ensuring there are no obstacles within 1 meter (3 feet) to the sides and 1.5 meters (5 feet) in front. Connect the power adapter to the charging dock and plug it into a power outlet.

2. Charging the Robot

Place the 360 S7 robot onto the charging dock. Ensure the charging contacts on the robot align with those on the dock. The indicator light on the robot will show charging status. For first use, fully charge the robot, which typically takes about 4-5 hours.

3. App Download and Connection

Download the "360 Robot" app from your mobile device's app store (iOS or Android). Open the app and follow the on-screen instructions to register an account and add your 360 S7 robot. This involves connecting the robot to your home Wi-Fi network. Ensure your Wi-Fi is 2.4GHz.

OPERATING YOUR 360 S7

Smart Navigation and Mapping

The 360 S7 utilizes LDS Lidar and SLAM algorithms for precise navigation and real-time mapping of your home. This allows the robot to plan efficient cleaning paths, avoid obstacles, and remember previously cleaned areas.



Image: An illustration showing the 360 S7 Robot Vacuum's smart navigation capabilities, including anti-collision, anti-drop, and long-lasting battery features, powered by LDS and SLAM technology.

Cleaning Modes and Suction Power

The 360 S7 offers 2-in-1 sweeping and mopping functionality. You can select various cleaning modes and adjust suction power via the app. The maximum suction power is 2650Pa for deep cleaning.




Image: The 360 S7 Robot Vacuum illustrating its dual function of sweeping and mopping, highlighting adjustable suction levels from quiet (600pa) to max (2650pa).

App Control and Voice Commands

Utilize the 360 Robot app to schedule cleanings, set virtual no-go zones, and monitor cleaning progress. The robot also supports voice commands through compatible devices like Amazon Alexa.

Set up off-limit areas via APP



Image: The 360 S7 Robot Vacuum operating in a room, with an overlay demonstrating how to set up off-limit areas using the mobile application.



Image: A couple interacting with the 360 S7 Robot Vacuum using voice commands, illustrating its compatibility with smart home assistants like Amazon Alexa.

Obstacle Avoidance and Mobility

The 360 S7 is designed with high passability and features anti-collision, anti-drop, and anti-stuck mechanisms to navigate your home safely and effectively.



Image: A four-panel image showcasing the 360 S7 Robot Vacuum's capabilities: high passability (clearing 3.9-inch obstacles), anti-collision, anti-drop (cliff detection), and anti-stuck features.

MAINTENANCE AND CARE

Regular maintenance ensures optimal performance and extends the lifespan of your 360 S7 Robot Vacuum Cleaner.

- **Dustbin and Filter:** Empty the dustbin after each cleaning cycle. Clean the filter regularly by tapping out debris or rinsing with water (ensure it's completely dry before reinserting).
- **Main Brush:** Remove and clean the main brush weekly. Use the cleaning tool provided to cut and remove tangled hair or debris.
- **Side Brushes:** Check side brushes monthly for wear and tear. Replace if bristles are bent or damaged. Clean any tangled hair.
- **Sensors:** Wipe all sensors (cliff sensors, wall sensors, charging contacts) with a clean, dry cloth monthly to ensure proper function.

- **Mop Pad:** Remove and wash the mop pad after each mopping session. Allow it to air dry completely.
- **Water Tank:** Empty any remaining water from the tank after mopping and allow it to air dry to prevent mold or odors.

TROUBLESHOOTING COMMON ISSUES

Problem	Possible Cause	Solution
Robot does not charge.	Charging contacts are dirty or misaligned. Power adapter not connected.	Clean charging contacts on both robot and dock. Ensure power adapter is securely plugged in.
Robot gets stuck frequently.	Obstacles in cleaning path. Sensors are dirty.	Clear cables, small objects, and thick rugs. Clean all sensors.
Suction power is weak.	Dustbin full. Filter clogged. Main brush tangled.	Empty dustbin. Clean or replace filter. Clean main brush.
Robot cannot connect to Wi-Fi.	Incorrect Wi-Fi password. Router too far. 5GHz Wi-Fi network.	Verify password. Move robot closer to router. Ensure 2.4GHz Wi-Fi is used.
Mopping function is ineffective.	Mop pad dry or dirty. Water tank empty.	Wet and clean mop pad. Fill water tank.

TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	360
Model Name	360 S7
Color	White
Battery Life	120 minutes
Voltage	110 Volts
Dustbin Capacity	0.57 Liters
Power Source	Corded Electric
Control Method	App




Feature	Detail
Compatible Devices	Amazon Echo
Item Weight	7.6 pounds
Product Dimensions	9.45 x 27.17 x 0.98 inches
Manufacturer	Qihoo 360
Included Components	Instruction Guide




WARRANTY INFORMATION AND SUPPORT

The 360 S7 Robot Vacuum Cleaner comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official 360 website. For technical support, troubleshooting assistance, or spare parts inquiries, please contact 360 customer service through the contact information provided in the app or on the official website. Please have your product model and serial number ready when contacting support.

© 2023 360. All rights reserved.

Related Documents - 360 S7

	<p>360 Robot Vacuum Cleaner S10 User Manual</p> <p>Comprehensive user manual for the 360 Robot Vacuum Cleaner, model S10. Provides safety instructions, product overview, detailed installation steps, operational guidance, and after-sales service information.</p>
	<p>360 S8 Series Robot Vacuum Cleaner User Manual</p> <p>User manual for the 360 S8 Series Robot Vacuum Cleaner, covering safety information, product overview, installation instructions, and after-sales service.</p>
	<p>360 S6 Robot Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the 360 S6 Robot Vacuum Cleaner, covering setup, operation, maintenance, troubleshooting, and specifications. Learn how to effectively use your intelligent cleaning robot.</p>

	<p>360 Robot Vacuum Cleaner P7 User Manual and Guide</p> <p>Comprehensive user manual for the 360 Robot Vacuum Cleaner P7, covering setup, operation, maintenance, and app control for efficient home cleaning.</p>
	<p>360 Pölynimurirobotin käyttöopas S8 Series</p> <p>Tämä käyttöopas tarjoaa kattavat ohjeet 360 S8 Series -pölynimurirobotin turvalliseen käyttöön, asennukseen, toimintoihin ja ylläpitoon. Se sisältää tietoa laitteen osista, teknisistä tiedoista, turvallisuusvaroituksista, takuusta ja EU-vaatimustenmukaisuudesta.</p>
	<p>360 S-sarjan Robotti-imurin Käyttöopas</p> <p>Kattava käyttöopas 360 S-sarjan robotti-imurille, joka kattaa turvallisuuden, asennuksen, käytön ja tekniset tiedot. Opi asentamaan ja käyttämään robotti-imuriasi tehokkaaseen kodin siivoukseen.</p>