

Linak Remotes Leggett Symmetry

Linak Remotes Leggett and Platt Symmetry Adjustable Bed Remote Replacement Instruction Manual

Model: Leggett Symmetry

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Linak Remotes Leggett and Platt Symmetry and Symmetry Zero Adjustable Bed Remote Replacement. This remote is specifically designed for the Symmetry and Symmetry Zero adjustable bed models. It is crucial to verify that the buttons on this replacement remote match your original remote exactly to ensure compatibility.

The remote control allows for precise adjustment of your adjustable bed's positions, enhancing comfort and usability. Please read these instructions carefully before attempting to set up or operate the remote.



Image 1: Front view of the Leggett and Platt Symmetry Adjustable Bed Remote Control. The remote is black with six circular buttons arranged in two columns of three. Each button features a white icon depicting a person in various reclining or elevated bed positions, indicating different bed adjustments.

2. SETUP AND PAIRING INSTRUCTIONS

2.1. Battery Installation

The remote control requires batteries for operation. Ensure you use the correct battery type as specified on the remote's battery compartment.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or unclip the cover to open the compartment.
3. Insert the required batteries, ensuring the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Replace the battery compartment cover, ensuring it is securely closed.

2.2. Remote Pairing/Syncing

After installing batteries, the remote must be paired with your adjustable bed's control box. The exact pairing procedure may vary slightly depending on your bed's specific control box model. The following is a general guide:

1. Ensure your adjustable bed is plugged into a working power outlet.
2. Locate the control box under your adjustable bed. This box typically has a small button, often labeled 'Pair', 'Sync', or 'Learn'.
3. Press and hold the 'Pair' or 'Sync' button on the control box for approximately 3-5 seconds. The indicator light on the control box may flash or change color, indicating it is in pairing mode.
4. While the control box is in pairing mode (usually within 10-30 seconds), press and hold any button on your new remote control for approximately 3-5 seconds.
5. Release the button on the remote. The indicator light on the control box should stop flashing or change to a solid color, confirming successful pairing.
6. Test the remote by pressing various function buttons to ensure the bed responds correctly.
7. If pairing is unsuccessful, repeat steps 3-5. If issues persist, refer to your adjustable bed's original manual for specific pairing instructions or contact customer support.

3. OPERATING THE REMOTE CONTROL

The remote control features six distinct buttons, each designed to adjust a specific section of your adjustable bed. Familiarize yourself with these functions for optimal use.

3.1. Button Functions

- **Top Left Button:** Elevates the head section of the bed.
- **Top Right Button:** Lowers the head section of the bed.
- **Middle Left Button:** Elevates the foot section of the bed.
- **Middle Right Button:** Lowers the foot section of the bed.
- **Bottom Left Button:** Elevates both the head and foot sections simultaneously.
- **Bottom Right Button:** Lowers both the head and foot sections simultaneously to a flat position.

To activate a function, press and hold the corresponding button until the desired position is reached. Release the button to stop the movement.

4. MAINTENANCE

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote. Avoid using liquid cleaners, aerosols, or harsh chemicals, as these can damage the remote's electronics or finish.
- **Battery Replacement:** Replace batteries promptly when the remote's performance diminishes or it stops responding. Always use new batteries of the specified type. Do not mix old and new batteries or different types of batteries.
- **Storage:** Store the remote in a dry place, away from extreme temperatures and direct sunlight.

- **Handling:** Avoid dropping the remote or subjecting it to strong impacts, which can cause internal damage.

5. TROUBLESHOOTING

If you encounter issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
 - Check if the batteries are correctly installed and have sufficient charge. Replace them if necessary.
 - Ensure the adjustable bed is properly plugged into a working power outlet.
 - Verify that the remote is paired with the bed's control box. If not, follow the pairing instructions in Section 2.2.
- **Intermittent Operation:**
 - This could indicate low battery power. Replace the batteries.
 - Ensure there are no obstructions between the remote and the bed's control box.
- **Bed Not Moving Smoothly:**
 - This is typically not a remote issue. Check the bed's power connection and ensure no objects are obstructing the bed's movement mechanisms.

If these steps do not resolve the issue, please contact the manufacturer or your retailer for further assistance.

6. SPECIFICATIONS

Product Dimensions	2 x 1 x 6 inches
Item Model Number	Leggett Symmetry
Brand	Linak Remotes
Manufacturer	Leggett Remotes
Color	Black
Special Feature	Ergonomic
Max Number of Supported Devices	1
Compatible Devices	Leggett Remote - Must match picture