Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy IJ2001DTISOAZ

iJoy ISO Wireless Bluetooth Headphones

Model: IJ2001DTISOAZ

Introduction

Thank you for choosing the iJoy ISO Wireless Bluetooth Headphones. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new headphones. Please read this manual thoroughly to ensure optimal performance and longevity of your device.



Image: iJoy ISO Wireless Bluetooth Headphones in a glossy green finish, showcasing their over-ear design.

What's Included

- iJoy ISO Wireless Bluetooth Headphones

- USB Charging Cable
- 3.5mm Audio Cable
- User Manual

Product Overview

Controls and Ports



Image: A diagram highlighting the control buttons on the right earcup, including Play/Pause, Answer/Hang Up, Next Track/Volume Up, and Previous Track/Volume Down.

- **Power Button / Multi-function Button:** Used for powering on/off, play/pause, answering/ending calls.
- **Volume Up / Next Track Button:** Press briefly to increase volume, press and hold for next track.
- **Volume Down / Previous Track Button:** Press briefly to decrease volume, press and hold for previous track.
- **Microphone:** For hands-free calls.
- **3.5mm Audio Jack:** For wired connection.

- **USB Charging Port:** For charging the headphones.

Setup

Charging the Headphones

Before first use, fully charge your headphones. Connect the USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The LED indicator will illuminate during charging. Once fully charged, the LED indicator will change or turn off.
Charging Time: Approximately 2.5 hours.

Bluetooth Pairing

To pair your headphones with a Bluetooth-enabled device:

1. Ensure the headphones are turned off.
2. Press and hold the Power Button until the LED indicator flashes rapidly (usually blue and red), indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "iJoy ISO" from the list of found devices.
5. Once connected, the LED indicator will typically show a slow blue flash or solid blue, and you may hear an audible confirmation.



Image: Illustration demonstrating the Bluetooth 5.0 connectivity of the headphones with various devices such as MP3 players, PCs, TVs, smartphones, iPads, and notebooks.

Operating

Power On/Off

- **Power On:** Press and hold the Power Button for approximately 3 seconds until the LED indicator lights up and you hear a power-on prompt.
- **Power Off:** Press and hold the Power Button for approximately 3 seconds until the LED indicator turns off and you hear a power-off prompt.

Music Playback

- **Play/Pause:** Press the Power Button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.

- **Volume Up:** Press the Volume Up button briefly.
- **Volume Down:** Press the Volume Down button briefly.

Call Management

- **Answer/End Call:** Press the Power Button once.
- **Reject Call:** Press and hold the Power Button for 2 seconds.
- **Redial Last Number:** Double-press the Power Button.

Wired Use

If the headphones run out of battery or you prefer a wired connection, you can use the included 3.5mm audio cable. Simply plug one end into the headphone's 3.5mm audio jack and the other end into your audio device's 3.5mm output.




Image: A person wearing the headphones, with a visual cue indicating that a 3.5mm backup cable is included for wired use when the battery is low.

Folding Design

The iJoy ISO headphones feature a convenient folding design for easy storage and portability. Simply fold the earcups inwards towards the headband to make them more compact.



Image: The headphones shown in their folded configuration, highlighting the compact folding design and adjustable headband for comfortable fit.

Video: An official product video demonstrating the features of the iJoy ISO Wireless Bluetooth Headphones, including their compact design, comfortable fit, and long battery life.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care:** To preserve battery life, charge the headphones regularly, even if not used frequently. Avoid fully draining the battery for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Headphones won't turn on.	Battery is low or depleted.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode (flashing LED). Turn device Bluetooth off and on. Move headphones closer to device (within 10m).
No sound or poor sound quality.	Volume too low; incorrect audio source; interference; wired connection issue.	Increase volume on headphones and device. Ensure correct audio output is selected on device. Move away from other wireless devices. Check 3.5mm cable connection if using wired.
Charging LED behavior is inconsistent.	Minor variations in LED indication.	Ensure the charging cable is securely connected. If the LED blinks, try unplugging and re-plugging until it shows a steady indication (e.g., solid red) for charging. The LED will change or turn off when fully charged.

Specifications



Image: A graphic displaying key specifications of the iJoy ISO headphones, including Bluetooth version, battery capacity, playback time, talk time, charging time, and wireless range.

Feature	Detail
Model Number	IJ2001DTISOAZ
Connectivity Technology	Wireless, Wired
Wireless Communication	Bluetooth
Bluetooth Version	5.0
Battery Capacity	500mAh
Playback Time	Up to 26 Hours
Talk Time	Up to 30 Hours

Feature	Detail
Charging Time	2.5 Hours
Wireless Range	10 meters (33 feet)
Frequency Range	20 Hz - 20,000 Hz
Product Dimensions	6 x 3.5 x 6 inches
Item Weight	11.3 ounces
UPC	842700130126

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official iJoy website. Keep your purchase receipt for warranty claims.
If you encounter any issues not covered in this manual, please contact iJoy customer support for assistance.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZS27Y7P

More documents and user manuals: **https://manuals.plus/**