iJoy IJ2001BRISOAZ

iJoy ISO Bluetooth 5.0 Wireless Over Ear Foldable Stereo Headphones User Manual

Model: IJ2001BRISOAZ

Introduction

Thank you for purchasing the iJoy ISO Bluetooth 5.0 Wireless Over Ear Foldable Stereo Headphones. These headphones are designed to provide a high-quality audio experience with the convenience of wireless connectivity, long battery life, and a comfortable, foldable design. This manual will guide you through the setup, operation, and maintenance of your new headphones.

Safety Information

- Do not expose the headphones to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not attempt to disassemble or repair the headphones yourself. Refer to qualified service personnel.
- Clean the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Listen at moderate volume levels to prevent hearing damage.

Package Contents

- iJoy ISO Bluetooth Headphones
- Charging Cable
- 3.5mm Audio Cable

Product Overview

Familiarize yourself with the components of your iJoy ISO headphones.



Figure 1: iJoy ISO Bluetooth Headphones (Black/Red)



Figure 2: Headphone Controls - Illustrates the location of Play/Pause, Volume Up/Next Track, and Volume Down/Previous Track buttons on the ear cup.

Setup

Charging the Headphones

Before first use, fully charge your headphones. A full charge provides up to 30 hours of playtime.

1. Connect the charging cable to the charging port on the headphone.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator will show charging status (refer to product specific LED behavior for full details).
4. Charging typically takes approximately 2.5 hours.



Figure 3: Extended Playtime - Visual representation of the 30-hour battery life.




Figure 4: Wired Backup Option - Demonstrates the use of the included 3.5mm cable for continued listening even when the battery is depleted.

Bluetooth Pairing

Pair your headphones with your Bluetooth-enabled device.

1. Ensure the headphones are charged and turned off.
2. Press and hold the Power button on the headphones until the LED indicator flashes rapidly (usually blue and red), indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "iJoy ISO" from the list of found devices.
5. Once connected, the LED indicator will typically show a solid blue light or slow blue flashes.
6. The headphones will automatically reconnect to the last paired device when powered on, if within range (up to 33 feet).



Figure 5: Bluetooth 5.0 Connectivity - Illustrates seamless connection to various devices for music streaming.

Operating Instructions

Basic Controls

- **Power On/Off:** Press and hold the Power button.
- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

Phone Calls

- **Answer/End Call:** Press the Play/Pause button once.

- **Reject Call:** Press and hold the Play/Pause button.
- **Redial Last Number:** Double-press the Play/Pause button.

Wired Mode

If the battery is low or you prefer a wired connection, use the included 3.5mm audio cable.

1. Plug one end of the 3.5mm audio cable into the audio input jack on the headphones.
2. Plug the other end into the 3.5mm audio output jack of your device.
3. In wired mode, the headphone's battery is not used, and some controls on the headphones may be inactive.

Your browser does not support the video tag.

Video: iJoy ISO Wireless Bluetooth Headphones - This video demonstrates the features and usage of the iJoy ISO headphones, including their comfortable fit, long battery life, and compact folding design.

Maintenance

Cleaning

Wipe the headphones with a soft, dry cloth. Do not use liquid cleaners or sprays.

Storage

When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage and easy portability.



Figure 6: Folding Design - Illustrates how the headphones can be folded for convenient storage and travel, along with the adjustable headband feature.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode. Turn device Bluetooth off and on. Move headphones closer to device (within 33 feet).

Problem	Possible Cause	Solution
No sound or poor sound quality.	Volume too low; headphones not connected; interference.	Increase volume on headphones and device. Re-pair headphones. Move away from other wireless devices. Try wired connection.
Microphone not working.	Device settings; microphone blocked.	Check device audio input settings. Ensure microphone is not covered.

Specifications

Feature	Detail
Model Name	IJ2001BRISOAZ
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	33 Feet (10 meters)
Battery Life	Up to 30 Hours
Charging Time	Approx. 2.5 Hours
Headphones Jack	3.5 mm Jack
Control Method	Touch
Noise Control	Active Noise Cancellation
Form Factor	Over Ear
Item Weight	12 ounces
Product Dimensions	6 x 3.5 x 6 inches

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official iJoy website. Keep your proof of purchase for any warranty claims.
For further assistance, you may contact iJoy customer service through their official channels.