

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 25V AC/DC Adapter Instruction Manual for Hoover BH52230 Vacuum Cleaners

UPBRIGHT BH52230

UpBright 25V AC/DC Adapter Instruction Manual

For Hoover BH52230 Series Cordless Vacuum Cleaners

1. PRODUCT OVERVIEW

This manual provides essential information for the safe and proper use of your UpBright 25V AC/DC Adapter. This adapter is designed to provide power and charge the battery of compatible Hoover cordless vacuum cleaners.



Figure 1: UpBright 25V AC/DC Adapter. This image shows the compact black power adapter with its attached power cord and barrel-type connector.

Compatibility: This adapter is compatible with various Hoover models, including BH52230, BH52230-RB, PN-440011694, ERI0492 Cruise Multi-Floor Ultra Light 21.6 Volt Lithium Ion Cordless Freedom Vacuum Cleaner series. Please verify your vacuum cleaner's model number and power requirements before use to ensure proper fit and function.



Figure 2: Example of compatible Hoover Cruise Multi-Floor vacuum cleaner. This image displays a user operating a Hoover cordless stick vacuum cleaner, highlighting its design and features, including the main unit and various attachments.

2. SETUP AND CONNECTION

- 1. Inspect the Adapter:** Before first use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
- 2. Connect to Vacuum:** Locate the charging port on your Hoover vacuum cleaner. Insert the barrel connector of the UpBright adapter firmly into the charging port.



Figure 3: Close-up of the barrel-type connector. This image shows the metallic tip and plastic housing of the adapter's barrel connector, which plugs into the vacuum cleaner.

3. **Connect to Power Outlet:** Plug the adapter's power prongs into a standard 100-240VAC 50/60Hz wall outlet. Ensure the outlet is easily accessible.
4. **International Use:** For international use, ensure you have the correct regional outlet adapter. The product may come with a suitable outlet adapter for your region (e.g., AU, EU, UK).



Figure 4: Examples of international outlet adapters. This image displays three different power plug types: Australian (AU), European (EU), and United Kingdom (UK), indicating regional compatibility options.

3. OPERATING INSTRUCTIONS (CHARGING)

- Once connected, the adapter will begin charging the vacuum cleaner's battery.
- Refer to your Hoover vacuum cleaner's manual for specific charging indicators (e.g., LED lights) and estimated charging times.
- Disconnect the adapter from the power outlet and the vacuum cleaner once charging is complete or when the vacuum is not in use.
- Do not leave the adapter plugged in indefinitely when not charging a device.

4. MAINTENANCE AND SAFETY

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Wipe the adapter with a dry, soft cloth. Do not use liquid cleaners or sprays.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid wrapping the cable too tightly around the adapter.
- **Safety Precautions:**
 - Do not expose the adapter to water or extreme temperatures.
 - Do not attempt to open or modify the adapter.
 - Keep out of reach of children.
 - Ensure proper ventilation around the adapter during use.
- **Protection Features:** The adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.

5. TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC Adapter, consider the following:

- **No Power/Charging:**
 - Ensure the adapter is securely plugged into both the wall outlet and the vacuum cleaner's charging port.
 - Test the wall outlet with another device to confirm it is functional.
 - Verify that the adapter's barrel connector fits correctly and makes proper contact with the vacuum's charging port. *Note: Some Hoover BH52230 models may have specific connector requirements. Double-check your vacuum's port design against the adapter's connector.*
- **Vacuum Not Holding Charge:**

- Rechargeable batteries have a limited lifespan (typically 1 to 3 years). If your vacuum's battery is old or degraded, it may no longer accept a charge, which is a battery issue, not an adapter issue.
- Consult your vacuum cleaner's manual for battery replacement procedures or service options.
- **Overheating:** If the adapter feels excessively hot, disconnect it immediately from the power source and the vacuum. Ensure it is used in a well-ventilated area. If overheating persists, discontinue use and contact support.

6. SPECIFICATIONS

Input Voltage	100-240VAC, 50/60Hz
Output Voltage	25VDC
Output Current	0.6A (600mA)
Wattage	15 watts
Connector Type	Barrel Round Connector
Color	Black
Product Dimensions	3 x 3 x 1 inches
Item Weight	2.39 ounces

7. WARRANTY INFORMATION

UpBright products are designed for reliability. This adapter comes with a **30-day refund policy** and a **24-month exchange warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.



Figure 5: UpBright Limited Warranty Certificate. This image shows a document titled "LIMITED WARRANTY CERTIFICATE" alongside a golden product warranty seal, indicating the product's warranty coverage.

8. CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact UpBright customer service through your original point of purchase or visit the official UpBright website. When contacting support, please have your product model information and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07ZT35C26>

More documents and user manuals: **<https://manuals.plus/>**